



COPPER MOUNTAIN  
TECHNOLOGIES

# 1-Port VNA Series

R60

R140

R180

RNVNA Network Analyzer

Programming Manual COM/DCOM



Revision 20.1

April 2020

## TABLE OF CONTENTS

|  |           |
|--|-----------|
| <b>Introduction .....</b>  | <b>10</b> |
| <b>1 Registering COM Server .....</b>  | <b>11</b> |
| <b>2 COM Technology Overview .....</b>   | <b>12</b> |
| <b>3 Automation Server .....</b>   | <b>13</b> |
| <b>4 Automation Controllers .....</b>  | <b>14</b> |
| <b>5 Local and Remote Server .....</b>   | <b>15</b> |
| <b>6 Structure of COM Objects .....</b>  | <b>16</b> |
| <b>7 Accessing the Application Object .....</b>  | <b>18</b> |
| <b>8 Object Methods.....</b>   | <b>20</b> |
| <b>9 Object Properties.....</b>  | <b>21</b> |
| <b>10 Error Handling .....</b>   | <b>22</b> |
| <b>11 COM Automation Data Types.....</b>   | <b>24</b> |
| <b>12 Measurement Data Arrays .....</b>  | <b>25</b> |
| <b>13 COM Server Commands .....</b>  | <b>26</b> |
| NAME.....  | 26        |
| Ready .....  | 26        |
| SCPI.ABORT .....   | 27        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.DEEMbed.PORT( <i>Pt</i> ).USER.FILEname .....    | 28        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.DEEMbed.PORT( <i>Pt</i> ).STATE .....            | 30        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.PMCircuit.PORT( <i>Pt</i> ).USER. FILEname ..... | 31        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.PMCircuit.PORT( <i>Pt</i> ).STATE .....          | 32        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.ZCONversion.PORT( <i>Pt</i> ).Z0.R .....         | 33        |
| SCPI.CALCulate( <i>Ch</i> ).FSIMulator.SENDed.ZCONversion.STATE .....                          | 34        |
| SCPI.CALCulate( <i>Ch</i> ).PARameter.COUNT .....  | 35        |
| SCPI.CALCulate( <i>Ch</i> ).PARameter( <i>Tr</i> ).DEFine .....                                | 36        |
| SCPI.CALCulate( <i>Ch</i> ).PARameter( <i>Tr</i> ).SElect .....                                | 37        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.CONVersion.FUNCTion .....                                 | 38        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.CONVersion.STATE .....                                    | 39        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.CORRection.EDElay.TIME .....                              | 40        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.CORRection.OFFSet.PHASE .....                             | 41        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.DATA.FDATa .....  | 42        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.DATA.FMEmory .....  | 43        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.DATA.SDATa .....  | 44        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.DATA.SMEmory .....  | 45        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.CENTer .....                             | 46        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.SHAPe .....                              | 47        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.SPAN .....                               | 48        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.START.....                               | 49        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.STATE .....                              | 50        |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.STOP.....                                | 51        |

|   |    |
|---|----|
| SCPI.CALCulate( <i>Ch</i> ).SElected.FILTer.GATE.TIME.TYPE .....                      | 52 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FORMat.....                                      | 53 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.DATA .....                              | 55 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.DOMain.COUPle.....                      | 56 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.DOMain.START .....                      | 57 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.DOMain.STATE .....                      | 58 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.DOMain.STOP.....                        | 59 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.EXECute .....                           | 60 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.PEXCursion .....                        | 61 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.POINTs .....                            | 62 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.PPOLarity.....                          | 63 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.TARGet .....                            | 64 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.TTRansition .....                       | 65 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCtion.TYPE.....                               | 66 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.DATA.....                                  | 67 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.DISPlay.STATE.....                         | 68 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.FAIL.....                                  | 69 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.OFFSet.AMPLitude .....                     | 70 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.OFFSet.STIMulus .....                      | 71 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.REPort.ALL .....                           | 72 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.REPort.DATA.....                           | 73 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.REPort.POINTs .....                        | 74 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.LIMit.STATE.....                                 | 75 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).ACTivate.....                | 76 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).BWIDth.DATA .....            | 77 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.BWIDth.REference .....                    | 78 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.BWIDth.STATE .....                        | 79 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.BWIDth.THreshold .....                    | 80 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.BWIDth.TYPE .....                         | 81 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.COUPle .....                              | 82 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.DOMain. START ..... | 83 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.DOMain. STATE ..... | 84 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.DOMain. STOP.....   | 85 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.EXECute .....       | 86 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.PEXCursion .....    | 87 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.PPOLarity.....      | 88 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.TARGet .....        | 89 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.TRACKing .....      | 90 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.TTRansition .....   | 91 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.TYPE.....           | 92 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.REference.STATE.....                      | 93 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).SET_ .....                   | 94 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).STATE .....                  | 95 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).X .....                      | 96 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).Y .....                      | 97 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer.COUNT .....                               | 98 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MATH.DELETE.....                                 | 99 |

|  |     |
|--|-----|
| SCPI.CALCulate( <i>Ch</i> ).SElected.MATH.FUNCTION .....                   | 100 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MATH.MEMorize .....                   | 101 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MAXhold.STATE .....                   | 101 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MStatistics.DATA.....                 | 102 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MStatistics.DOMain.MARKer.START ..... | 103 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MStatistics.DOMain.MARKer.STOP .....  | 104 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MStatistics.DOMain.STATE .....        | 105 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.MStatistics.STATE.....                | 106 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.RLIMit.DATA.....                      | 107 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.RLIMit.DISPlay.LINE .....             | 108 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.RLIMit.FAIL.....                      | 108 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.RLIMit.REPort.DATA .....              | 109 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.RLIMit.STATE.....                     | 110 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.SMOothing.APERture .....              | 111 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.SMOothing.STATE.....                  | 112 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.DISTance.CENTer.....        | 113 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.DISTance.SPAN .....         | 114 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.DISTance.MINimum .....      | 115 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.DISTance.MAXimum .....      | 116 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.DISTance.UNIT .....         | 117 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.CENTer .....           | 118 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.IMPulse.WIDTh .....    | 119 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.KBESsel.....           | 120 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.LPFrequency .....      | 121 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.SPAN .....             | 122 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.START.....             | 123 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.STATE .....            | 124 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.STEP.RTIme .....       | 125 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.STIMulus .....         | 126 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.STOP .....             | 127 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.TYPE .....             | 128 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.TIME.UNIT .....             | 129 |
| SCPI.CALCulate( <i>Ch</i> ).SElected.TRANSform.KWINdow .....               | 130 |
| SCPI.CALCulate( <i>Ch</i> ).TRACe( <i>Tr</i> ).DATA.FDATA .....            | 131 |
| SCPI.CALCulate( <i>Ch</i> ).TRACe( <i>Tr</i> ).DATA.FMEmory .....          | 132 |
| SCPI.CALCulate( <i>Ch</i> ).TRACe( <i>Tr</i> ).DATA.SDATA .....            | 133 |
| SCPI.CALCulate( <i>Ch</i> ).TRACe( <i>Tr</i> ).DATA.SMEMory .....          | 134 |
| SCPI.DEVices.ADDNext .....   | 135 |
| SCPI.DEVices.COUNT.....  | 135 |
| SCPI.DEVices.MOVDown(Port).....  | 136 |
| SCPI.DEVices.MOVUp(Port).....  | 136 |
| SCPI.DEVices.READy(Port) .....   | 137 |
| SCPI.DEVices.REFERence.ADJust.Execute .....                                | 137 |
| SCPI.DEVices. REFERence.ADJust.Period .....                                | 138 |
| SCPI.DEVices. REFERence.Offset(Port).....                                  | 139 |
| SCPI.DEVices.REMLast .....   | 139 |
| SCPI.DEVices.SERial(Port) .....  | 140 |

|  |     |
|--|-----|
| SCPI.DEVices.SYNChronization.Method .....  | 140 |
| SCPI.DISPlay.ANNotation.FREQuency.STATE .....  | 141 |
| SCPI.DISPlay.COLOR.BACK .....  | 142 |
| SCPI.DISPlay.COLOR.GRATicule .....   | 143 |
| SCPI.DISPlay.COLOR.RESet .....   | 144 |
| SCPI.DISPlay.COLOR.TRACe( <i>Tr</i> ).DATA .....                                       | 145 |
| SCPI.DISPlay.COLOR.TRACe( <i>Tr</i> ).MEMORY .....                                     | 146 |
| SCPI.DISPlay.ENABLE .....  | 147 |
| SCPI.DISPlay.FSIGn .....   | 148 |
| SCPI.DISPlay.IMGAGE .....  | 149 |
| SCPI.DISPlay.MAXimize .....  | 150 |
| SCPI.DISPlay.SPLit .....   | 151 |
| SCPI.DISPlay.UPDate_.IMMEDIATE .....   | 152 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).ACTivate .....  | 152 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).ANNOTATION.MARKer.ALIGN.TYPE .....                    | 153 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).ANNOTATION.MARKer.SINGle.STATE .....                  | 154 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).MAXimize .....  | 155 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).SPLit .....   | 156 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TITLe.DATA .....                                      | 157 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TITLe.STATE .....                                     | 158 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).ANNOTATION.MARKer.MEMORY .....     | 159 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).ANNOTATION.MARKer.POSition.X ..... | 160 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).ANNOTATION.MARKer.POSition.Y ..... | 161 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).Y.SCALE.AUTO .....                 | 162 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).Y.SCALE.PDIVision .....            | 163 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).Y.SCALE.RLEVel .....               | 164 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).TRACe( <i>Tr</i> ).Y.SCALE.RPOSITION .....            | 165 |
| SCPI.DISPlay.WINDOW( <i>Ch</i> ).Y.SCALE.DIVisions .....                               | 166 |
| SCPI.HCOPy.DATE.STAMP .....  | 167 |
| SCPI.HCOPy.IMGAGE .....  | 168 |
| SCPI.HCOPy.IMMEDIATE .....   | 168 |
| SCPI.HCOPy.PAINT .....   | 169 |
| SCPI.IEEE488.2.CLS .....   | 170 |
| SCPI.IEEE488.2.IDN .....   | 171 |
| SCPI.IEEE488.2.RST .....   | 171 |
| SCPI.IEEE488.2.TRG .....   | 172 |
| SCPI.IEEE488.2.WAI .....   | 172 |
| SCPI.INITiate( <i>Ch</i> ).CONTinuous .....  | 173 |
| SCPI.INITiate( <i>Ch</i> ).IMMEDIATE .....   | 174 |
| SCPI.MMEmory.COPY( <i>Src</i> , <i>Dst</i> ) .....                                     | 175 |
| SCPI.MMEmory.DELETE( <i>File</i> ) .....   | 175 |
| SCPI.MMEmory.LOAD.CHANnel.STATE .....  | 176 |
| SCPI.MMEmory.LOAD.CKIT( <i>Ck</i> ) .....  | 177 |
| SCPI.MMEmory.LOAD.CALibration .....  | 178 |
| SCPI.MMEmory.LOAD.LIMIT .....  | 179 |
| SCPI.MMEmory.LOAD.RLIMIT .....   | 180 |
| SCPI.MMEmory.LOAD.SEGMent .....  | 181 |

|   |     |
|---|-----|
| SCPI.MMEMORY.LOAD.SNP.DATA.....                                   | 182 |
| SCPI.MMEMORY.LOAD.SNP.TRACe(Tr).MEMory .....                      | 183 |
| SCPI.MMEMORY.LOAD.STATE .....                                     | 184 |
| SCPI.MMEMORY.MDIRectory .....                                     | 185 |
| SCPI.MMEMORY.STORe.CHANnel.CLEar .....                            | 185 |
| SCPI.MMEMORY.STORe.CHANnel.STATE .....                            | 186 |
| SCPI.MMEMORY.STORe.CKIT(Ck) .....                                 | 187 |
| SCPI.MMEMORY.STORe.CALibration .....                              | 188 |
| SCPI.MMEMORY.STORe.FDATA .....                                    | 189 |
| SCPI.MMEMORY.STORe.IMAGe .....                                    | 190 |
| SCPI.MMEMORY.STORe.LIMit .....                                    | 191 |
| SCPI.MMEMORY.STORe.RLIMit .....                                   | 192 |
| SCPI.MMEMORY.STORe.SEGment .....                                  | 193 |
| SCPI.MMEMORY.STORe.SNP.DATA .....                                 | 194 |
| SCPI.MMEMORY.STORe.SNP.FORMAT .....                               | 195 |
| SCPI.MMEMORY.STORe.SNP.TYPE.S1P .....                             | 196 |
| SCPI.MMEMORY.STORe.SNP.TYPE.S2P .....                             | 197 |
| SCPI.MMEMORY.STORe.STATE .....                                    | 198 |
| SCPI.MMEMORY.STORe.STYPe .....                                    | 199 |
| SCPI.OUTPut.STATE .....   | 200 |
| SCPI.SENSE(Ch).AVERage.CLEar .....                                | 200 |
| SCPI.SENSE(Ch).AVERage.COUNT .....                                | 201 |
| SCPI.SENSE(Ch).AVERage.CURRent .....                              | 202 |
| SCPI.SENSE(Ch).AVERage.STATE .....                                | 202 |
| SCPI.SENSE(Ch).BANDwidth.RESolution .....                         | 203 |
| SCPI.SENSE(Ch).CORRection.CLEar .....                             | 204 |
| SCPI.SENSE(Ch).CORRection.COEFficient.DATA(Str, Pt_r, Pt_s) ..... | 205 |
| SCPI.SENSE(Ch).CORRection.COEFficient.METHOD.RESPonse.OPEN .....  | 206 |
| SCPI.SENSE(Ch).CORRection.COEFficient.METHOD.RESPonse.SHORT ..... | 207 |
| SCPI.SENSE(Ch).CORRection.COEFficient.METHOD.SOLT1 .....          | 208 |
| SCPI.SENSE(Ch).CORRection.COEFficient.SAVE .....                  | 209 |
| SCPI.SENSE(Ch).CORRection.COLlect.ACQuire.LOAD .....              | 210 |
| SCPI.SENSE(Ch).CORRection.COLlect.ACQuire.OPEN .....              | 211 |
| SCPI.SENSE(Ch).CORRection.COLlect.ACQuire.SHORT .....             | 212 |
| SCPI.SENSE(Ch).CORRection.COLlect.ACQuire.THRU .....              | 213 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.LABel .....                | 214 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.RESet .....                | 215 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.SElect .....               | 216 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).C0 .....         | 217 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).C1 .....         | 218 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).C2 .....         | 219 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).C3 .....         | 220 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).DElay .....      | 221 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).LO .....         | 222 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).L1 .....         | 223 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).L2 .....         | 224 |
| SCPI.SENSE(Ch).CORRection.COLlect.CKIT.STAN(Std).L3 .....         | 225 |

|   |     |
|---|-----|
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).LABel .....                  | 226 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).LOSS .....                   | 227 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).TYPE .....                   | 228 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).Z0 .....                     | 229 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.CLEAR .....  | 230 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.DATA.LOAD( <i>Pt</i> ).....                          | 231 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.DATA.OPEN( <i>Pt</i> ) .....                         | 232 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.DATA.SHORT( <i>Pt</i> ) .....                        | 233 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.INFormation .....                               | 234 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.CHECK.Execute .....                             | 235 |
| SCPI.SENSE.CORRection.COLLect.ECAL.ORlenation.Execute .....                                     | 235 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.ORlenation.STATE .....                          | 236 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.SOLT1 .....                                     | 237 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.SOLT2 .....                                     | 238 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.UChar .....                                     | 239 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.EREspone .....                                | 240 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.RESPonse.OPEN .....                           | 241 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.RESPonse.SHORT .....                          | 242 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.SOLT1 .....                                   | 243 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.SOLT2 .....                                   | 244 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.RESPonse.THRU .....                           | 245 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.TYPE .....                                    | 246 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.SAVE .....   | 247 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.PORT( <i>Pt</i> ).FREQuency( <i>Ls</i> ) .....     | 248 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.PORT( <i>Pt</i> ).INCLUDE( <i>Ls</i> ).STATE ..... | 249 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.PORT( <i>Pt</i> ).LDC .....                        | 250 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.PORT( <i>Pt</i> ).LOSS( <i>Ls</i> ) .....          | 251 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.PORT( <i>Pt</i> ).TIME .....                       | 252 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.EXTension.STATE .....  | 253 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.IMPedance.INPUT.MAGNitude .....                              | 254 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.STATE .....  | 255 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.TRANSform.DISTance.FREQuency .....                           | 256 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.TRANSform.DISTance.LOSS .....                                | 257 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.TRANSform.DISTance.RVELOCITY .....                           | 258 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.TRANSform.DISTance.STATE .....                               | 259 |
| SCPI.SENSE( <i>Ch</i> ).CORRection.TYPE( <i>Tr</i> ) .....                                      | 260 |
| SCPI.SENSE( <i>Ch</i> ).FREQuency.CENTer .....  | 261 |
| SCPI.SENSE( <i>Ch</i> ).FREQuency.DATA .....  | 262 |
| SCPI.SENSE( <i>Ch</i> ).FREQuency.SPAN .....  | 263 |
| SCPI.SENSE( <i>Ch</i> ).FREQuency.START .....   | 264 |
| SCPI.SENSE( <i>Ch</i> ).FREQuency.STOP .....  | 265 |
| SCPI.SENSE( <i>Ch</i> ).ROSCillator.SOURce .....  | 266 |
| SCPI.SENSE( <i>Ch</i> ).SEGment.DATA .....  | 267 |
| SCPI.SENSE( <i>Ch</i> ).SWEep.POINT.TIME .....  | 268 |
| SCPI.SENSE( <i>Ch</i> ).SWEep.POINts .....  | 269 |
| SCPI.SENSE( <i>Ch</i> ).SWEep.REVerse.STATE .....   | 270 |
| SCPI.SENSE( <i>Ch</i> ).SWEep.TYPE .....  | 271 |

|  |     |
|--|-----|
| SCPI.SERViCe.CHANnel.ACTive .....                                      | 272 |
| SCPI.SERViCe.CHANnel.COUNT .....                                       | 272 |
| SCPI.SERViCe.CHANnel( <i>Ch</i> ).TRACe.ACTive .....                   | 273 |
| SCPI.SERViCe.CHANnel.TRACe.COUNT.....                                  | 273 |
| SCPI.SERViCe.PORT.COUNT.....   | 274 |
| SCPI.SERViCe.SWEep.FREQency.MAXimum .....                              | 274 |
| SCPI.SERViCe.SWEep.FREQency.MINimum.....                               | 275 |
| SCPI.SERViCe.SWEep.POINts .....  | 275 |
| SCPI.SOURce( <i>Ch</i> ).POWER.LEVel.STATE.....                        | 276 |
| SCPI.SOURce( <i>Ch</i> ).POWER.LEVel.IMMEDIATE.AMPLitude .....         | 277 |
| SCPI.STATus.OPERation.CONDITION.....                                   | 278 |
| SCPI.STATus.OPERation.ENABLE .....                                     | 278 |
| SCPI.STATus.OPERation.EVENT.....                                       | 279 |
| SCPI.STATus.OPERation.NTRansition .....                                | 279 |
| SCPI.STATus.OPERation.PTRansition.....                                 | 280 |
| SCPI.STATus.PRESET.....  | 280 |
| SCPI.STATus.QUESTIONable.CONDITION .....                               | 281 |
| SCPI.STATus.QUESTIONable.ENABLE.....                                   | 281 |
| SCPI.STATus.QUESTIONable.EVENT.....                                    | 282 |
| SCPI.STATus.QUESTIONable.LIMIT.CHANnel( <i>Ch</i> ).CONDITION .....    | 282 |
| SCPI.STATus.QUESTIONable.LIMIT.CHANnel( <i>Ch</i> ).ENABLE .....       | 283 |
| SCPI.STATus.QUESTIONable.LIMIT.CHANnel( <i>Ch</i> ).EVENT .....        | 283 |
| SCPI.STATus.QUESTIONable.LIMIT.CHANnel( <i>Ch</i> ).NTRansition .....  | 284 |
| SCPI.STATus.QUESTIONable.LIMIT.CHANnel( <i>Ch</i> ).PTRansition .....  | 285 |
| SCPI.STATus.QUESTIONable.LIMIT.CONDITION .....                         | 286 |
| SCPI.STATus.QUESTIONable.LIMIT.ENABLE .....                            | 286 |
| SCPI.STATus.QUESTIONable.LIMIT.EVENT .....                             | 287 |
| SCPI.STATus.QUESTIONable.LIMIT.NTRansition.....                        | 287 |
| SCPI.STATus.QUESTIONable.LIMIT.PTRansition .....                       | 288 |
| SCPI.STATus.QUESTIONable.NTRansition .....                             | 289 |
| SCPI.STATus.QUESTIONable.PTRansition .....                             | 290 |
| SCPI.STATus.QUESTIONable.RLIMIT.CHANnel( <i>Ch</i> ).CONDITION .....   | 291 |
| SCPI.STATus.QUESTIONable.RLIMIT.CHANnel( <i>Ch</i> ).ENABLE .....      | 292 |
| SCPI.STATus.QUESTIONable.RLIMIT.CHANnel( <i>Ch</i> ).EVENT.....        | 293 |
| SCPI.STATus.QUESTIONable.RLIMIT.CHANnel( <i>Ch</i> ).NTRansition ..... | 294 |
| SCPI.STATus.QUESTIONable.RLIMIT.CHANnel( <i>Ch</i> ).PTRansition ..... | 295 |
| SCPI.STATus.QUESTIONable.RLIMIT.CONDITION .....                        | 296 |
| SCPI.STATus.QUESTIONable.RLIMIT.ENABLE .....                           | 297 |
| SCPI.STATus.QUESTIONable.RLIMIT.EVENT .....                            | 297 |
| SCPI.STATus.QUESTIONable.RLIMIT.NTRansition .....                      | 298 |
| SCPI.STATus.QUESTIONable.RLIMIT.PTRansition .....                      | 299 |
| SCPI.SYSTem.COMMUnicate.ECAL.TEMPerature.SENSor .....                  | 300 |
| SCPI.SYSTem.CORRection.STATE.....                                      | 301 |
| SCPI.SYSTem.DATE .....   | 302 |
| SCPI.SYSTem.HIDe .....   | 302 |
| SCPI.SYSTem.LOCal.....   | 303 |
| SCPI.SYSTem.PRESET.....  | 303 |

|   |            |
|---|------------|
| SCPI.SYSTem.REMote .....                      | 304        |
| SCPI.SYSTem.RWLock .....                      | 304        |
| SCPI.SYSTem.SHOp .....                        | 305        |
| SCPI.SYSTem.STANdby .....                     | 305        |
| SCPI.SYSTem.TEMPerature.SENSor(Idx).....      | 306        |
| SCPI.SYSTem.TERMinate .....                   | 306        |
| SCPI.SYSTem.TIME.....                         | 307        |
| SCPI.TRIGger.OUTPut.FUNCtion.....             | 308        |
| SCPI.TRIGger.OUTPut.POLarity .....            | 309        |
| SCPI.TRIGger.OUTPut.STATE .....               | 310        |
| SCPI.TRIGger.SEQuence.EXTernal.Delay .....    | 311        |
| SCPI.TRIGger.SEQuence.EXTernal.POSition ..... | 312        |
| SCPI.TRIGger.SEQuence.EXTernal.SLOPe .....    | 313        |
| SCPI.TRIGger.SEQuence.IMMEDIATE .....         | 314        |
| SCPI.TRIGger.SEQuence.POINT.....              | 315        |
| SCPI.TRIGger.SEQuence.SINGle.....             | 316        |
| SCPI.TRIGger.SEQuence.SOURce.....             | 317        |
| SCPI.TRIGger.SEQuence.STATE .....             | 318        |
| <b>Appendix 1. Error Codes .....</b>          | <b>319</b> |
| <b>Appendix 2. Programming Examples.....</b>  | <b>320</b> |

## INTRODUCTION

This Programming Manual contains information on remote control over R54, R140, R60, R180 Analyzer or and N-port mode of VNA (RNVNA) and its data communication by means of user programs written with COM/DCOM technology.

This Operating Manual corresponds to software version:

- RVNA - 19.4.4.
- RNVNA - 20.1.2.

COM technology is used when a user program runs together with an external measurement instrument program on one PC. DCOM technology is used when a user program runs on a PC connected with the measurement instrument by LAN.

Methods and techniques for writing of user programs are same for the both technologies. The only difference between the technologies is that the DCOM technology requires additional LAN setting performed by the LAN administrator.

It is recommended to be familiar with 1-Port VNA Series Operating Manual before reading this Manual.

## 1 REGISTERING COM SERVER

To register COM server of the analyzer run the executable module from command prompt with the */regserver* keyword. To unregister COM server of the analyzer run the executable module from command prompt with the */unregserver* keyword. Administrative rights are required to register/unregister COM server. Also user has ability to register COM server during the software installation procedure.

Example of the COM server registration command:

```
RVNA.exe /regserver
```

## 2 COM TECHNOLOGY OVERVIEW

COM stands for Component Object Model. This programming technology was developed by Microsoft for two purposes:

- the model provides the specification for interaction of binary modules created in different programming languages;
- the model defines the interfacing between a client application and a server application running either on the same PC or on two different PCs. In the latter case, the technology has DCOM abbreviation – Distributed COM.

### 3 AUTOMATION SERVER

The Analyzer executable module contains a built-in COM server that enables other programs to access its functionality. The COM server was developed in conformity with the COM automation specification. COM automation is a technology allowing control over the COM server by the programs written in both traditional compiling programming languages and interpreting programming languages, such as VBScript. This enables the server applications to make their functionality accessible to many more clients.

## 4 AUTOMATION CONTROLLERS

*Automation controllers* are client programs, which use internal functionality of COM servers. Automation controller programs are developed by users for writing their own additions for the system.

User programs can be written in different languages:

- programming languages with built-in COM support, such as Visual Basic®, Delphi, Java;
- universal programming languages, such as C, C++;
- Microsoft Excel and Word office applications as they include built-in programming language Visual Basic for Applications®;
- program generators, such as National Instruments LabView®, or HP–VEE.

Examples represented in this Manual are written in Visual Basic (VB). Appendix 2 contains examples written in VB, and C++ languages.

Examples\COM\VBA folder contains source codes for examples written in Visual Basic for Applications® (Microsoft Excel files).

Examples\COM\CPP folder contains source codes for the C++ language examples.

## 5 LOCAL AND REMOTE SERVER

The analyzer executable module can function either as a *local* server or as a *remote* server of COM automation.

*Local server* runs on the same PC with the automation controller and each of the programs is executed as an individual application in a separate window. COM technology is used in this case (Figure 1).

*Remote server* and the automation controller run on different PCs connected by LAN. DCOM (Distributed COM) technology is used in this case (Figure 2). When using DCOM it is necessary to configure the local network by means of DCOM Windows tools.

The same automation controller is used for the both COM and DCOM technology. Some changes to the user program may be required in operators, which establish connection with the server. Moreover, DCOM technology requires additional settings of the LAN performed by the LAN administrator.




Figure 1. COM technology




Figure 2. DCOM technology

## 6 STRUCTURE OF COM OBJECTS

COM server contains several *objects*, which provide different functionality of the server. The COM objects of the network analyzer executable module are organized in a hierarchical structure. Figure 3 shows the main COM objects, which comprise the first three levels of the hierarchical structure of the COM server. COM objects provide various *methods* and *properties*, which allow access to the server functions; besides, they allow access to the objects of the lower levels, which are not shown in Figure 3.




Figure 3. The structure of COM objects

The Object Application is in the top of the hierarchy. Access to the lower level objects is implemented via higher level objects.

The hierarchy of COM objects is organized in accordance with the standard and syntax of the SCPI programming language. Operators in SCPI have hierarchical chain structure, for example:

**Note**

SCPI:CALCulate:SElected:FORMAT SWR

The same COM command written in VB programming language is as follows:

```
app.SCPI.CALCulate.SElected.FORMAT = "SWR"
```

---

## 7 ACCESSING THE APPLICATION OBJECT

To establish connection with the COM server application, create an object reference in the client program. In COM programming the object reference needs to be acquired preliminarily, to be used later to access the object functionality. To define an object in Visual Basic perform the following:

- 1) Declare a variable as an object.
- 2) Assign the object to this variable.

To declare a variable, use *Dim* operator or other declaration statement (*Public*, *Private* or *Static*). The variables used for references should be of the types *Variant*, *Object*, or a type of a specific object. For example, the following three operators declare *app* variable:

```
Dim app
Dim app as Object
Dim app as R54.Application
Dim app as RVNA.Application
```

Use *Set* operator and *CreateObject (ObjectName, HostName)* function to assign a specific object to a variable.

|                   |   |
|-------------------|---|
| <i>ObjectName</i> | Automation object name is always equal to<br>“R54.Application” or “RVNA.Application”                      |
| <i>HostName</i>   | Network name of the PC hosting the COM server. This parameter is not specified in case of a local server. |

For example, the following operators create *Application* object and assign it to *app* variable:

```
Set app = CreateObject ("RVNA.Application")
Set app = CreateObject ("RVNA.Application", "Network_Name")
Set app = CreateObject ("RVNA.Application", "192.168.10.10")
```

---

**Note** The first form of the operator is used to create the reference to the local COM server, the second one is used to create the reference to the remote DCOM server.

---

To allow access to the objects of a lower level of the hierarchy, these objects are specified after the reference to the higher level object and separated from it by a dot. For example:

```
Dim SystObj  
Set SystObj = app.SCPI.SYSTem
```

COM objects can have indices. For example, *CALCulate*, *INITiate*, *SENSe*, *SOURce* objects represent various aspects of the 4 measurement channels of the Analyzer. Therefore, it is necessary to write the channel index from 1 to 4 to acquire the data of these objects. For example:

```
Set SensObj1 = app.SCPI.SENSe(1)  
Set SensObj2 = app.SCPI.SENSe(2)
```

Visual Basic allows omitting of such indices; in this case the indices are considered as equal to 1. For example, the following VB operators are equivalent:

```
Set SensObj = app.SCPI.SENSe(1)  
Set SensObj = app.SCPI.SENSe
```

## 8 OBJECT METHODS

Objects have methods. Methods are actions that can be applied to objects. The object methods are specified after the object name and separated from it by a dot.

The following example shows the *PRESet* method of *SYSTem* object. This method performs setting of the Analyzer to the preset condition:

```
app.SCPI.SYSTem.PRESet
```

## 9 OBJECT PROPERTIES

Along with methods, objects have properties. Properties are object characteristics that can be set or read out. The object properties are specified after the object name and separated from it by a dot.

To modify an object characteristic, write the value of the corresponding property. To define an object characteristic, read out the value of its property. The following example show the setting of the *POINts* property of *SWEep* object, i.e. the number of sweep points:

```
app.SCPI.SENSE.SWEp.POINTs = 201
```

---

**Note** Some object properties cannot be written, and some object properties cannot be read. In such cases, the properties are indicated as “read only” or “write only”.

---

## 10 ERROR HANDLING

You can use different approaches to error handling in VB program:

- check the value of *Err.Number* variable after execution of VB operator, which contains the call to COM server object;
- use *On Error GoTo* VB operator.

These approaches are represented in the examples below. The following operator causes an error in VB program as "S13" value of the *DEFine* property is incorrect.

```
app.SCPI.PARameter.DEFINE = "S13"
```

In the first example, the value of the *Err.Number* variable is checked after execution of the VB operator, which contains the call to COM server object. *On Error Resume Next* directive instructs VB not to interrupt the program execution when the error is detected but to pass control to the next operator in natural order.

```
Dim app
Public Sub HandleError1()
    Set app = CreateObject("RVNA.Application")
    On Error Resume Next
    app.SCPI.PARameter.DEFINE = "S13"
    If Err.Number <> 0 Then
        Msg = "Error # " & Str(Err.Number) & " was generated by " &_
            Err.Source & Chr(13) & Err.Description
        MsgBox Msg,, "Error"
    End If
    ...
End Sub
```

In the second example, *On Error GoTo ErrHandler* directive instructs VB to interrupt the program execution when the error is detected and to pass control to *ErrHandler* label.

```
Dim app
Public Sub HandleError2()
Set app = CreateObject("RVNA.Application")
On Error GoTo ErrHandler
app.SCPI.PARameter.DEFine = "S13"
...
Exit Sub
ErrorHandler:
Msg = "Error # " & Str(Err.Number) & " was generated by " &_
Err.Source & Chr(13) & Err.Description
MsgBox Msg,, "Error"
End Sub
```

## 11 COM AUTOMATION DATA TYPES

In COM automation, there are the following data types, which can be used for client-to-server communication:

**Long** 32-bit signed integer, value range from -2147483648 to 2147483647

**Double** 64-bit double-precision floating point, value range from -1.79769313486232E308 to -4.94065645841247E-324 for negative values, and from 4.94065645841247E-324 to 1.79769313486232E308 for positive values

**Boolean** 16-bit integer, two values 0 – *False*, 1 – *True*

**String** Variable-length string

**Variant** Can be either a value of arbitrary type or an array of values of arbitrary type. In this case, the term “arbitrary type” means any allowed type of COM automation. A variable contains information about its type and array size (if it is an array). It is used for communication of data arrays between a client and a server.

## 12 MEASUREMENT DATA ARRAYS

Measurement data can be either complex values or real values. This depends on the format selected by the user. For example, the data is real in logarithmic magnitude format and the data is complex in polar format.

The measurement data is transferred in a *Variant* type variable, which represents an array of *Double* type. To transfer one complex measurement, two adjacent array cells are used. To transfer one real measurement two adjacent array cells are used as well but the second cell is always equal to 0. Thus, measurement data array size is a double number of the measurement points.

| Measurement 1 | Measurement 2 | ...  | Measurement N |
|---------------|---------------|------|---------------|
| Real          | Imag          | Real | Imag          |

Figure 4. Array of complex measurements

| Measurement 1 | Measurement 2 | ...   | Measurement N |
|---------------|---------------|-------|---------------|
| Value         | 0             | Value | 0             |

Figure 5. Array of real measurements

## 13 COM SERVER COMMANDS

### NAME

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | String   |
| <i>Description</i>         | Instrument information string. String format: manufacturer, model, serial number, number of firmware version and number of software version. |
| <i>Range</i>               | up to 40 characters  |
| <i>Syntax</i>              | Dim <i>ID</i> As String<br><i>ID</i> = <i>app.NAME</i>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

### Ready

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Boolean   |
| <i>Description</i>         | Ready state of the instrument. Reads out the <i>True</i> value after successful completion of the boot process (about 10 sec). The analyzer must be connected to PC by a USB cable. |
| <i>Syntax</i>              | Dim <i>State</i> as Boolean<br><i>State</i> = <i>app.Ready</i>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.ABORT**

| <i>Object Type</i>         | Method  |
|----------------------------|---|
| <i>Description</i>         | Aborts the sweep. Switches trigger mode from <i>Single</i> to <i>Hold</i> , or from <i>Continuous</i> to waiting for a trigger. If the trigger source is set to <i>Internal</i> , starts a new sweep. |
| <i>Syntax</i>              | app.SCPI.ABORT  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.CALCulate(*Ch*).FSIMulator.SENDed.DEEMbed.PORT(*Pt*).USER.FILenam**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | De-embedding function file name (*.s2p). The file contains the circuit S-parameters in Touchstone format.  |
| <i>Range</i>               | up to 256 characters   |
| <i>Preset Value</i>        | ""   |
| <i>Syntax</i>              | <pre>Dim File As String File = app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEMbed. PORT(Pt).USER.FILenam app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEMbed. PORT(Pt).USER.FILenam = "network.s2p"</pre> |
| <i>Notes</i>               | If the full path to the file is not specified, the \FixtureSim subdirectory of the main directory will be searched for the file.   |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; S-parameters File (De-Embedding)</b>   |

Table 1. *Ch*: Channel Number

|                     |  |
|---------------------|--|
| <i>Data Type</i>    | Long   |
| <i>Description</i>  | Channel number.  |
| <i>Range</i>        | From 1 to 4<br>From 1 to 16 (in N-port mode only)                  |
| <i>Out of Range</i> | An error occurs. Error code: 201.                                  |
| <i>Notes</i>        | If the channel number is not specified, it is taken as equal to 1. |

Table 2. *Pt*: Port Number

|                     |   |
|---------------------|---|
| <i>Data Type</i>    | Long  |
| <i>Description</i>  | Port number.  |
| <i>Range</i>        | Only 1<br>From 1 to 16 (in N-port mode only)                    |
| <i>Out of Range</i> | An error occurs. Error code: 114.                               |
| <i>Notes</i>        | If the port number is not specified, it is taken as equal to 1. |

SCPI.CALCulate(*Ch*).FSIMulator.SENDed.DEEMbed.PORT(*Pt*).STATe

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | The ON/OFF state of the e-embedding function.  |
| <i>Allowable Values</i>    | <i>True</i> De-embedding function ON<br><i>False</i> De-embedding function OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEMbed.<br>PORT(Pt).STATE<br>app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEMbed.<br>PORT(Pt).STATE = True |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; De-Embedding</b>   |

**SCPI.CALCulate(*Ch*).FSIMulator.SENDed.PMCircuit.PORT(*Pt*).USER.FILename**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | Embedding function file name (*.s2p). The file contains the circuit S-parameters in Touchstone format.   |
| <i>Range</i>               | up to 256 characters   |
| <i>Preset Value</i>        | ""   |
| <i>Syntax</i>              | <pre>Dim File As String File = app.SCPI.CALCulate(Ch).FSIMulator.SENDed.PMCircuit.PORT(Pt).USER.FILename app.SCPI.CALCulate(Ch).FSIMulator.SENDed.PMCircuit.PORT(Pt).USER.FILename = "network.s2p"</pre> |
| <i>Notes</i>               | If the full path to the file is not specified, the \FixtureSim subdirectory of the main directory will be searched for the file.   |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; S-parameters File (Embedding)</b>  |

SCPI.CALCulate(*Ch*).FSIMulator.SENDed.PMCircuit.PORT(*Pt*).STATe

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | The ON/OFF state of the embedding function.  |
| <i>Allowable Values</i>    | True      Embedding function ON<br>False      Embedding function OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEbed.<br>PORT(Pt).STATE<br>app.SCPI.CALCulate(Ch).FSIMulator.SENDed.DEEbed.<br>PORT(Pt).STATE = True |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; Embedding</b>  |

SCPI.CALCulate(*Ch*).FSIMulator.SENDed.ZCONversion.PORT(*Pt*).Z0.R

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)  |
| <i>Description</i>         | The value of the impedance for port impedance conversion function.  |
| <i>Range</i>               | from 1e-6 to 1e6  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 50  |
| <i>Unit</i>                | $\Omega$ (Ohm)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).FSIMulator.SENDed. ZCONversion.PORT(Pt).Z0.R app.SCPI.CALCulate(Ch).FSIMulator.SENDed. ZCONversion.PORT(Pt).Z0.R = 75</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; Port Z0</b>   |

**SCPI.CALCulate(*Ch*).FSIMulator.SENDed.ZCONversion.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the port impedance conversion function.  |
| <i>Allowable Values</i>    | <i>True</i> Port Z conversion function ON<br><i>False</i> Port Z conversion function OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).FSIMulator.SENDed. ZCONversion.STATE app.SCPI.CALCulate(Ch).FSIMulator.SENDed. ZCONversion.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Fixture Simulator &gt; Port Z Conversion</b>  |

SCPI.CALCulate(*Ch*).PARameter.COUNT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of traces in the channel.   |
| <i>Range</i>               | from 1 to 4<br>from 1 to 16 (in N-port mode only)  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | <pre>Dim TraceNum As Long TraceNum = app.SCPI.CALCulate(Ch).PARameter.COUNT app.SCPI.CALCulate(Ch).PARameter.COUNT = 2</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

Table 3. *Tr*: Trace Number

|                     |  |
|---------------------|--|
| <i>Data Type</i>    | Long   |
| <i>Description</i>  | Trace number   |
| <i>Range</i>        | From 1 to 4<br>From 1 to 16 (in N-port mode only)                |
| <i>Out of Range</i> | An error occurs. Error code: 202.                                |
| <i>Notes</i>        | If the trace number is not specified, it is taken as equal to 1. |

SCPI.CALCulate(*Ch*).PARameter(*Tr*).DEFine

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)              |
| <i>Description</i>         | The measurement parameter of the trace.   |
| <i>Allowable Values</i>    | "S11"<br>"S11", "S21", ..."S16.1", ..."S1.16", ... "S16.16" (in N-port mode only)   |
| <i>Out of Range</i>        | An error occurs.  |
| <i>Preset Value</i>        | "S11"   |
| <i>Syntax</i>              | Dim Meas As String<br>Meas =<br>app.SCPI.CALCulate(Ch).PARameter(Tr).DEFine<br>app.SCPI.CALCulate(Ch).PARameter(Tr).DEFine =<br>"S11" |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Measurement</b> (in N-port mode only)   |

SCPI.CALCulate(*Ch*).PARameter(*Tr*).SElect

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)   |
| <i>Description</i>         | Sets the active channel and trace.   |
| <i>Syntax</i>              | app . SCPI . CALCulate (Ch) . PARameter (Tr) . SElect  |
| <i>Notes</i>               | If the channel number is greater than the number of the channels displayed, an error occurs and the command is ignored. If the trace number is greater than the number of the traces displayed in the channel, an error occurs and the command is ignored. |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Active Channel</b>  |

SCPI.CALCulate(*Ch*).SElected.CONVersion.FUNCtion

|                            |  |             |  |              |   |             |                     |               |                       |
|----------------------------|--|-------------|--|--------------|---|-------------|---------------------|---------------|-----------------------|
| <i>Object Type</i>         | Property (read/write)  |             |  |              |   |             |                     |               |                       |
| <i>Data Type</i>           | String   |             |  |              |   |             |                     |               |                       |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |             |  |              |   |             |                     |               |                       |
| <i>Description</i>         | The S-parameter conversion function type.  |             |  |              |   |             |                     |               |                       |
| <i>Range</i>               | <table> <tr> <td>"IMPedance"</td> <td>Reflection equivalent impedance of measurement parameter S11</td> </tr> <tr> <td>"ADMittance"</td> <td>Reflection equivalent admittance of measurement parameter S11</td> </tr> <tr> <td>"INVersion"</td> <td>Inverse S-parameter</td> </tr> <tr> <td>"CONJugation"</td> <td>S-parameter conjugate</td> </tr> </table> | "IMPedance" | Reflection equivalent impedance of measurement parameter S11 | "ADMittance" | Reflection equivalent admittance of measurement parameter S11 | "INVersion" | Inverse S-parameter | "CONJugation" | S-parameter conjugate |
| "IMPedance"                | Reflection equivalent impedance of measurement parameter S11   |             |  |              |   |             |                     |               |                       |
| "ADMittance"               | Reflection equivalent admittance of measurement parameter S11  |             |  |              |   |             |                     |               |                       |
| "INVersion"                | Inverse S-parameter  |             |  |              |   |             |                     |               |                       |
| "CONJugation"              | S-parameter conjugate  |             |  |              |   |             |                     |               |                       |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters.   |             |  |              |   |             |                     |               |                       |
| <i>Out of Range</i>        | An error occurs. Error code: 217.  |             |  |              |   |             |                     |               |                       |
| <i>Preset Value</i>        | "IMP"  |             |  |              |   |             |                     |               |                       |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.CONVersion.FUNCtion app.SCPI.CALCulate(Ch).SElected.CONVersion.FUNCtion = "INV"</pre>   |             |  |              |   |             |                     |               |                       |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Conversion &gt; Function &gt; Impedance Z   AdmittanceY   Inverse 1/S   Conjugation</b>   |             |  |              |   |             |                     |               |                       |

SCPI.CALCulate(*Ch*).SElected.CONVersion.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the S-parameter conversion function.   |
| <i>Allowable Values</i>    | <i>True</i> S-parameter conversion function ON<br><i>False</i> S-parameter conversion function OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.CONVersion.STATE app.SCPI.CALCulate(Ch).SElected.CONVersion.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Conversion &gt; Conversion</b>  |

SCPI.CALCulate(*Ch*).SElected.CORRection.EDELay.TIME

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The value of the electrical delay.  |
| <i>Range</i>               | from -10 to 10  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.CORRection.EDELay     .TIME app.SCPI.CALCulate(Ch).SElected.CORRection.EDELay     .TIME = 1e-9</pre> |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Electrical Delay</b>  |

SCPI.CALCulate(*Ch*).SElected.CORRection.OFFSet.PHASE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The value of the phase offset.   |
| <i>Range</i>               | from -360 to 360   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | ° (degree)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.CORRection.OFFSet     .PHASE app.SCPI.CALCulate(Ch).SElected.CORRection.OFFSet     .PHASE = 360</pre> |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Phase Offset</b>   |

SCPI.CALCulate(*Ch*).SElected.DATA.FDATA

|                            |  |                |  |                |   |
|----------------------------|--|----------------|--|----------------|---|
| <i>Object Type</i>         | Property (read only)   |                |  |                |   |
| <i>Data Type</i>           | Variant (Double array)   |                |  |                |   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |                |  |                |   |
| <i>Description</i>         | <p>The formatted data array. The array elements contain measurements in the current format, for example, in logarithmic magnitude format (Log Mag). Also, see section 12.</p> <p>The array size is <math>2N</math>, where <math>N</math> is the number of measurement points.</p> <p>For the <math>n</math>-th point, where <math>n</math> from 1 to <math>N</math>:</p> <table> <tr> <td>Data(<math>2n-2</math>)</td> <td>real number in rectangular format, real part in polar and Smith chart formats;</td> </tr> <tr> <td>Data(<math>2n-1</math>)</td> <td>0 in rectangular format, imaginary part in polar and Smith chart formats.</td> </tr> </table> | Data( $2n-2$ ) | real number in rectangular format, real part in polar and Smith chart formats; | Data( $2n-1$ ) | 0 in rectangular format, imaginary part in polar and Smith chart formats. |
| Data( $2n-2$ )             | real number in rectangular format, real part in polar and Smith chart formats;   |                |  |                |   |
| Data( $2n-1$ )             | 0 in rectangular format, imaginary part in polar and Smith chart formats.  |                |  |                |   |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch) . SElected.DATA.FDATA</pre>   |                |  |                |   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |                |  |                |   |

SCPI.CALCulate(*Ch*).SElected.DATA.FMEMory

|                            |  |                |  |                |   |
|----------------------------|--|----------------|--|----------------|---|
| <i>Object Type</i>         | Property (read only)   |                |  |                |   |
| <i>Data Type</i>           | Variant (Double array)   |                |  |                |   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |                |  |                |   |
| <i>Description</i>         | <p>The formatted memory array. The array elements contain saved measurements in the current format, for example, in logarithmic magnitude format (Log Mag). Also, see section 12.</p> <p>The array size is <math>2N</math>, where <math>N</math> is the number of measurement points.</p> <p>For the <math>n</math>-th point, where <math>n</math> from 1 to <math>N</math>:</p> <table> <tr> <td>Data(<math>2n-2</math>)</td> <td>real number in rectangular format, real part in polar and Smith chart formats;</td> </tr> <tr> <td>Data(<math>2n-1</math>)</td> <td>0 in rectangular format, imaginary part in polar and Smith chart formats.</td> </tr> </table> | Data( $2n-2$ ) | real number in rectangular format, real part in polar and Smith chart formats; | Data( $2n-1$ ) | 0 in rectangular format, imaginary part in polar and Smith chart formats. |
| Data( $2n-2$ )             | real number in rectangular format, real part in polar and Smith chart formats;   |                |  |                |   |
| Data( $2n-1$ )             | 0 in rectangular format, imaginary part in polar and Smith chart formats.  |                |  |                |   |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch) . SElected.DATA.FMEMory</pre>   |                |  |                |   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |                |  |                |   |

SCPI.CALCulate(*Ch*).SElected.DATA.SDATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | <p>The corrected data array. The corrected measurements are complex numbers. Also, see section 12.</p> <p>The array size is <math>2N</math>, where <math>N</math> is the number of measurement points.</p> <p>For the <math>n</math>-th point, where <math>n</math> from 1 to <math>N</math>:</p> <p><math>\text{Data}(2n-2)</math> the real part of corrected measurement;</p> <p><math>\text{Data}(2n-1)</math> the imaginary part of corrected measurement.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch) . SElected.DATA.SDATA</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.DATA.SMEMory

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | <p>The corrected memory array. The corrected measurements are complex numbers. Also, see section 12.</p> <p>The array size is <math>2N</math>, where <math>N</math> is the number of measurement points.</p> <p>For the <math>n</math>-th point, where <math>n</math> from 1 to <math>N</math>:</p> <p style="padding-left: 40px;">Data(<math>2n-2</math>) the real part of corrected measurement memory;</p> <p style="padding-left: 40px;">Data(<math>2n-1</math>) the imaginary part of corrected measurement memory.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch).SElected.DATA.SMEMory</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.FILTter.GATE.TIME.CENTer

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The gate center value of the gating function.   |
| <i>Range</i>               | Varies depending on the frequency span and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second), m (metre), ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.FILTter.GATE.TIME. CENTer app.SCPI.CALCulate(Ch).SESelected.FILTter.GATE.TIME. CENTer = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.CALCulate(*Ch*).SELected.FILTter.GATE.TIME.SHAPe**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The gate shape of the gating function.   |
| <i>Range</i>               | "MAXimum" Maximum shape<br>"WIDE" Wide shape<br>"NORMAL" Normal shape<br>"MINimum" Minimum shape   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs. Error code: 218.  |
| <i>Preset Value</i>        | "NORM"   |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.CALCulate(Ch).SELected.FILTter.GATE.TIME.SHAPe<br>app.SCPI.CALCulate(Ch).SELected.FILTter.GATE.TIME.SHAPe = "MAX"   |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Gating &gt; Shape &gt; Maximum   Wide   Normal   Minimum</b>  |

SCPI.CALCulate(*Ch*).SElected.FILTer.GATE.TIME.SPAN

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The gate span value of the gating function.   |
| <i>Range</i>               | Varies depending on the frequency span and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 2e-8  |
| <i>Unit</i>                | s (second), m (metre), ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.FILTer.GATE.TIME. SPAN app.SCPI.CALCulate(Ch).SElected.FILTer.GATE.TIME. SPAN = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.FILTter.GATE.TIME.START

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The gate start value of the gating function.  |
| <i>Range</i>               | Varies depending on the frequency span and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | -1e-8   |
| <i>Unit</i>                | s (second), m (metre), ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.FILTter.GATE.TIME. START app.SCPI.CALCulate(Ch).SElected.FILTter.GATE.TIME. START = 1e-7</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Gating &gt; Start</b>  |

SCPI.CALCulate(*Ch*).SELected.FILTer.GATE.TIME.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the gating function.   |
| <i>Allowable Values</i>    | <i>True</i> Gating function ON<br><i>False</i> Gating function OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SELected.FILTer.GATE.TIME. STATE app.SCPI.CALCulate(Ch).SELected.FILTer.GATE.TIME. STATE = Status</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Gating &gt; Gating</b>  |

SCPI.CALCulate(*Ch*).SElected.FILTer.GATE.TIME.STOP

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The gate stop value of the gating function.   |
| <i>Range</i>               | Varies depending on the frequency span and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 1e-8  |
| <i>Unit</i>                | s (second), m (metre), ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.FILTer.GATE.TIME. STOP app.SCPI.CALCulate(Ch).SElected.FILTer.GATE.TIME. STOP = 1e-7</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Gating &gt; Stop</b>   |

SCPI.CALCulate(*Ch*).SELected.FILTter.GATE.TIME.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The gate type of the gating function.  |
| <i>Range</i>               | "BPASS" Bandpass type<br>"NOTCh" Notch type  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs. Error code: 219.  |
| <i>Preset Value</i>        | "BPAS"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch) .SELected.FILTter.GATE.TIME. TYPE app.SCPI.CALCulate(Ch) .SELected.FILTter.GATE.TIME. TYPE = "NOTC"</pre>  |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Gating &gt; Type</b>  |

SCPI.CALCulate(*Ch*).SElected.FORMAT

|                     |   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
|---------------------|---|----------------|-----------------------|---------|-------|----------|----------------|----------|------------------|-------|-----------------------------|--------|-----------|-------------|----------------|-----------|------------------|-----------|--------------------------|----------------|--------------------------|------------|--------------------------------|---------|---------------------------------|---------------|---------------------------------|-----------|--------------------|----------------|--------------------|---------|--------------------------|---------|------------|---------|---|--------|---|----------|---|
| <i>Object Type</i>  | Property (read/write)   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Data Type</i>    | String  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Target</i>       | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Description</i>  | Data format.  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Range</i>        | <table> <tr><td>"MLOGarithmic"</td><td>Logarithmic magnitude</td></tr> <tr><td>"PHASE"</td><td>Phase</td></tr> <tr><td>"UPHase"</td><td>Expanded phase</td></tr> <tr><td>"GDELay"</td><td>Group delay time</td></tr> <tr><td>"SWR"</td><td>Voltage standing wave ratio</td></tr> <tr><td>"REAL"</td><td>Real part</td></tr> <tr><td>"IMAGinary"</td><td>Imaginary part</td></tr> <tr><td>"MLINear"</td><td>Linear magnitude</td></tr> <tr><td>"SLINear"</td><td>Smith chart format (Lin)</td></tr> <tr><td>"SLOGarithmic"</td><td>Smith chart format (Log)</td></tr> <tr><td>"SCOMplex"</td><td>Smith chart format (Real/Imag)</td></tr> <tr><td>"SMITH"</td><td>Smith chart format (<math>R + jX</math>)</td></tr> <tr><td>"SADMittance"</td><td>Smith chart format (<math>G + jB</math>)</td></tr> <tr><td>"PLINear"</td><td>Polar format (Lin)</td></tr> <tr><td>"PLOGarithmic"</td><td>Polar format (Log)</td></tr> <tr><td>"POLar"</td><td>Polar format (Real/Imag)</td></tr> <tr><td>"CLOSS"</td><td>Cable Loss</td></tr> <tr><td>"RLOSS"</td><td>Retun Loss (obsolete, write only) use MLOG<sup>1</sup></td></tr> <tr><td>"DSWR"</td><td>DFT in SWR chart format (obsolete, write only) use SWR+Time Domain<sup>1</sup></td></tr> <tr><td>"DRLOSS"</td><td>DFT Logarithmic magnitude (obsolete, write only) useMLOG+Time Domain<sup>1</sup></td></tr> </table> | "MLOGarithmic" | Logarithmic magnitude | "PHASE" | Phase | "UPHase" | Expanded phase | "GDELay" | Group delay time | "SWR" | Voltage standing wave ratio | "REAL" | Real part | "IMAGinary" | Imaginary part | "MLINear" | Linear magnitude | "SLINear" | Smith chart format (Lin) | "SLOGarithmic" | Smith chart format (Log) | "SCOMplex" | Smith chart format (Real/Imag) | "SMITH" | Smith chart format ( $R + jX$ ) | "SADMittance" | Smith chart format ( $G + jB$ ) | "PLINear" | Polar format (Lin) | "PLOGarithmic" | Polar format (Log) | "POLar" | Polar format (Real/Imag) | "CLOSS" | Cable Loss | "RLOSS" | Retun Loss (obsolete, write only) use MLOG <sup>1</sup> | "DSWR" | DFT in SWR chart format (obsolete, write only) use SWR+Time Domain <sup>1</sup> | "DRLOSS" | DFT Logarithmic magnitude (obsolete, write only) useMLOG+Time Domain <sup>1</sup> |
| "MLOGarithmic"      | Logarithmic magnitude   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "PHASE"             | Phase   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "UPHase"            | Expanded phase  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "GDELay"            | Group delay time  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SWR"               | Voltage standing wave ratio   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "REAL"              | Real part   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "IMAGinary"         | Imaginary part  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "MLINear"           | Linear magnitude  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SLINear"           | Smith chart format (Lin)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SLOGarithmic"      | Smith chart format (Log)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SCOMplex"          | Smith chart format (Real/Imag)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SMITH"             | Smith chart format ( $R + jX$ )   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "SADMittance"       | Smith chart format ( $G + jB$ )   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "PLINear"           | Polar format (Lin)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "PLOGarithmic"      | Polar format (Log)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "POLar"             | Polar format (Real/Imag)  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "CLOSS"             | Cable Loss  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "RLOSS"             | Retun Loss (obsolete, write only) use MLOG <sup>1</sup>   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "DSWR"              | DFT in SWR chart format (obsolete, write only) use SWR+Time Domain <sup>1</sup>   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| "DRLOSS"            | DFT Logarithmic magnitude (obsolete, write only) useMLOG+Time Domain <sup>1</sup>   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Notes</i>        | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters.  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Out of Range</i> | An error occurs.  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Preset Value</i> | "MLOG"  |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |
| <i>Syntax</i>       | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.FORMAT app.SCPI.CALCulate(Ch).SElected.FORMAT = "PHAS"</pre>   |                |                       |         |       |          |                |          |                  |       |                             |        |           |             |                |           |                  |           |                          |                |                          |            |                                |         |                                 |               |                                 |           |                    |                |                    |         |                          |         |            |         |   |        |   |          |   |

<sup>1</sup> To switch on Time Domain mode – Analysis > Time Domain > Time Domain

|                            |   |
|----------------------------|---|
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Format &gt; Log Magnitude   Phase   Expand Phase   Group Delay   SWR   Real   Imag   Lin Magnitude   Smith (Lin)   Smith (Log)   Smith (Re/Im)   Smith (R+jX)   Smith (G+jB)   Polar (Lin)   Polar (Log)   Polar (Re/Im) Cable Loss</b> |
|----------------------------|---|

SCPI.CALCulate(*Ch*).SELected.FUNCTion.DATA

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Variant (Double array)  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | <p>The data array of analysis executed by the SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.EXECute method.</p> <p>The array size is <math>2N</math>, where <math>N</math> is the number of points defined by the SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.POINTs property.</p> <p>For the <math>n</math>-th point, where <math>n</math> from 1 to <math>N</math>:</p> <p style="margin-left: 40px;">Data(<math>2n-2</math>) the response value in the <math>n</math>-th measurement point;</p> <p style="margin-left: 40px;">Data(<math>2n-1</math>) the stimulus value in the <math>n</math>-th measurement point.<br/>Always set to 0 for the analysis of mean value, standard deviation, and peak-to-peak value.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.DATA</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SELected.FUNCtion.DOMain.COUPLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | All traces of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF coupling state of the analysis range for the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCtion.EXECute method.  |
| <i>Allowable Values</i>    | <i>True</i> Coupling state ON<br><i>False</i> Coupling state OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain. COUPLE app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain. COUPLE = Status</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SELected.FUNCtion.DOMain.START

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the coupling is set to OFF by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCtion.DOMain.COUPLE property), the active trace of channel <i>Ch</i> (if otherwise),<br><i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | The start value of the analysis range set by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCtion.EXECute method.   |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | Hz (Hertz)   s (second)   dBm (decibels above 1 milliwatt)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain. START app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain. START = 1e9</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SELected.FUNCTion.DOMain.STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the coupling is set to OFF by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.DOMain.COUPLe property), the active trace of channel <i>Ch</i> (if otherwise), <i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | The ON/OFF state of the arbitrary range when executing the analysis by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.EXECute method.  |
| <i>Allowable Values</i>    | <i>True</i> Arbitrary range ON<br><i>False</i> Arbitrary range OFF (entire sweep range)   |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.DOMain. STATE app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.DOMain. STATE = True</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SELected.FUNCtion.DOMain.STOP

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the coupling is set to OFF by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCtion.DOMain.COUPLE property), the active trace of channel <i>Ch</i> (if otherwise), <i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | The stop value of the analysis range set by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCtion.EXECute method.   |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.   |
| <i>Out of Range</i>        | No limitation   |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | Hz (Hertz)   s (second)   dBm (decibels above 1 milliwatt)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain.STOP app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCtion.DOMain.STOP = 2e9</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.CALCulate(*Ch*).SELected.FUNCTion.EXECute

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Executes the analysis specified with the<br>SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.TYPE property.<br>The analysis result can then be read out with the<br>SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.DATA property. |
| <i>Syntax</i>              | app.SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.EXECute   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.FUNCTION.PEXCursion

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The lower limit for the peak excursion value when executing the peak search by the<br>SCPI.CALCulate(Ch).SElected.FUNCTION.EXECute method.           |
| <i>Range</i>               | Varies depending on the trace format.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 3  |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.FUNCTION.PEXCursion app.SCPI.CALCulate(Ch).SElected.FUNCTION.PEXCursion = 1.5</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.FUNCTION.POINts

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The number of points (data pairs) of the analysis result by the SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCTION.EXECute method.<br>Always equal to 1, when the search is executed for the maximum, minimum, mean, standard deviation, peak, and peak-to-peak values. The actual number of points is read out, when the search is executed for all peaks or all targets. |
| <i>Syntax</i>              | Dim Value As Long<br>Value =<br>app.SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCTION.POINts  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SELected.FUNCTion.PPOLarity

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The polarity selection when performing the peak search by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.EXECute method.  |
| <i>Range</i>               | "POSitive" Positive peaks<br>"NEGative" Negative peaks<br>"BOTH" Both positive peaks and negative peaks  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "POS"  |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.PPOLarity<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.PPOLarity<br>= "NEG"  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SELected.FUNCTion.TARGet

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The target level when performing the search for the trace and the target level crosspoints by the SCPI.CALCulate( <i>Ch</i> ).SELected.FUNCTion.EXECute method. |
| <i>Range</i>               | Varies depending on the trace format.   |
| <i>Out of Range</i>        | No limitation   |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.TARGet app.SCPI.CALCulate(<i>Ch</i>).SELected.FUNCTion.TARGet = -10</pre>      |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.FUNCTION.TTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The transition type selection when performing the search for the trace and the target level crosspoints by the SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCTION.EXECute method.   |
| <i>Range</i>               | "POSitive" Positive peaks<br>"NEGative" Negative peaks<br>"BOTH" Both positive peaks and negative peaks  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "POS"  |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.FUNCTION. TTRansition app.SCPI.CALCulate(Ch).SElected.FUNCTION. TTRansition = "BOTH"</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.FUNCTion.TYPE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The selection of the type of analysis executed by the SCPI.CALCulate( <i>Ch</i> ).SElected.FUNCTion.EXECute method.   |
| <i>Range</i>               | "PTPeak" Peak-to-peak (difference between the maximum value and the minimum value)<br>"STDEV" Standard deviation<br>"MEAN" Mean value<br>"MAXimum" Maximum value<br>"MINimum" Minimum value<br>"PEAK" Search for the peak<br>"APEak" Search for all the peaks<br>"ATARget" Search for all targets |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters.  |
| <i>Out of Range</i>        | The value is ignored.   |
| <i>Preset Value</i>        | "PTP"   |
| <i>Syntax</i>              | <pre> Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.FUNCTion.TYPE app.SCPI.CALCulate(Ch).SElected.FUNCTion.TYPE = "STDEV" </pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.LIMit.DATA

|                            |   |         |  |            |  |            |  |            |  |            |  |            |  |
|----------------------------|---|---------|--|------------|--|------------|--|------------|--|------------|--|------------|--|
| <i>Object Type</i>         | Property (read/write)   |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Data Type</i>           | Variant (Double array)  |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Description</i>         | <p>The data array, which is the limit line in the limit test function. The array size is <math>1 + 5N</math>, where N is the number of measuring points.</p> <p>For the n-th point, where n from 1 to N:</p> <table> <tr> <td>Data(0)</td> <td>The number of limit line segments N is from 0 to 100. Setting 0 clears the limit line;</td> </tr> <tr> <td>Data(5n-4)</td> <td>type of the n-th limit line segment;<br/>0: OFF<br/>1: Upper limit<br/>2: Lower limit</td> </tr> <tr> <td>Data(5n-3)</td> <td>the stimulus value in the start point of the n-th segment;</td> </tr> <tr> <td>Data(5n-2)</td> <td>the stimulus value in the end point of the n-th segment;</td> </tr> <tr> <td>Data(5n-1)</td> <td>the response value in the start point of the n-th segment;</td> </tr> <tr> <td>Data(5n-0)</td> <td>the response value in the end point of the n-th segment.</td> </tr> </table> | Data(0) | The number of limit line segments N is from 0 to 100. Setting 0 clears the limit line; | Data(5n-4) | type of the n-th limit line segment;<br>0: OFF<br>1: Upper limit<br>2: Lower limit | Data(5n-3) | the stimulus value in the start point of the n-th segment; | Data(5n-2) | the stimulus value in the end point of the n-th segment; | Data(5n-1) | the response value in the start point of the n-th segment; | Data(5n-0) | the response value in the end point of the n-th segment. |
| Data(0)                    | The number of limit line segments N is from 0 to 100. Setting 0 clears the limit line;  |         |  |            |  |            |  |            |  |            |  |            |  |
| Data(5n-4)                 | type of the n-th limit line segment;<br>0: OFF<br>1: Upper limit<br>2: Lower limit  |         |  |            |  |            |  |            |  |            |  |            |  |
| Data(5n-3)                 | the stimulus value in the start point of the n-th segment;  |         |  |            |  |            |  |            |  |            |  |            |  |
| Data(5n-2)                 | the stimulus value in the end point of the n-th segment;  |         |  |            |  |            |  |            |  |            |  |            |  |
| Data(5n-1)                 | the response value in the start point of the n-th segment;  |         |  |            |  |            |  |            |  |            |  |            |  |
| Data(5n-0)                 | the response value in the end point of the n-th segment.  |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Notes</i>               | If the array size is not $1 + 5N$ , where N is Data(0), an error occurs (error code 214). If Data(5n - 4) is less than 0 or more than 2, an error occurs (error code 214). When Data(5n-3), Data(5n-2), Data(5n-1) and Data(5n-0) elements are out of allowable range, the value is set to the limit, which is closer to the specified value.   |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch).SElected.LIMit.DATA app.SCPI.CALCulate(Ch).SElected.LIMit.DATA = Array(1,2,800,900,-10,-10)</pre>  |         |  |            |  |            |  |            |  |            |  |            |  |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Edit Limit Line</b>  |         |  |            |  |            |  |            |  |            |  |            |  |

**SCPI.CALCulate(*Ch*).SELected.LIMit.DISPlay.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The ON/OFF state of the limit line display of the limit test function.  |
| <i>Allowable Values</i>    | <i>True</i> Limit line display ON<br><i>False</i> Limit line display OFF  |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).SELected.LIMit.DISPlay.STATE<br>app.SCPI.CALCulate(Ch).SELected.LIMit.DISPlay.STATE<br>= True |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Limit Line</b>   |

SCPI.CALCulate(*Ch*).SElected.LIMit.FAIL

|                            |   |             |      |              |      |
|----------------------------|---|-------------|------|--------------|------|
| <i>Object Type</i>         | Property (read only)  |             |      |              |      |
| <i>Data Type</i>           | Boolean   |             |      |              |      |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                             |             |      |              |      |
| <i>Description</i>         | The limit test result.  |             |      |              |      |
| <i>Allowable Values</i>    | <table> <tr> <td><i>True</i></td> <td>Fail</td> </tr> <tr> <td><i>False</i></td> <td>Pass</td> </tr> </table> | <i>True</i> | Fail | <i>False</i> | Pass |
| <i>True</i>                | Fail  |             |      |              |      |
| <i>False</i>               | Pass  |             |      |              |      |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.LIMit.FAIL</pre>                          |             |      |              |      |
| <i>Equivalent Softkeys</i> | <b>None</b>   |             |      |              |      |

SCPI.CALCulate(*Ch*).SElected.LIMit.OFFSetAMPLitude

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The value of the limit line offset along Y-axis.   |
| <i>Range</i>               | Varies depending on the trace format.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.LIMit.OFFSet. AMPLitude app.SCPI.CALCulate(Ch).SElected.LIMit.OFFSet. AMPLitude = -10</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Response Offset</b>   |

SCPI.CALCulate(*Ch*).SElected.LIMit.OFFSet.STIMulus

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The value of the limit line offset along X-axis.   |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | Hz (Hertz)   s (second)   dBm (decibels above 1 milliwatt)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.LIMit.OFFSet. STIMulus app.SCPI.CALCulate(Ch).SElected.LIMit.OFFSet. STIMulus = 1e6</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Stimulus Offset</b>   |

SCPI.CALCulate(*Ch*).SElected.LIMit.REPort.ALL

|                            |  |            |                                      |            |  |            |  |            |  |
|----------------------------|--|------------|--------------------------------------|------------|--|------------|--|------------|--|
| <i>Object Type</i>         | Property (read only)   |            |                                      |            |  |            |  |            |  |
| <i>Data Type</i>           | Variant (Double array)   |            |                                      |            |  |            |  |            |  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |            |                                      |            |  |            |  |            |  |
| <i>Description</i>         | <p>The data array, which is the limit test results. The array size is 4N, where N is the number of measurement points.</p> <p>For the n-th point, where n from 1 to N:</p> <table> <tr> <td>Data(4n-3)</td> <td>the stimulus value in the n-th point</td> </tr> <tr> <td>Data(4n-2)</td> <td>the limit test result in the n-th point           <ul style="list-style-type: none"> <li>• -1: No limit</li> <li>• 0: Fail</li> <li>• 1: Pass</li> </ul> </td> </tr> <tr> <td>Data(4n-1)</td> <td>the upper limit value in the n-th point (0 – if there is no limit)</td> </tr> <tr> <td>Data(4n-0)</td> <td>the lower limit value in the n-th point (0 – if there is no limit)</td> </tr> </table> | Data(4n-3) | the stimulus value in the n-th point | Data(4n-2) | the limit test result in the n-th point <ul style="list-style-type: none"> <li>• -1: No limit</li> <li>• 0: Fail</li> <li>• 1: Pass</li> </ul> | Data(4n-1) | the upper limit value in the n-th point (0 – if there is no limit) | Data(4n-0) | the lower limit value in the n-th point (0 – if there is no limit) |
| Data(4n-3)                 | the stimulus value in the n-th point   |            |                                      |            |  |            |  |            |  |
| Data(4n-2)                 | the limit test result in the n-th point <ul style="list-style-type: none"> <li>• -1: No limit</li> <li>• 0: Fail</li> <li>• 1: Pass</li> </ul>   |            |                                      |            |  |            |  |            |  |
| Data(4n-1)                 | the upper limit value in the n-th point (0 – if there is no limit)   |            |                                      |            |  |            |  |            |  |
| Data(4n-0)                 | the lower limit value in the n-th point (0 – if there is no limit)   |            |                                      |            |  |            |  |            |  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch) .SElected.LIMit.REPort.ALL</pre>  |            |                                      |            |  |            |  |            |  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |            |                                      |            |  |            |  |            |  |

SCPI.CALCulate(*Ch*).SELected.LIMit.REPort.DATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The data array, which is the stimulus values at all the measurement points that failed the limit test. The array size is defined by the SCPI.CALCulate( <i>Ch</i> ).SELected.LIMit.REPort.POINTs property. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data =<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.LIMit.REPort.DATA  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SELected.LIMit.REPort.POINts

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of the measurement points that failed the limit test.<br>The array of stimulus values of the points can be read out by the SCPI.CALCulate( <i>Ch</i> ).SELected.LIMit.REPort.DATA property. |
| <i>Syntax</i>              | <pre>Dim Cnt As Long Cnt = app.SCPI.CALCulate(<i>Ch</i>).SELected.LIMit.REPort.POINts</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.CALCulate(*Ch*).SElected.LIMit.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the limit test function.   |
| <i>Allowable Values</i>    | <i>True</i> Limit test function ON<br><i>False</i> Limit test function OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.LIMit.STATE app.SCPI.CALCulate(Ch).SElected.LIMit.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Limit Test</b>  |

SCPI.CALCulate(*Ch*).SELected.MARKer(*Mk*).ACTivate

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Target</i>              | Marker <i>Mk</i> of the active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)   |
| <i>Description</i>         | Sets the active marker. If a marker is OFF this function will turn it ON.<br>Turning ON a marker with the number from 1 to 15 will turn ON all the markers of smaller numbers. Turning ON the reference marker with number 16 does not turn ON the markers with the numbers from 1 to 15, but switches these markers to the relative measurement mode. |
| <i>Syntax</i>              | app.SCPI.CALCulate( <i>Ch</i> ).SELected.MARKer( <i>Mk</i> ).ACTivate  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

Table 4. *Mk*: Marker Number

| <i>Data Type</i>    | Long  |
|---------------------|---|
| <i>Description</i>  | Marker number. Numbers from 1 to 15 are for regular markers, number 16 is for the reference marker. |
| <i>Range</i>        | from 1 to 16  |
| <i>Out of Range</i> | An error occurs. Error code: 203.   |

SCPI.CALCulate(*Ch*).SELected.MARKer(*Mk*).BWIDth.DATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i> channel number (see Table 1)</p> <p><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)</p>   |
| <i>Description</i>         | <p>The bandwidth search result. The bandwidth search can be performed relatively to the marker <i>Mk</i>, or relatively to the absolute maximum value of the trace (in this case the marker number is ignored), what is set by the SCPI .CALCulate (<i>Ch</i>) .SELected.MARKer .BWIDth .REFerence property.</p> <p>The array contains 4 elements:</p> <p>Data(0) Bandwidth;</p> <p>Data(1) Center frequency;</p> <p>Data(2) Q value;</p> <p>Data(3) Loss.</p> |
| <i>Notes</i>               | If the bandwidth search is impossible, all the read out values are 0. If the search is performed relatively to a maker, which is OFF, an error occurs (error code 204).  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch) .SELected.MARKer(Mk) .BWIDth     .DATA</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer.BWIDth.REFERENCE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The selection of the reference point for the bandwidth search function:<br>reference marker, absolute maximum or absolute minimum value of the trace.   |
| <i>Range</i>               | "MARKer" Bandwidth search relative to the reference marker<br><br>"MAXimum" Bandwidth search relative to the absolute maximum of<br>the trace<br><br>"MINimum" Bandwidth search relative to the absolute minimum of<br>the trace                              |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There<br>is no distinction between upper and lower case letters when the property<br>is written. When the property is read out, the short format is indicated by<br>upper case letters. |
| <i>Out of Range</i>        | The value is ignored.   |
| <i>Preset Value</i>        | "MAX"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth. REFERENCE app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth. REFERENCE = "MARK"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Bandwidth Search &gt; Search Ref To</b>  |

**SCPI.CALCulate(*Ch*).SELected.MARKer.BWIDth.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the bandwidth search function.   |
| <i>Allowable Values</i>    | <i>True</i> Bandwidth search function ON<br><i>False</i> Bandwidth search function OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SELected.MARKer.BWIDth.STATE app.SCPI.CALCulate(Ch).SELected.MARKer.BWIDth.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Bandwidth Search &gt; Bandwidth Search</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer.BWIDth.THReshold

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The bandwidth definition value.   |
| <i>Range</i>               | Varies depending on the trace format.   |
| <i>Out of Range</i>        | No limitation   |
| <i>Preset Value</i>        | -3  |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth. THReshold app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth. THReshold = -6.0</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Bandwidth Search &gt; Bandwidth Value</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer.BWIDth.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The type of the bandwidth search function.   |
| <i>Range</i>               | "BPASS" Bandpass<br>"NOTCh" Notch  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "BPAS"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth.TYPE app.SCPI.CALCulate(Ch).SElected.MARKer.BWIDth.TYPE = "NOTC"</pre>  |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Bandwidth Search &gt; Type Search</b>   |

**SCPI.CALCulate(*Ch*).SElected.MARKer.COUPLE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | All traces of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the marker coupling function.  |
| <i>Allowable Values</i>    | <i>True</i> Marker coupling ON<br><i>False</i> Marker coupling OFF   |
| <i>Preset Value</i>        | True   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).SElected.MARKer.COUPLE<br>app.SCPI.CALCulate(Ch).SElected.MARKer.COUPLE =<br>false |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Properties &gt; Marker Couple</b>   |

SCPI.CALCulate(*Ch*).SELected.MARKer(*Mk*).FUNCtion.DOMain. START

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the marker search range coupling is set to OFF by the SCPI.CALCulate(Ch).SELected.FUNCtion.DOMain.COUPLE property), the active trace of channel <i>Ch</i> (if otherwise),<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4) |
| <i>Description</i>         | The start value of the marker search range.  |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 85e6   |
| <i>Unit</i>                | Hz (Hertz)   s (second)   m (metre)   ft (foot)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.MARKer(Mk).FUNCtion.DOMain.START app.SCPI.CALCulate(Ch).SELected.MARKer(Mk).FUNCtion.DOMain.START = 100e6</pre>   |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Start</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.DOMain. STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the marker search range coupling is set to OFF by the SCPI.CALCulate(Ch).SElected.MARKer.FUNCtion.DOMain.COUPLE property), the active trace of channel <i>Ch</i> (if otherwise),<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4) |
| <i>Description</i>         | The ON/OFF state of the arbitrary range when executing the marker search.   |
| <i>Allowable Values</i>    | <i>True</i> Marker search range ON<br><i>False</i> Marker search range OFF (entire sweep range)   |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.DOMain.STATE<br>app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.DOMain.STATE = True  |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Range</b>   |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.DOMain. STOP

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | All traces of channel <i>Ch</i> (if the marker search range coupling is set to OFF by the SCPI.CALCulate(Ch).SElected.MARKer.FUNCtion.DOMain.COUPle property), the active trace of channel <i>Ch</i> (if otherwise),<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4) |
| <i>Description</i>         | The stop value of the marker search range.  |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.   |
| <i>Out of Range</i>        | No limitation   |
| <i>Preset Value</i>        | Maximum frequency of vector reflecrometer   |
| <i>Unit</i>                | Hz (Hertz)   s (second)   m (metre)   ft (foot)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.DOMain.STOP app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.DOMain.STOP = 3.1e9</pre>  |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Stop</b>  |

## SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.EXECute

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Target</i>              | Marker <i>Mk</i> of the active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)   |
| <i>Description</i>         | Executes the marker search according to the specified criterion. The type of the marker search is set by the SCPI.CALCulate( <i>Ch</i> ).SESelected.MARKer( <i>Mk</i> ).FUNCTION.TYPE property.  |
| <i>Syntax</i>              | app.SCPI.CALCulate( <i>Ch</i> ).SESelected.MARKer( <i>Mk</i> ).FUNCTION.EXECute  |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Maximum   Minimum</b><br><br><b>Marker &gt; Search &gt; Search Peak &gt; Search Peak   Search Max Peak   Search Peak Left   Search Peak Right</b><br><br><b>Marker &gt; Search &gt; Search Target &gt; Search Target   Search Target Left   Search Target Right</b> |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.PEXcursion

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i> channel number (see Table 1)</p> <p><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)</p> |
| <i>Description</i>         | The peak excursion value, when the marker search for peak is performed by the SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.EXECute method.  |
| <i>Range</i>               | Varies depending on the trace format.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 1  |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)   m (metre)   ft (foot)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.PEXcursion app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.PEXcursion = 3.0</pre>                       |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Peak &gt; Peak Excursion</b>   |

SCPI.CALCulate(*Ch*).SELected.MARKer(*Mk*).FUNCtion.PPOLarity

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i> channel number (see Table 1)</p> <p><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)</p>   |
| <i>Description</i>         | The peak polarity selection, when the marker search for peak is performed by the SCPI.CALCulate(Ch).SELected.MARKer(Mk).FUNCtion.EXECute method.   |
| <i>Range</i>               | <p>"POSitive" Positive polarity</p> <p>"NEGative" Negative polarity</p> <p>"BOTH" Both positive polarity and negative polarity</p>   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "POS"  |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SELected.MARKer(Mk).FUNCtion.PPOLarity app.SCPI.CALCulate(Ch).SELected.MARKer(Mk).FUNCtion.PPOLarity = "neg"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Peak &gt; Peak Polarity &gt; Positive   Negative   Both</b>  |

SCPI.CALCulate(*Ch*).SELected.MARKer(*Mk*).FUNCtion.TARGet

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Marker <i>Mk</i> of the active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4) |
| <i>Description</i>         | The target value, when the marker search for target is performed by the SCPI .CALCulate (Ch) .SELected.MARKer (Mk) .FUNCtion. EXECute method.                                      |
| <i>Range</i>               | Varies depending on the trace format.  |
| <i>Out of Range</i>        | No limitation  |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate (Ch) .SELected.MARKer (Mk) .FUNCtion.TARGet app.SCPI.CALCulate (Ch) .SELected.MARKer (Mk) .FUNCtion.TARGet = -10</pre>         |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Target &gt; Target Value</b>   |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.TRACKing

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i> channel number (see Table 1)</p> <p><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)</p> |
| <i>Description</i>         | The ON/OFF state of the marker search tracking function.   |
| <i>Allowable Values</i>    | <p><i>True</i> Marker search tracking ON</p> <p><i>False</i> Marker search tracking OFF</p>  |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.TRACKing app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.TRACKing = True</pre>                       |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Tracking</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.TTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i>      channel number (see Table 1)</p> <p><i>Mk</i>      marker number 1–15, or reference marker number 16 (see Table 4)</p>   |
| <i>Description</i>         | The selection of the type of the target transition, when the marker search for transition is performed by the SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).FUNCtion.EXECute method.  |
| <i>Range</i>               | <p>"POSitive"    Positive target transition</p> <p>"NEGative"    Negative target transition</p> <p>"BOTH"        Both positive target transition and negative target transition</p>  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "POS"  |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.TTRansition app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).FUNCtion.TTRansition = "NEG"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Search Target &gt; Target Transition</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).FUNCtion.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Marker <i>Mk</i> of the active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)   |
| <i>Description</i>         | The selection of the type of the marker search, which is performed by the SCPI.CALCulate ( <i>Ch</i> ) .SElected.MARKer ( <i>Mk</i> ) .FUNCtion.EXECute method.  |
| <i>Range</i>               | "MAXimum" Maximum value search<br>"MINimum" Minimum value search<br>"PEAK" Peak search<br>"LPEnak" Peak search to the left from the marker<br>"RPEnak" Peak search to the right from the marker<br>"TARGET" Target search<br>"LTARGET" Target search to the left from the marker<br>"RTARGET" Target search to the right from the marker |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters.   |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "MAX"  |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.CALCulate ( <i>Ch</i> ) .SElected.MARKer ( <i>Mk</i> ) .FUNCtion.TYPE<br>app.SCPI.CALCulate ( <i>Ch</i> ) .SElected.MARKer ( <i>Mk</i> ) .FUNCtion.TYPE = "MIN"   |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Search &gt; Maximum   Minimum</b><br><br><b>Marker &gt; Search &gt; Search Peak &gt; Search Peak   Max Peak   Peak Left   Peak Right</b><br><br><b>Marker &gt; Search &gt; Search Target &gt; Search Target   Target Left   Target Right</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer.REFerence.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the reference marker. When the reference marker is turned ON, all the values of the other markers turn to relative values.                   |
| <i>Allowable Values</i>    | <i>True</i> Reference marker ON<br><i>False</i> Reference marker OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.MARKer.REFerence. STATE app.SCPI.CALCulate(Ch).SElected.MARKer.REFerence. STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Reference Marker</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).SET\_

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Marker <i>Mk</i> of the active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Mk</i> marker number 1–15, or reference marker number 16 (see Table 4)  |
| <i>Description</i>         | The setting of the value of the specified item to the value of the position of the marker.  |
| <i>Range</i>               | "START" Sweep start value set to the stimulus value of the marker position.<br>"STOP" Sweep stop value set to the stimulus value of the marker position.<br>"CENTER" Sweep center value set to the stimulus value of the marker position.<br>"RLEVel" Reference value set to the response value of the marker position. |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters.  |
| <i>Out of Range</i>        | The value is ignored.   |
| <i>Syntax</i>              | app.SCPI.CALCulate( <i>Ch</i> ).SElected.MARKer( <i>Mk</i> ).SET_ = "STOP"  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i>      channel number (see Table 1)</p> <p><i>Mk</i>      marker number 1–15, or reference marker number 16 (see Table 4)</p>  |
| <i>Description</i>         | The ON/OFF state of a marker. Turning ON a marker with the number from 1 to 15 will turn ON all the markers of smaller numbers. Turning OFF a marker with the number from 1 to 15 will turn OFF all the markers of greater numbers (except for the reference marker). Turning ON/OFF the reference marker with number 16 does not turn ON/OFF the markers with the numbers from 1 to 15, but switches these markers to the relative measurement mode. |
| <i>Allowable Values</i>    | <p><i>True</i>      Marker ON</p> <p><i>False</i>      Marker OFF</p>   |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).STATE app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).STATE = True</pre>  |
| <i>Equivalent Softkeys</i> | <p><b>Marker &gt; Add Marker   Delete Marker</b></p> <p><b>Marker &gt; Reference Marker</b></p>   |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).X

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i>      channel number (see Table 1)</p> <p><i>Mk</i>      marker number 1–15, or reference marker number 16 (see Table 4)</p> |
| <i>Description</i>         | The stimulus value of the marker.  |
| <i>Range</i>               | From the stimulus current start value to the stimulus current stop value.  |
| <i>Out of Value</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Stimulus center value  |
| <i>Unit</i>                | Hz (Hertz)   s (second)   m (metre)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).X app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).X =  1e9</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.MARKer(*Mk*).Y

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Variant (Double array)  |
| <i>Target</i>              | <p>Marker <i>Mk</i> of the active trace of channel <i>Ch</i>,</p> <p><i>Ch</i>      channel number (see Table 1)</p> <p><i>Mk</i>      marker number 1–15, or reference marker number 16 (see Table 4)</p>  |
| <i>Description</i>         | <p>The response value of the marker. If the reference marker is turned ON, the values of the markers from 1 to 15 are read out as relative values to the reference marker.</p> <p>The array includes 2 elements:</p> <p>Data(0)      real number in rectangular format, real part in polar and Smith chart formats;</p> <p>Data(1)      0 in rectangular format, imaginary part in polar and Smith chart formats.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch).SElected.MARKer(Mk).Y</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.MARKer.COUNT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of the turned ON markers excluding the reference marker.  |
| <i>Range</i>               | from 0 to 16   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim MarkerCnt As Long MarkerCnt = app.SCPI.CALCulate(Ch).SElected.MARKer.COUNT app.SCPI.CALCulate(Ch).SElected.MARKer.COUNT = 5</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.CALCulate(*Ch*).SElected.MATH.DELETE**

| <i>Object Type</i>         | Method  |
|----------------------------|---|
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | Removes the data from the memory trace.   |
| <i>Syntax</i>              | app.SCPI.CALCulate(Ch).SElected.MATH.DELETE                                       |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Clear Memory</b>  |

**SCPI.CALCulate(*Ch*).SELected.MATH.FUNCtion**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The selection of the math operation between the measurement data and the memory trace data. The math result replaces the data trace. If the data trace is not saved, the command is ignored.   |
| <i>Range</i>               | <p>"DIVide" Division <i>Data / Mem.</i></p> <p>"MULTiply" Multiplication <i>Data x Mem.</i></p> <p>"ADD" Addition <i>Data + Mem.</i></p> <p>"SUBTract" Subtraction <i>Data – Mem.</i></p> <p>"NORMal" No math</p>                                    |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs. Error code 210.   |
| <i>Preset Value</i>        | "NORM"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SELected.MATH.FUNCtion app.SCPI.CALCulate(Ch).SELected.MATH.FUNCtion= "DIV"</pre>  |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Data Math &gt; Data/Mem   Data*Mem   Data+Mem   Data–Mem   OFF</b>   |

**SCPI.CALCulate(*Ch*).SELected.MATH.MEMorize**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                       |
| <i>Description</i>         | Saves the measurement data to the memory trace. Automatically turns on the display of the memory trace. |
| <i>Syntax</i>              | app.SCPI.CALCulate(Ch).SELected.MATH.MEMorize   |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Memory Trace</b>  |

**SCPI.CALCulate(*Ch*).SELected.MAXhold.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The ON/OFF state of the Maximum Hold function.  |
| <i>Allowable Values</i>    | <i>True</i> Maximum Hold ON<br><i>False</i> Maximum Hold OFF  |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate(Ch).SELected.MAXhold.STATE<br>app.SCPI.CALCulate(Ch).SELected.MAXhold.STATE =<br>True |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Max Hold</b>  |

SCPI.CALCulate(*Ch*).SElected.MStatistics.DATA

|                            |   |         |             |         |                     |         |  |
|----------------------------|---|---------|-------------|---------|---------------------|---------|--|
| <i>Object Type</i>         | Property (read only)  |         |             |         |                     |         |  |
| <i>Data Type</i>           | Variant (Double array)  |         |             |         |                     |         |  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |         |             |         |                     |         |  |
| <i>Description</i>         | <p>The math statistics data array. The statistics function is applied either over the whole range (for all the trace), or within the range specified by the SCPI .CALCulate (Ch) .SElected.MStatistics.DOMain.STATE property (the range limits are determined by two markers).</p> <p>The array includes 3 elements:</p> <table> <tr> <td>Data(0)</td> <td>Mean value;</td> </tr> <tr> <td>Data(1)</td> <td>Standard deviation;</td> </tr> <tr> <td>Data(2)</td> <td>Peak-to-peak (difference between the maximum value and the minimum value).</td> </tr> </table> | Data(0) | Mean value; | Data(1) | Standard deviation; | Data(2) | Peak-to-peak (difference between the maximum value and the minimum value). |
| Data(0)                    | Mean value;   |         |             |         |                     |         |  |
| Data(1)                    | Standard deviation;   |         |             |         |                     |         |  |
| Data(2)                    | Peak-to-peak (difference between the maximum value and the minimum value).  |         |             |         |                     |         |  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch).SElected.MStatistics.DATA</pre>  |         |             |         |                     |         |  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |         |             |         |                     |         |  |

SCPI.CALCulate(*Ch*).SELected.MStatistics.DOMain.MARKer.START

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of the marker, which specifies the start frequency of the math statistics range.  |
| <i>Range</i>               | from 1 to 16   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | <pre>Dim MkrNum As Long MkrNum = app.SCPI.CALCulate(Ch).SELected.MStatistics.DOMain. MARKer.START app.SCPI.CALCulate(Ch).SELected.MStatistics.DOMain. MARKer.START = 3</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Statistics &gt; Statistic Start</b>   |

SCPI.CALCulate(*Ch*).SELected.MStatistics.DOMain.MARKer.STOP

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of the marker, which specifies the stop frequency of the math statistics range.   |
| <i>Range</i>               | from 1 to 16   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 2  |
| <i>Syntax</i>              | <pre>Dim MarkerNum As Long MarkerNum = app.SCPI.CALCulate(Ch).SELected.MStatistics.DOMai n. MARKer.STOP app.SCPI.CALCulate(Ch).SELected.MStatistics.DOMai n. MARKer.STOP = 4</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Statistics &gt; Statistic Stop</b>  |

**SCPI.CALCulate(*Ch*).SELected.MStatistics.DOMain.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the math statistics range.   |
| <i>Allowable Values</i>    | <i>True</i> Statistics range ON<br><i>False</i> Statistics range OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch) .SELected.MStatistics.DOMai n.STATE app.SCPI.CALCulate(Ch) .SELected.MStatistics.DOMai n.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Math &gt; Statistics &gt; Statistic Range</b>   |

**SCPI.CALCulate(*Ch*).SELected.MSTatistics.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the math statistics display.   |
| <i>Allowable Values</i>    | <i>True</i> Statistics display ON<br><i>False</i> Statistics display OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SELected.MSTatistics.STATE app.SCPI.CALCulate(Ch).SELected.MSTatistics.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Markers &gt; Math &gt; Statistics &gt; Statistics</b>   |

**SCPI.CALCulate(*Ch*).SElected.RLIMit.DATA**

|                            |   |         |   |            |   |            |  |            |  |            |   |
|----------------------------|---|---------|---|------------|---|------------|--|------------|--|------------|---|
| <i>Object Type</i>         | Property (read/write)   |         |   |            |   |            |  |            |  |            |   |
| <i>Data Type</i>           | Variant (Double array)  |         |   |            |   |            |  |            |  |            |   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |         |   |            |   |            |  |            |  |            |   |
| <i>Description</i>         | <p>The data array, which is the limit line for the ripple limit function. The array size is <math>1 + 4N</math>, where N is the number of limit line segments.</p> <p>For the n-th point, where n from 1 to N:</p> <table> <tr> <td>Data(0)</td> <td>the number of limit line segments N is the integer from 0 to 12. Setting 0 clears the limit line;</td> </tr> <tr> <td>Data(4n-3)</td> <td>type of the n-th limit line segment;<br/> <ul style="list-style-type: none"> <li>• 0: Off</li> <li>• 1: On</li> </ul> </td> </tr> <tr> <td>Data(4n-2)</td> <td>the stimulus value in the beginning point of the n-th segment;</td> </tr> <tr> <td>Data(4n-1)</td> <td>the stimulus value in the end point of the n-th segment;</td> </tr> <tr> <td>Data(4n-0)</td> <td>the ripple limit value of the n-th segment.</td> </tr> </table> | Data(0) | the number of limit line segments N is the integer from 0 to 12. Setting 0 clears the limit line; | Data(4n-3) | type of the n-th limit line segment;<br><ul style="list-style-type: none"> <li>• 0: Off</li> <li>• 1: On</li> </ul> | Data(4n-2) | the stimulus value in the beginning point of the n-th segment; | Data(4n-1) | the stimulus value in the end point of the n-th segment; | Data(4n-0) | the ripple limit value of the n-th segment. |
| Data(0)                    | the number of limit line segments N is the integer from 0 to 12. Setting 0 clears the limit line;   |         |   |            |   |            |  |            |  |            |   |
| Data(4n-3)                 | type of the n-th limit line segment;<br><ul style="list-style-type: none"> <li>• 0: Off</li> <li>• 1: On</li> </ul>   |         |   |            |   |            |  |            |  |            |   |
| Data(4n-2)                 | the stimulus value in the beginning point of the n-th segment;  |         |   |            |   |            |  |            |  |            |   |
| Data(4n-1)                 | the stimulus value in the end point of the n-th segment;  |         |   |            |   |            |  |            |  |            |   |
| Data(4n-0)                 | the ripple limit value of the n-th segment.   |         |   |            |   |            |  |            |  |            |   |
| <i>Notes</i>               | If the array size is not $1 + 4N$ , where N is Data(0), an error occurs (error code 214). If Data(4n - 3) is less than 0 or more than 1, an error occurs (error code 214). When Data(4n-2), Data(4n-1), and Data(4n-0) elements are out of allowable range, the value is set to the limit, which is closer to the specified value.  |         |   |            |   |            |  |            |  |            |   |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(<i>Ch</i>).SElected.RLIMit.DATA app.SCPI.CALCulate(<i>Ch</i>).SElected.RLIMit.DATA = Array(1,1,800,900,10)</pre>   |         |   |            |   |            |  |            |  |            |   |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Ripple Test &gt; Edit Ripple Limit</b>   |         |   |            |   |            |  |            |  |            |   |

**SCPI.CALCulate(*Ch*).SELected.RLIMit.DISPlay.LINE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The ON/OFF state of the ripple limit line display.  |
| <i>Allowable Values</i>    | <i>True</i> Ripple limit line ON<br><i>False</i> Ripple limit line OFF  |
| <i>Preset Value</i>        | <i>False</i>  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.RLIMit.DISPlay.LI<br>NE<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.RLIMit.DISPlay.LI<br>NE = <i>True</i> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Ripple Test &gt; Limit Line</b>  |

**SCPI.CALCulate(*Ch*).SELected.RLIMit.FAIL**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)         |
| <i>Description</i>         | Ripple limit test result.   |
| <i>Allowable Values</i>    | <i>True</i> Fail<br><i>False</i> Pass   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.RLIMit.FAIL |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.RLIMit.REPort.DATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | <p>The data array, which is the ripple limit test results. The array size is 1+3N, where N is the number of ripple limit bands.</p> <p>For the n-th point, where n from 1 to N:</p> <ul style="list-style-type: none"> <li>Data(0) N total number of the bands;</li> <li>Data(3n-2) n number of the band;</li> <li>Data(3n-1) Ripple value in the n-th band;</li> <li>Data(3n-0) Ripple limit test result in the n-th band: <ul style="list-style-type: none"> <li>• 0: Pass</li> <li>• 1: Fail</li> </ul> </li> </ul> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.CALCulate(Ch).SElected.RLIMit.REPort.DAT A</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.CALCulate(*Ch*).SELected.RLIMit.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The ON/OFF state of the ripple limit test.  |
| <i>Allowable Values</i>    | <i>True</i> Ripple limit test ON<br><i>False</i> Ripple limit test OFF  |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.RLIMit.STATE<br>app.SCPI.CALCulate( <i>Ch</i> ).SELected.RLIMit.STATE =<br>True |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Ripple Test &gt; Ripple Test</b>   |

SCPI.CALCulate(*Ch*).SElected.SMOothingAPERture

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The smoothing aperture for the smoothing function.   |
| <i>Range</i>               | from 0.01 to 20  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 1  |
| <i>Unit</i>                | %  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.SMOothingAPERture app.SCPI.CALCulate(Ch).SElected.SMOothingAPERture = 1.5</pre> |
| <i>Equivalent Softkeys</i> | <b>Average &gt; Smoothing Aperture</b>   |

SCPI.CALCulate(*Ch*).SELected.SMOothing.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the trace smoothing function.  |
| <i>Allowable Values</i>    | <i>True</i> Trace smoothing ON<br><i>False</i> Trace smoothing OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch).SELected.SMOothing.STATE app.SCPI.CALCulate(Ch).SELected.SMOothing.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Average &gt; Smoothing</b>  |

SCPI.CALCulate(*Ch*).SELected.TRANSform.DISTance.CENTer

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The time domain center value, when the time domain transformation function is turned ON.<br>(obsolete command)  |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second), m (metre), ft (foot)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.DISTanc e.CENTer app.SCPI.CALCulate(Ch).SELected.TRANSform.DISTanc e.CENTer = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SELected.TRANSform.DISTance.SPAN

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The time domain span value, when the time domain transformation function is turned ON.<br>(obsolete command)   |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 1e-8   |
| <i>Unit</i>                | s (second), m (metre), ft (foot)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.DISTanc e.SPAN app. SCPI.CALCulate(Ch).SELected.TRANSform.DISTance.SP AN = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.TRANSform.DISTance.MINimum

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The start value used for the transformation function of the time domain function.<br>(obsolete command)   |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second), m (metre), ft (foot)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.TRANSform.DISTanc e.MINimum app.SCPI.CALCulate(Ch).SElected.TRANSform.DISTanc e.MINimum = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SELected.TRANSform.DISTance.MAXimum

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The time domain stop value, when the time domain transformation function is turned ON.<br>(obsolete command)  |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 1e-8  |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.DISTanc e.MAXimum app.SCPI.CALCulate(Ch).SELected.TRANSform.DISTanc e.MAXimum = 2e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Start Distance – Stop Distance</b>   |

## SCPI.CALCulate(Ch).SELected.TRANSform.DISTance.UNIT

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Set the unit of measurement for time domain.<br>(obsolete command)  |
| <i>Range</i>               | "SEC"      seconds;<br>"MET"      metre;<br>"FEET"      feet.   |
| <i>Out of Range</i>        | An error occurs.  |
| <i>Preset Value</i>        | "MET"   |
| <i>Syntax</i>              | <pre>Dim Value As String Value = app.SCPI.CALCulate(Ch) .SELected.TRANSform.DISTance .UNIT app.SCPI.CALCulate(Ch) .SELected.TRANSform.DISTance .UNIT = "FEET"</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.CENTer

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The time domain center value, when the time domain transformation function is turned ON.  |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (seconds), m (meters) or ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. CENTer app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. CENTer = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Center</b>  |

SCPI.CALCulate(*Ch*).SELected.TRANSform.TIME.IMPulse.WIDTH

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The impulse width (time domain transformation resolution), coupled with the Kaiser–Bessel window shape $\beta$ parameter. The impulse width setting changes the $\beta$ parameter, and setting of $\beta$ parameter changes the impulse width. |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | None   |
| <i>Unit</i>                | s (second)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME. IMPulse.WIDTH app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME. IMPulse.WIDTH = 1e-8</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.KBESsel

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The $\beta$ parameter, which controls the Kaiser–Bessel window shape, when performing time domain transformation.   |
| <i>Range</i>               | from 0 to 13  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 6   |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. KBESsel app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. KBESsel = 13</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.LPFRrequency

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                      |
| <i>Description</i>         | Changes the frequency range to match with the lowpass type of the time domain transformation function. |
| <i>Syntax</i>              | app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.LPFRrequency  |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Set Frequency Low Pass</b>   |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.SPAN

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The time domain span value, when the time domain transformation function is turned ON.  |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 2e-8  |
| <i>Unit</i>                | s (seconds), m (meters) or ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.SP AN app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.SP AN = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Span</b>  |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.START

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The start value used for the transformation function of the time domain function.   |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | -1e-8   |
| <i>Unit</i>                | s (seconds), m (meters) or ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. START app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME. START = 1e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Start</b>   |

**SCPI.CALCulate(*Ch*).SELected.TRANSform.TIME.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the time domain transformation function.   |
| <i>Allowable Values</i>    | <i>True</i> Time domain transformation ON<br><i>False</i> Time domain transformation OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.CALCulate(Ch) .SELected.TRANSform.TIME. STATE app.SCPI.CALCulate(Ch) .SELected.TRANSform.TIME. STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Time Domain</b>  |

SCPI.CALCulate(*Ch*).SELected.TRANSform.TIME.STEP.RTIme

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The rise time of the step signal (time domain transformation resolution), coupled with the Kaiser–Bessel window shape $\beta$ parameter. The impulse width setting changes the $\beta$ parameter, and setting of $\beta$ parameter changes the impulse width. |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | None  |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME. IMPulse.WIDTh app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME. IMPulse.WIDTh = 1e-8</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.TIMulus

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The selection of the stimulus type for the time domain transformation function: impulse or step.  |
| <i>Range</i>               | "IMPulse<br>"<br>"STEP" Step  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters.<br>There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.   |
| <i>Preset Value</i>        | "IMP"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch) .SElected.TRANSform.TIME. STIMulus app.SCPI.CALCulate(Ch) .SElected.TRANSform.TIME. STIMulus = "STEP"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Response Type &gt; Bandpass   Lowpass Step   Lowpass Impulse</b>  |

SCPI.CALCulate(*Ch*).SELected.TRANSform.TIME.STOP

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The time domain stop value, when the time domain transformation function is turned ON.  |
| <i>Range</i>               | Varies depending on the specified frequency range and the number of points.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 1e-8  |
| <i>Unit</i>                | s (seconds), m (meters) or ft (feet)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME.STOP app.SCPI.CALCulate(Ch).SELected.TRANSform.TIME.STOP = 2e-8</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Stop</b>  |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The selection of the transformation type for the time domain transformation function: bandpass response or direct current circuit.   |
| <i>Range</i>               | "BPASSs" Bandpass<br>"LPASSs" Lowpass  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "BPASSs"   |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.TY<br>PE<br>app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.TY<br>PE = "STEP"  |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Response Type &gt; Bandpass   Lowpass Step   Lowpass Impulse</b>   |

SCPI.CALCulate(*Ch*).SElected.TRANSform.TIME.UNIT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The selection of the unit for the time domain transformation function.   |
| <i>Range</i>               | "SEC" Seconds<br>"MET" Metre<br>"FEET" Feet  |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "SEC"  |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.UN IT app.SCPI.CALCulate(Ch).SElected.TRANSform.TIME.UN IT = "MET"</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Unit &gt; Time, ns   Metric, m   Imperial, ft</b>  |

SCPI.CALCulate(*Ch*).SELected.TRANSform.KWINdow

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | The active trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The Kaiser–Bessel window shape, when performing time domain transformation.   |
| <i>Range</i>               | "MINimum" minimum window shape<br>"NORMal" normal window shape<br>"MAXimum" maximum window shape  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 6   |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As String Value = app.SCPI.CALCulate(Ch).SELected.TRANSform.KWINdow app.SCPI.CALCulate(Ch).SELected.TRANSform.KWINdow = "'MAX"</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Kaiser Window &gt; Minimum   Normal   Maximum</b>   |

SCPI.CALCulate(*Ch*).TRACe(*Tr*).DATA.FDATA

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Variant (Double array)  |
| <i>Target</i>              | The specified trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Tr</i> trace number (see Table 3)<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The formatted data array. The array elements contain measurements in the current format, for example, in logarithmic magnitude format (Log Mag). Also, see section 12.<br>The array size is 2N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br>Data(2n-2) real number in rectangular format, real part in polar and Smith chart formats;<br>Data(2n-1) 0 in rectangular format, imaginary part in polar and Smith chart formats. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data =<br>app.SCPI.CALCulate( <i>Ch</i> ).Trace( <i>Tr</i> ).DATA.FDATA  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.CALCulate(*Ch*).TRACe(*Tr*).DATA.FMEMory

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The specified trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Tr</i> trace number (see Table 3)<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The formatted memory array. The array elements contain saved measurements in the current format, for example, in logarithmic magnitude format (Log Mag). Also, see section 12. The array size is 2N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br>Data(2n-2)      real number in rectangular format, real part in polar and Smith chart formats;<br>Data(2n-1)      0 in rectangular format, imaginary part in polar and Smith chart formats. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data =<br>app.SCPI.CALCulate( <i>Ch</i> ).Trace( <i>Tr</i> ).DATA.FMEMory   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).TRACe(*Tr*).DATA.SDATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The specified trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Tr</i> trace number (see Table 3)<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The corrected data array. The corrected measurements are complex numbers. Also, see section 12.<br>The array size is 2N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br>Data(2n-2)      the real part of corrected measurement;<br>Data(2n-1)      the imaginary part of corrected measurement. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data = app.SCPI.CALCulate(Ch) .<br>Trace(Tr) .DATA.SDATA  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.CALCulate(*Ch*).TRACe(*Tr*).DATA.SMEMory

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | The specified trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Tr</i> trace number (see Table 3)<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The corrected memory array. The corrected measurements are complex numbers. Also, see section 12.<br>The array size is 2N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br>Data(2n-2)      the real part of corrected measurement memory;<br>Data(2n-1)      the imaginary part of corrected measurement memory. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data =<br>app.SCPI.CALCulate( <i>Ch</i> ) .Trace( <i>Tr</i> ) .DATA.SMEMory   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.DEVices.ADDNext**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Description</i>         | Additing one more device to configuration<br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.ADDNext   |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Add Next</b>                                       |

**SCPI.DEVices.COUNT**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Description</i>         | Number of connected devices in the configuration<br>(in N-port mode only) |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.DEVices.COUNT                       |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DEVices.MOVDown(Port)**

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Description</i>         | Moving the device from the position <i>Port</i> into position <i>Port+1</i><br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.MOVDown(Port)   |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Move Down</b>  |

**SCPI.DEVices.MOVUp(Port)**

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Description</i>         | Moving the device from the position <i>Port</i> into position <i>Port-1</i><br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.MOVUp(Port)   |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Move Up</b>  |

**SCPI.DEVices.READy(Port)**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Boolean   |
| <i>Description</i>         | Readiness of the device associated with port <i>Port</i><br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.READy(Port)  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DEVices.REFerence.ADJust.Execute**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Description</i>         | Adjustment of the reference frequency of all devices relative to the first in the list<br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.REFerence.ADJust.Execute   |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Adjust Immediate</b>  |

## SCPI.DEVices. REFerence.ADJust.Period

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Long  |
| <i>Description</i>         | Frequency automatic adjustment period<br>(in N-port mode only)                |
| <i>Unit</i>                | sec   |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.DEVices.REFerence.ADJust.Period</pre> |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Frequency Adjust Period { OFF   3   10   30   100   300 }</b> |

## SCPI.DEVices. REFerence.Offset(Port)

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Description</i>         | Reference frequency correction value<br>(in N-port mode only) |
| <i>Unit</i>                | Hz  |
| <i>Syntax</i>              | app.SCPI.DEVices.REFerence.Offset(Port)                       |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.DEVices.REMLast

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Description</i>         | Removing one more device to configuration<br>(in N-port mode only) |
| <i>Syntax</i>              | app.SCPI.DEVices.REMLast   |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Remove Last</b>                                    |

**SCPI.DEVices.SERial(Port)**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | String  |
| <i>Description</i>         | Serial number of the device associated with port <i>Port</i><br>(in N-port mode only) |
| <i>Syntax</i>              | Dim Value As String<br>Value = app.SCPI.DEVices.SERial (Port)                         |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DEVices.SYNChronization.Method**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Description</i>         | Device synchronization method<br>(in N-port mode only)                |
| <i>Syntax</i>              | app.SCPI.DEVices. SYNChronization.Method                              |
| <i>Equivalent Softkeys</i> | <b>Devices &gt; Synchronization { Free Run   USB Bus   Trig Bus }</b> |

**SCPI.DISPlay.ANNotation.FREQuency.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | The ON/OFF state of the frequency/distance labels on the channel windows.   |
| <i>Allowable Values</i>    | <p><i>True</i> Frequency/Distance labels ON</p> <p><i>False</i> Frequency/Distance labels OFF</p>   |
| <i>Preset Value</i>        | True  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.DISPlay.ANNotation.FREQuency.STATE app.SCPI.DISPlay.ANNotation.FREQuency.STATE = False</pre> |
| <i>Equivalent Softkeys</i> | <b>Display &gt; Frequency / Distance Label</b>  |

## SCPI.DISPlay.COLor.BACK

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Variant (Long array)  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | <p>The background color for trace display.</p> <p>The array contains 3 elements:</p> <p>Data(0) Red value R;</p> <p>Data(1) Green value G;</p> <p>Data(2) Blue value B.</p> |
| <i>Range</i>               | For all the array elements from 0 to 255.   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 16, 16, 16  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.DISPlay.COLor.BACK app.SCPI.DISPlay.COLor.BACK = Array(0, 0, 0)</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DISPlay.COLor.GRATicule**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | <p>The grid and the graticule label color for trace display.</p> <p>The array contains 3 elements:</p> <p>Data(0)      Red value R;</p> <p>Data(1)      Green value G;</p> <p>Data(2)      Blue value B.</p> |
| <i>Range</i>               | For all array elements from 0 to 255.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Data (0)      63<br>Data (1)      63<br>Data (2)      63   |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.DISPlay.COLor.GRATicule app.SCPI.DISPlay.COLor.GRATicule = Array(128, 128, 128)</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.DISPlay.COLor.RESet**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Restores the display settings to the default values. |
| <i>Syntax</i>              | <code>app.SCPI.DISPlay.COLor.RESet</code>            |
| <i>Equivalent Softkeys</i> | <b>Display &gt; Preset</b>                           |

SCPI.DISPlay.COLOr.TRACe(*Tr*).DATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Trace number <i>Tr</i> in all channels,<br><i>Tr</i> trace number (see Table 3)  |
| <i>Description</i>         | The data trace color.<br>The array contains 3 elements:<br><br>Data(0) Red value R;<br>Data(1) Green value G;<br>Data(2) Blue value B. |
| <i>Range</i>               | For all array elements from 0 to 255.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the trace number.  |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.DISPlay.COLOr.TRACe(Tr).DATA app.SCPI.DISPlay.COLOr.TRACe(Tr).DATA = Array(255, 255, 0)</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.DISPlay.COLOr.TRACe(*Tr*).MEMORY

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Trace number <i>Tr</i> in all channels<br><i>Tr</i> trace number (see Table 3)   |
| <i>Description</i>         | The memory trace color.<br>The array contains 3 elements:<br><br>Data(0) Red value R;<br><br>Data(1) Green value G;<br><br>Data(2) Blue value B.           |
| <i>Range</i>               | For all array elements from 0 to 255.  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the trace number.  |
| <i>Syntax</i>              | Dim Data As Variant<br>Data = app.SCPI.DISPlay.COLOr.TRACe( <i>Tr</i> ).MEMORY<br>app.SCPI.DISPlay.COLOr.TRACe( <i>Tr</i> ).MEMORY =<br>Array(255, 255, 0) |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.DISPlay.ENABLe**

|                            |  |                    |
|----------------------------|--|--------------------|
| <i>Object Type</i>         | Property (read/write)  |                    |
| <i>Data Type</i>           | Boolean  |                    |
| <i>Description</i>         | Turns ON/OFF the display update.                                   |                    |
| <i>Allowable Values</i>    | <i>True</i>  | Display update ON  |
|                            | <i>False</i>   | Display update OFF |
| <i>Preset Value</i>        | True   |                    |
| <i>Syntax</i>              | Status = app.SCPI.DISPlay.ENABLe<br>app.SCPI.DISPlay.ENABLe = true |                    |
| <i>Equivalent Softkeys</i> | <b>Display &gt; Update</b>   |                    |

**SCPI.DISPlay.FSIGN**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The ON/OFF state of the <i>Fail</i> sign display, when performing limit test or ripple limit test.           |
| <i>Allowable Values</i>    | <p><i>True</i> Fail sign display ON</p> <p><i>False</i> Fail sign display OFF</p>                            |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.DISPlay.FSIGN app.SCPI.DISPlay.FSIGN = True</pre>               |
| <i>Equivalent Softkeys</i> | <p><b>Analysis &gt; Limit Test &gt; Fail Sign</b></p> <p><b>Analysis &gt; Ripple Test &gt; Fail Sign</b></p> |

**SCPI.DISPlay.IMAGe**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The inverted color display of the data traces.   |
| <i>Range</i>               | "NORMal" Normal display<br>"INVert" Inverted color display   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "NORM"   |
| <i>Syntax</i>              | Dim Param As String<br>Param = app.SCPI.DISPlay.IMAGe<br>app.SCPI.DISPlay.IMAGe = "INV"  |
| <i>Equivalent Softkeys</i> | <b>Display &gt; Inverse Color</b>  |

**SCPI.DISPlay.MAXimize**




|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Active Channel   |
| <i>Description</i>         | The ON/OFF maximize state of the active channel window.  |
| <i>Allowable Values</i>    | <p><i>True</i>      Maximize active channel state ON</p> <p><i>False</i>     Maximize active channel state OFF</p> |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | <p>Dim Status As Boolean</p> <p>Status = app.SCPI.DISPlay.MAXimize</p> <p>app.SCPI.DISPlay.MAXimize = True</p>     |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Maximize Channel</b>  |

## SCPI.DISPlay.SPLit






|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The number and layout of the channel windows on the screen. The channel window layout is in Table 5 below. |
| <i>Range</i>               | From 1 to 6<br>From 1 to 12 (in N-port mode only)  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.                                       |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.DISPlay.SPLit<br>app.SCPI.DISPlay.SPLit = 2                          |
| <i>Equivalent Softkeys</i> | <b>Channels</b>  |

Table 5.

## Channel Window Layout on the Screen

|  |  |  |
|--|--|--|
| 1:  | 2:  | 3:  |
| 4:  | 5:  | 6:  |

## Channel Window Layout on the Screen (in N-port mode only)

|   |   |   |
|---|---|---|
| 1:   | 2:   | 3:   |
| 4:   | 5:   | 6:   |
| 7:   | 8:   | 9:   |
| 10:  | 11:  | 12:  |

**SCPI.DISPlay.UPDate\_.IMMEDIATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Updates the display once, when the display update is set to OFF (SCPI.DISPLAY.ENABLE property is set to <i>False</i> ). |
| <i>Syntax</i>              | app.SCPI.DISPlay.UPDate_.IMMEDIATE  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DISPlay.WINDOW(*Ch*).ACTivate**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Sets the active channel.  |
| <i>Notes</i>               | The channel window must be displayed. At attempt to set to the active channel the channel, which is not displayed, an error occurs. |
| <i>Syntax</i>              | app.SCPI.DISPlay.WINDOW( <i>Ch</i> ).ACTivate   |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Active Channel</b>   |

SCPI.DISPlay.WINDOW(*Ch*).ANNAnnotation.MARKer.ALIGn.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The alignment mode of the marker display position of each trace, when the only active trace display feature is turned OFF (SCPI.DISPlay.WINDOW( <i>Ch</i> ).ANNAnnotation.MARKer.SINGLe.STATE property is set to <i>False</i> ).                     |
| <i>Range</i>               | "VERTical" Vertical alignment<br>"HORIZONTAL" Horizontal alignment<br>"NONE" No alignment  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "NONE"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.DISPlay.WINDOW(Ch).ANNAnnotation.MARKer. ALIGn.TYPE app.SCPI.DISPlay.WINDOW(Ch).ANNAnnotation.MARKer. ALIGn.TYPE = "VERT"</pre>  |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Properties &gt; Align &gt; Vertical   Horizontal   OFF</b>  |

**SCPI.DISPlay.WINDoW(*Ch*).ANNotation.MARKer.SINGLe.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the marker display for the active trace only.  |
| <i>Allowable Values</i>    | <i>True</i> Only active trace markers display ON<br><i>False</i> Only active trace markers display OFF   |
| <i>Preset Value</i>        | True   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI SCPI.DISPlay.WINDoW(<i>Ch</i>).ANNotation.MARKer.SINGLe. STATE app.SCPI SCPI.DISPlay.WINDoW(<i>Ch</i>).ANNotation.MARKer.SINGLe. STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Marker &gt; Properties &gt; Active Only</b>   |

SCPI.DISPlay.WINDOW(*Ch*).MAXimize

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | Active Trace of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                                       |
| <i>Description</i>         | The ON/OFF maximize state of the active trace for channel window.   |
| <i>Allowable Values</i>    | <i>True</i> Maximize active trace state ON<br><i>False</i> Maximize active trace state OFF                          |
| <i>Preset Value</i>        | <i>False</i>  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.DISPlay.WINDOW(1).MAXimize<br>app.SCPI.DISPlay.WINDOW(1).MAXimize = True |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Trace Allocation &gt; Maximize Trace</b>  |

## SCPI.DISPlay.WINDOW(Ch).SPLit

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number and layout of the trace on the channel window. The trace layout is in Table 6 below.            |
| <i>Range</i>               | From 1 to 6<br>From 1 to 12 (in N-port mode only)  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.                                       |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.DISPlay.WINDOW(1).SPLit<br>app. app.SCPI.DISPlay.WINDOW(1).SPLit = 2 |
| <i>Equivalent Softkeys</i> | <b>Trace &gt; Trace Allocation</b>   |

Table 6.

## Trace Layout on the Channel Window

|    |    |    |
|----|----|----|
| 1: | 2: | 3: |
| 4: | 5: | 6: |

## Trace Layout on the Channel Window (in N-port mode only)

|     |     |     |
|-----|-----|-----|
| 1:  | 2:  | 3:  |
| 4:  | 5:  | 6:  |
| 7:  | 8:  | 9:  |
| 10: | 11: | 12: |

SCPI.DISPlay.WINDOW(*Ch*).TITLE.DATA

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The channel title label.  |
| <i>Range</i>               | up to 254 characters  |
| <i>Preset Value</i>        | ""  |
| <i>Syntax</i>              | <pre>Dim Text As String Text = app.SCPI.DISPlay.WINDOW(Ch).TITLE.DATA app.SCPI.DISPlay.WINDOW(Ch).TITLE.DATA = "Example1"</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.DISPlay.WINDoW(*Ch*).TITLE.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the title label display.   |
| <i>Allowable Values</i>    | <i>True</i> Title label display ON<br><i>False</i> Title label display OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.DISPlay.WINDoW( <i>Ch</i> ).TITLE.STATE<br>app.SCPI.DISPlay.WINDoW( <i>Ch</i> ).TITLE.STATE = <i>True</i> |
| <i>Equivalent Softkeys</i> | <b>Display &gt; Caption</b>  |

**SCPI.DISPlay.WINDoW(*Ch*).TRACe(*Tr*).ANNotation.MARKer.MEMory**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)   |
| <i>Description</i>         | Turns ON/OFF the state of the memory value display on the marker.  |
| <i>Parameter</i>           | True Memory value display ON<br>False Memory value display OFF   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.DISPlay.WINDoW(<i>Ch</i>).TRACe(<i>Tr</i>).ANNotation. MARKer. MEMory app.SCPI.DISPlay.WINDoW(<i>Ch</i>).TRACe(<i>Tr</i>).ANNotation. MARKer. MEMory = true</pre> |
| <i>Equivalent Softkeys</i> | <b>Markers &gt; Properties &gt; Memory Value</b>   |

SCPI.DISPlay.WINDOW(*Ch*).TRACe(*Tr*).ANNotation.MARKer.POSition.X

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)  |
| <i>Description</i>         | The display position of the marker value on the X-axis by a percentage of the display width.  |
| <i>Range</i>               | from 0 to 100   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | %   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).ANNotation. MARKer.POSition.X app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).ANNotation. MARKer.POSition.X = 50</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.DISPlay.WINDoW(*Ch*).TRACe(*Tr*).ANNotatIon.MARKer.POSition.Y

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)  |
| <i>Description</i>         | The display position of the marker value on the Y-axis by a percentage of the display height.   |
| <i>Range</i>               | from 0 to 100   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | %   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.DISPlay.WINDoW(Ch).TRACe(Tr).ANNotatIon. MARKer.POSition.Y app.SCPI.DISPlay.WINDoW(Ch).TRACe(Tr).ANNotatIon. MARKer.POSition.Y = 50</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.DISPlay.WINDoW(*Ch*).TRACe(*Tr*).Y.SCALE.AUTO

| <i>Object Type</i>         | Method   |
|----------------------------|--|
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3) |
| <i>Description</i>         | Executes the auto scale function for the trace.  |
| <i>Syntax</i>              | app.SCPI.DISPlay.WINDoW( <i>Ch</i> ).TRACe( <i>Tr</i> ).Y.SCALE.AUTO   |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Auto Scale</b>   |

SCPI.DISPlay.WINDOW(*Ch*).TRACe(*Tr*).Y.SCALE.PDIVision

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)  |
| <i>Description</i>         | The trace scale. Sets the scale per division, when the data format is the rectangular format. Sets the full scale value, when the data format is the Smith chart format or the polar format.                                    |
| <i>Range</i>               | from 10E-18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | Varies depending on the format.<br><br>Logarithmic Magnitude: 10 dB/Div<br><br>Phase: 40 °/Div<br><br>Expand Phase: 100 °/Div<br><br>Group Delay: 10e-9 s/Div<br><br>Smith Chart, SWR: 1 /Div<br><br>Linear Magnitude: 0.1 /Div |
| <i>Unit</i>                | dB/Div (decibel per division), °/Div (degree per division), s/Div (second per division)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. PDIVision app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. PDIVision = 20</pre>   |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Scale</b>   |

SCPI.DISPlay.WINDOW(*Ch*).TRACe(*Tr*).Y.SCALE.RLEVel

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)                                |
| <i>Description</i>         | The value of the reference line (response value on the reference line). For the rectangular format only.  |
| <i>Range</i>               | from -1E-18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0 (except for SWR: 1)   |
| <i>Unit</i>                | dB (decibel)   ° (degree)   s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. RLEVel app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. RLEVel = 10</pre> |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Ref Value</b>   |

SCPI.DISPlay.WINDOW(*Ch*).TRACe(*Tr*).Y.SCALE.RPOSITION

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Trace <i>Tr</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Tr</i> trace number (see Table 3)                                    |
| <i>Description</i>         | The position of the reference line. For the rectangular format only.  |
| <i>Range</i>               | From 0 to the number of the scale divisions (set by the SCPI.DISPlay.WINDOW( <i>Ch</i> ).Y.SCALE.DIVisions property, 10 by default).                        |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 5 (except for SWR: 0)   |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. RPOSITION app.SCPI.DISPlay.WINDOW(Ch).TRACe(Tr).Y.SCALE. RPOSITION = 10</pre> |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Ref Position</b>  |

SCPI.DISPlay.WINDOW(*Ch*).Y.SCALE.DIVisions

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1).  |
| <i>Description</i>         | The number of the vertical scale divisions. For the rectangular format only.  |
| <i>Range</i>               | from 4 to 20  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 10  |
| <i>Resolution</i>          | 2   |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.DISPlay.WINDOW(Ch).Y.SCALE.DIVisions app.SCPI.DISPlay.WINDOW(Ch).Y.SCALE.DIVisions = 12</pre> |
| <i>Equivalent Softkeys</i> | <b>Scale &gt; Divisions</b>   |

**SCPI.HCOPy.DATE.STAMP**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The ON/OFF state of the current date and time printout in the upper right corner.                        |
| <i>Allowable Values</i>    | <p><i>True</i>      Date &amp; time printout ON</p> <p><i>False</i>     Date &amp; time printout OFF</p> |
| <i>Preset Value</i>        | True   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.HCOPy.DATE.STAMP app.SCPI.HCOPy.DATE.STAMP = False</pre>    |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.HCOPy.IMAGe

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The inverted color image printout.   |
| <i>Range</i>               | "NORMAl"     Normal printout<br>"INVert"     Inverted color printout   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "NORM"   |
| <i>Syntax</i>              | Dim Param As String<br>Param = app.SCPI.HCOPy.IMAGe<br>app.SCPI.HCOPy.IMAGe = "INV"  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.HCOPy.IMMediate

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Prints out the image displayed on the screen without previewing. |
| <i>Syntax</i>              | app.SCPI.HCOPy.IMMediate   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.HCOPy.PAINT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The color chart for the image printout.  |
| <i>Range</i>               | "COLor" Color printout<br>"GRAY" Grayscale printout<br>"BW" Black&white printout   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "BW"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.HCOPy.PAINT app.SCPI.HCOPy.PAINT = "COL"</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.IEEE4882.CLS

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Status Reporting System   |
| <i>Description</i>         | <p>Clears the following:</p> <ul style="list-style-type: none"> <li>• Error Queue</li> <li>• Status Byte Register</li> <li>• Standard Event Status Register</li> <li>• Operation Status Event Register</li> <li>• Questionable Status Event Register</li> <li>• Questionable Limit Status Event Register</li> <li>• Questionable Limit Channel Status Event Register</li> </ul> |
| <i>Syntax</i>              | app.SCPI.IEEE4882.CLS   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.IEEE4882.IDN**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The instrument information string. The string format: "{manufacturer}, {model}, {serial number}, {software version/firmware version}". |
| <i>Range</i>               | up to 40 characters  |
| <i>Syntax</i>              | Dim ID As String<br>ID = app.SCPI.IEEE4882.IDN   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.IEEE4882.RST**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Restores the default settings of the instrument. There is difference from presetting the instrument with the SCPI.SYSTem.PRESet method – in this case the trigger mode is set to <i>Hold</i> . |
| <i>Syntax</i>              | app.SCPI.IEEE4882.RST  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.IEEE4882.TRG**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | If the trigger source is set to LAN<br>(SCPI.TRIGger.SEQuence.SOURce property is set to "BUS"), triggers a sweep.<br>If the trigger source is not set to the bus (SCPI.TRIGger.SEQuence.SOURce property is not set to "BUS") or the instrument is not waiting for a trigger, the method is ignored. |
| <i>Syntax</i>              | app.SCPI.IEEE4882.TRG   |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce<br>SCPI.INITiate(Ch).CONTinuous<br>SCPI.INITiate(Ch).IMMEDIATE   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.IEEE4882.WAI**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Waits for the execution of all commands sent before this command. |
| <i>Syntax</i>              | app.SCPI.IEEE4882.WAI   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.INITiate(*Ch*).CONTinuous

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the continuous trigger initiation mode. If the continuous trigger initiation mode is set to OFF, the channel turns to the <i>hold</i> state.   |
| <i>Allowable Values</i>    | <i>True</i> Continuous trigger initiation mode ON<br><i>False</i> Continuous trigger initiation mode OFF   |
| <i>Preset Value</i>        | True   |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.INITiate( <i>Ch</i> ).CONTinuous<br>app.SCPI.INITiate( <i>Ch</i> ).CONTinuous = <i>False</i>  |
| <i>Notes</i>               | The sweep start in continuous trigger initiation mode depends on the trigger source. If the trigger is set to internal, the sweeps will go immediately one after another. If the trigger is set otherwise, the sweep will start when the trigger signal is received. |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Mode &gt; Continuous   Single   Hold</b>   |

**SCPI.INITiate(*Ch*).IMMEDIATE**

| <i>Object Type</i>         | Method  |
|----------------------------|---|
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Sets the channel to the single trigger mode. Before this method is called, the channel must be in hold state, otherwise an error occurs (error code 213) and the method is ignored.<br>On completion of the sweep, the channel goes back into the <i>hold</i> state.<br>The method returns control before the end of the sweep. |
| <i>Syntax</i>              | app.SCPI.INITiate( <i>Ch</i> ).IMMEDIATE  |
| <i>Notes</i>               | The sweep start in the single trigger mode depends on the trigger source. If the trigger is set to internal, the sweep will start immediately after the method is called. If the trigger is set otherwise, the sweep will start when the trigger signal is received.  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Mode &gt; Single</b>  |

**SCPI.MMEMORY.COPY(*Src, Dst*)**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Copies a file.  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.COPY( <i>Src, Dst</i> )  |
| <i>Parameter</i>           | <i>Src</i> – Source file name. String data type.<br><i>Dst</i> – Destination file name. String data type. |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.MMEMORY.DELETE(*File*)**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method                                     |
| <i>Target</i>              | Instrument                                 |
| <i>Description</i>         | Deletes a file.                            |
| <i>Syntax</i>              | app.SCPI.MMEMORY.DELETE( <i>File</i> )     |
| <i>Parameter</i>           | <i>File</i> – File name. String data type. |
| <i>Equivalent Softkeys</i> | <b>None</b>                                |

**SCPI.MMEMORY.LOAD.CHANNEL.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data type</i>           | String  |
| <i>Target</i>              | Active channel  |
| <i>Description</i>         | Recalls the analyzer state for the active channel, saved in one of the four memory registers by the SCPI.MMEMORY.STORE.CHANNEL.STATE property |
| <i>Range</i>               | "A" Recall from register A<br>"B" Recall from register B<br>"C" Recall from register C<br>"D" Recall from register D                          |
| <i>Out of range</i>        | The value is ignored.   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.CHANNEL.STATE = "A"   |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Recall Channel &gt; State A   State B   State C   State D</b>  |

**SCPI.MMEMORY.LOAD.CKIT(Ck)**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Calibration kit Ck,<br>Ck calibration kit number see Table 7)  |
| <i>Description</i>         | Recalls the definition file for the calibration kit. The file must be saved by the SCPI.MMEMORY.STORE.CKIT(Ck) property.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.CKIT(Ck) = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the \CalKit subdirectory of the main directory will be searched for the file. The calibration kit definition file has *.ckd extension by default. |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

Table 7. Ck: Calibration Kit Number

|                     |  |
|---------------------|--|
| <i>Data Type</i>    | Long   |
| <i>Description</i>  | Calibration kit number.  |
| <i>Range</i>        | from 1 to 50   |
| <i>Out of Range</i> | An error occurs. Error code: 114.  |
| <i>Notes</i>        | If the calibration kit number is not specified, it is taken as equal to 1. |

**SCPI.MMEMORY.LOAD.CALibration**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | User calibration of the active channel.  |
| <i>Description</i>         | Recalls the specified calibration file. The file must be saved by the SCPI.MMEMORY.STORE.CALibration property.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.CALibration = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the \State subdirectory of the main directory will be searched for the file. The calibration files have *.cal extension by default. |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Recall Calibration</b>   |

**SCPI.MMEMORY.LOAD.LIMIT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active trace of the active channel.  |
| <i>Description</i>         | Recalls the specified limit table file. The file must be saved by the SCPI.MMEMORY.STORE.LIMIT property.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.LIMIT = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the \Limit subdirectory of the main directory will be searched for the file. The limit table files have *.lim extension by default. |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Edit Limit Line &gt; Restore Limit Table</b>  |

**SCPI.MMEMORY.LOAD.RLIMIT**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Active trace of the active channel.   |
| <i>Description</i>         | Recalls the ripple limit table file. The file must be saved by the SCPI.MMEMORY.STORE.RLIMIT property.  |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.RLIMIT = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the \Limit subdirectory of the main directory will be searched for the file. The ripple limit files have *.rlm extension by default. |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Ripple Test &gt; Edit Ripple Limit &gt; Restore Ripple Table</b>   |

**SCPI.MMEMORY.LOAD.SEGMENT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active channel   |
| <i>Description</i>         | Recalls the segment table file. The file must be saved by the SCPI.MMEMORY.STORE.SEGMENT property.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.SEGMENT = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the \Segment subdirectory of the main directory will be searched for the file. The segment files have *.seg extension by default. |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Segment Table &gt; Recall</b>   |

## SCPI.MMEMORY.LOAD.SNP.DATA

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Active channel  |
| <i>Description</i>         | Loads the Touchstone file with the specified name to the measured S-parameters of the active channel. The Touchstone file types *.s1p (1-port) and *.s2p (2-port) are supported. *.s1p file loads the S11 parameter only.<br>*.s2p file loads all S11, S21, S12 and S22 parameters. On completion of the command, the channel goes to the hold state. |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.SNP.DATA = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the \Segment subdirectory of the main directory will be searched for the file. The segment files have *.seg extension by default.  |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Recall Touchstone &gt; Recall To S-Parameters</b>   |

**SCPI.MMEMORY.LOAD.SNP.TRACe(Tr).MEMORY**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | The specified memory trace <i>Tr</i> of active channel<br><i>Tr</i> trace number (see Table 3)<br>Active channel set by command<br>SCPI.DISPlay.WINdow(Ch).ACTivate  |
| <i>Description</i>         | Loads the Touchstone file with the specified name to the memory trace.<br>The Touchstone file types *.s1p (1-port) and *.s2p (2-port) are supported.<br>The current measured S-parameter of data trace selects the appropriate S-parameter from Touchstone file. After successful load the display of memory trace is automatically switched on. |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.SNP.TRACe(Tr).MEMORY = File  |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Recall Touchstone &gt; Recall To Active Trace Memory</b>   |

**SCPI.MMEMORY.LOAD.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Recalls the specified instrument state file. The file must be saved by the SCPI.MMEMORY.STORE.STATE property.   |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.LOAD.STATE = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the \State subdirectory of the main directory will be searched for the file. The instrument state files have *.cfg extension by default. |
| <i>Equivalent Softkeys</i> | <b>Files &gt; State &gt; Recall State</b>   |

## SCPI.MMEMORY.MDIRECTORY

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Creates a new directory (folder). Contains the full path to the folder being created. |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.MDIRECTORY = Path  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.MMEMORY.STORE.CHANNEL.CLEAR

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Analyzer   |
| <i>Description</i>         | Clears the memory of the channel state saved by the SCPI.MMEMORY.STORE.CHANNEL.STATE property. |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.CHANNEL.CLEAR   |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Save Channel &gt; Clear States</b>  |

**SCPI.MMEMORY.STORE.CHANNEL.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Active channel  |
| <i>Description</i>         | Saves the analyzer state of the items set for the active channel into one of the four memory registers. |
| <i>Range</i>               | "A" Save to register A<br>"B" Save to register B<br>"C" Save to register C<br>"D" Save to register D    |
| <i>Out of range</i>        | The value is ignored.   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.CHANNEL.STATE = "A"  |
| <i>Equivalent Softkeys</i> | <b>Channels &gt; Save Channel &gt; State A   State B   State C   State D</b>                            |

## SCPI.MMEMORY.STORE.CKIT(Ck)

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Calibration kit Ck,<br>Ck calibration kit number (see Table 7)   |
| <i>Description</i>         | Saves the definition file for the calibration kit parameters.  |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.CKIT(Ck) = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \CalKit subdirectory of the main directory. The calibration kit definition file has *.dat extension by default. |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.MMEMORY.STORE.CALibration**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | User calibration of the active channel.  |
| <i>Description</i>         | Save the specified calibration file. The file must be recalled by the SCPI.MMEMORY.LOAD.CALibration property.  |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.CALibration = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the \State subdirectory of the main directory will be searched for the file. The calibration files have *.cal extension by default. |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Save Calibration</b>   |

**SCPI.MMEMORY.STORE.FDATA**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active trace of the active channel   |
| <i>Description</i>         | Saves the CSV formatted data into a file.  |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.FDATA = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \CSV subdirectory of the main directory. The files have *.csv extension by default. |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Save Trace Data</b>  |

**SCPI.MMEMORY.STORE.IMAGE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Saves the display image in BMP or PNG format into a file.   |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.IMAGE = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \Image subdirectory of the main directory. If the file has *.png extension, the file has PNG format, in all the other cases the file has BMP format. |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.MMEMORY.STORE.LIMIT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active trace of the active channel   |
| <i>Description</i>         | Saves the limit table into a file with the specified name.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.LIMIT = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \Limit subdirectory of the main directory. The files have *.lim extension by default. |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Limit Test &gt; Edit Limit Line &gt; Save Limit Table</b>   |

**SCPI.MMEMORY.STORE.RLIMit**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Active trace of the active channel  |
| <i>Description</i>         | Saves the ripple limit table into a file with the specified name.   |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.RLIMit = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \Limit subdirectory of the main directory. The ripple limit files have *.rlm extension by default. |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Ripple Test &gt; Edit Ripple Limit &gt; Save Ripple Table</b>  |

**SCPI.MMEMORY.STORESEGMENT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active channel   |
| <i>Description</i>         | Saves the segment table in a file with the specified name.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORESEGMENT = File   |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \Segment subdirectory of the main directory. The segment files have *.seg extension by default. |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Segment Table &gt; Save</b>   |

**SCPI.MMEMORY.STORE.SNP.DATA**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Active channel  |
| <i>Description</i>         | Saves the measured S-parameters of the active channel into a Touchstone file with the specified name. The 1-port type file saves one reflection parameter: S11.                 |
| <i>Range</i>               | up to 254 characters  |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.SNP.DATA = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \FixtureSim subdirectory of the main directory. The 1-port measurement files have *.slp extension. |
| <i>Equivalent Softkeys</i> | <b>Files &gt;Save Touchstone</b>  |

## SCPI.MMEMORY.STORE.SNP.FORMAT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Active channel   |
| <i>Description</i>         | The data format for the S-parameters saving by the SCPI.MMEMORY.STORE.SNP.DATA property.   |
| <i>Range</i>               | " MA"      Logarithmic Magnitude / Angle format<br>" DB"      Linear Magnitude / Angle format<br>" RI"      Real part /Imaginary part format |
| <i>Out of Range</i>        | The value is ignored.  |
| <i>Preset Value</i>        | "RI"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.MMEMORY.STORE.SNP.FORMAT app.SCPI.MMEMORY.STORE.SNP.FORMAT = "DB"</pre>                            |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Save Touchstone &gt; Touchstone Format &gt; Real-Imaginary   Magnitude-Angle   dB-Angle</b>                                    |

## SCPI.MMEMORY.STORE.SNP.TYPE.S1P

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Active channel   |
| <i>Description</i>         | Selects 1-port measurements and sets port numbers (selects S11 parameter) when saving the measured S-parameters by the SCPI.MMEMORY.STORE.SNP.DATA property. |
| <i>Range</i>               | From 1 to 2  |
| <i>Out of Range</i>        | An error occurs.   |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.MMEMORY.STORE.SNP.TYPE.S1P<br>app.SCPI.MMEMORY.STORE.SNP.TYPE.S1P = 1  |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Save Touchstone &gt; Type</b>  |

**SCPI.MMEMORY.STORE.SNP.TYPE.S2P**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Variant (Long array)  |
| <i>Target</i>              | Active channel  |
| <i>Description</i>         | Selects 2-port measurements and sets port numbers when saving the measured S-parameters by the SCPI.MMEMORY.STORE.SNP.DATA property.<br>The array contains 2 elements:<br>Data(0) First port number (only 1, ignored when written);<br>Data(1) Second port number (only 1, ignored when written). |
| <i>Syntax</i>              | Dim Data As Variant<br>Data = app.SCPI.MMEMORY.STORE.SNP.TYPE.S2P<br>app.SCPI.MMEMORY.STORE.SNP.TYPE.S2P = Array(1, 2)  |
| <i>Equivalent Softkeys</i> | <b>Files &gt; Save Touchstone &gt; Type</b>   |

**SCPI.MMEMORY.STORE.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Saves the instrument state into a file with the specified name.  |
| <i>Range</i>               | up to 254 characters   |
| <i>Syntax</i>              | app.SCPI.MMEMORY.STORE.STATE = File  |
| <i>Notes</i>               | If the full path to the file is not specified, the file will be saved to the \State subdirectory of the main directory. The state files have *.cfg extension by default. |
| <i>Equivalent Softkeys</i> | <b>Files &gt; State &gt; Save State</b>  |

**SCPI.MMEMORY.STORE.STYPE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Selects the type of the instrument or channel state saving by the SCPI.MMEMORY.STORE.STATE or SCPI.MMEMORY.STORE.CHANNEL.STATE property.   |
| <i>Range</i>               | "STATE" Measurement conditions<br>"CST" Measurement conditions and calibration tables<br>"DST" Measurement conditions and trace data<br>"CDST" Measurement conditions, trace data and calibration tables   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs. Error code 205.   |
| <i>Preset Value</i>        | "CST"  |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.MMEMORY.STORE.STYPE app.SCPI.MMEMORY.STORE.STYPE = "STATE"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Files &gt; State &gt; Save Type &gt; State   State and Cal   State and Trace   All</b>  |

**SCPI.OUTPUT.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Sets the ON/OFF state of the stimulus signal output.   |
| <i>Allowable Values</i>    | <p><i>True</i>      Stimulus signal output ON</p> <p><i>False</i>     Stimulus signal output OFF</p> |
| <i>Preset Value</i>        | True   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.OUTPUT.STATE app.SCPI.OUTPUT.STATE = False</pre>        |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Power &gt; RF Out</b>   |

**SCPI.SENSE(*Ch*).AVERage.CLEar**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)         |
| <i>Description</i>         | Resets the averaging data count to 0. Restarts the averaging process. |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).AVERage.CLEar                             |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).AVERage.COUNT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The averaging factor, when the averaging function is set to ON by the SCPI.SENSE(Ch).AVERage.STATE property. |
| <i>Range</i>               | from 1 to 999  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 10   |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.SENSE(Ch).AVERage.COUNT app.SCPI.SENSE(Ch).AVERage.COUNT = 2</pre>   |
| <i>Equivalent Softkeys</i> | <b>Average &gt; Averaging Factor</b>   |

**SCPI.SENSE(Ch).AVERage.CURRent**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)    |
| <i>Description</i>         | Current averaging step.  |
| <i>Range</i>               | from 1 to Averaging Factor                                       |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.SENSE(Ch) .AVERage.CURRent |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SENSE(Ch).AVERage.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the averaging function.  |
| <i>Allowable Values</i>    | <i>True</i> Averaging ON<br><i>False</i> Averaging OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.SENSE(Ch) .AVERage.STATE<br>app.SCPI.SENSE(Ch) .AVERage.STATE = False |
| <i>Equivalent Softkeys</i> | <b>Average&gt; Averaging</b>   |

SCPI.SENSe(*Ch*).BANDwidth.RESolution

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The IF bandwidth value.  |
| <i>Range</i>               | from 100 to 30000  |
| <i>Resolution</i>          | In steps of 3. (100, 300, 1000, 3000, 10000, 30000)  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 10000  |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSe(Ch).BANDwidth.RESolution app.SCPI.SENSe(Ch).BANDwidth.RESolution = 100</pre> |
| <i>Equivalent Softkeys</i> | <b>Average &gt; IFBW</b>   |

**SCPI.SENSE(*Ch*).CORRection.CLEar**

| <i>Object Type</i>         | Method  |
|----------------------------|---|
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | Clears the calibration coefficient table.                     |
| <i>Syntax</i>              | <i>app</i> .SCPI.SENSE( <i>Ch</i> ).CORRection.CLEar          |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).CORRection.COEFFicient.DATA(Str, Pt\_r, Pt\_s)

|                            |  |      |              |      |                     |      |             |      |            |      |                       |      |           |
|----------------------------|--|------|--------------|------|---------------------|------|-------------|------|------------|------|-----------------------|------|-----------|
| <i>Object Type</i>         | Property (read/write)  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Data Type</i>           | Variant (Double array)   |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Description</i>         | <p>The calibration coefficient data array set by the type of the corrected error <i>Str</i>, the number of the receiver port <i>Pt_r</i> and the number of the source port <i>Pt_s</i>,</p> <p style="padding-left: 40px;"><i>Str</i> error type (see below)</p> <p style="padding-left: 40px;"><i>Pt_r</i> the number of the receiver port (see Table 2)</p> <p style="padding-left: 40px;"><i>Pt_s</i> the number of the source port (see Table 2)</p> <p>The array size is 2N, where N is the number of measurement points. For the n-th point, where n from 1 to N:</p> <p style="padding-left: 40px;">Data(2n-2) real part of the calibration coefficients</p> <p style="padding-left: 40px;">Data(2n-1) imaginary part of the calibration coefficients</p> |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Parameter</i>           | <p>String <i>Str</i> – corrected error type:</p> <table style="margin-left: 40px;"> <tr><td>"ES"</td><td>Source match</td></tr> <tr><td>"ER"</td><td>Reflection tracking</td></tr> <tr><td>"ED"</td><td>Directivity</td></tr> <tr><td>"EL"</td><td>Load match</td></tr> <tr><td>"ET"</td><td>Transmission tracking</td></tr> <tr><td>"EX"</td><td>Isolation</td></tr> </table> <p>When ES, ER, or ED is used, the numbers of the ports <i>Pt_r</i> and <i>Pt_s</i> must be the same. When EL, ET, or EX is used, the numbers of the ports <i>Pt_r</i> and <i>Pt_s</i> must be different.</p>   | "ES" | Source match | "ER" | Reflection tracking | "ED" | Directivity | "EL" | Load match | "ET" | Transmission tracking | "EX" | Isolation |
| "ES"                       | Source match   |      |              |      |                     |      |             |      |            |      |                       |      |           |
| "ER"                       | Reflection tracking  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| "ED"                       | Directivity  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| "EL"                       | Load match   |      |              |      |                     |      |             |      |            |      |                       |      |           |
| "ET"                       | Transmission tracking  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| "EX"                       | Isolation  |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SENSE(Ch).CORRection.COEFFicient.DATA (Str, Pt_r, Pt_s) app.SCPI.SENSE(Ch).CORRection.COEFFicient.DATA (Str, Pt_r, Pt_s) = Data</pre>   |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Notes</i>               | The written calibration coefficients become effective only after the SCPI.SENSE(Ch).CORRection.COEFFicient.SAVE method is invoked.   |      |              |      |                     |      |             |      |            |      |                       |      |           |
| <i>Equivalent Softkeys</i> | <b>None</b>  |      |              |      |                     |      |             |      |            |      |                       |      |           |

## SCPI.SENSE(Ch).CORRection.COEfficient.METHOD.RESPonse.OPEN

|                            |  |
|----------------------------|--|
| <i>Description</i>         | Selects the port and sets the response calibration (Open) type, when the written calibration coefficients are made effective by the SCPI.SENSE(Ch).CORRection.COEfficient.SAVE method. |
| <i>Type</i>                | Long (write only)  |
| <i>Range</i>               | Port number (see Table 2)  |
| <i>Out of Range</i>        | An error occurs. Error code: 222.  |
| <i>Target</i>              | Channel Ch from 1 to 4<br>Channel Ch from 1 to 16 (in N-port mode only)  |
| <i>Syntax</i>              | Port = 1<br>app.SCPI.SENSE(Ch).CORRection.COEfficient.METHOD.RESPonse.OPEN = Port  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SENSE(Ch).CORRection.COEfficient.METHOD.RESPonse.SHORT

|                            |   |
|----------------------------|---|
| <i>Description</i>         | Selects the port and sets the response calibration (Short) type, when the written calibration coefficients are made effective by the SCPI.SENSE(Ch).CORRection.COEfficient.SAVE method. |
| <i>Type</i>                | Long (write only)   |
| <i>Range</i>               | Port number (see Table 2)   |
| <i>Out of Range</i>        | An error occurs. Error code: 222.   |
| <i>Target</i>              | Channel Ch from 1 to 4<br>Channel Ch from 1 to 16 (in N-port mode only)   |
| <i>Syntax</i>              | Port = 1<br>app.SCPI.SENSE(Ch).CORRection.COEfficient.METHOD.RESPonse.SHORT = Port  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).CORRection.COEFficient.METHOD.SOLT1

|                            |  |
|----------------------------|--|
| <i>Description</i>         | Selects the port and sets the full 1-port calibration type, when the written calibration coefficients are made effective by the SCPI.SENSE(Ch).CORRection.COEFficient.SAVE method. |
| <i>Type</i>                | Long (write only)  |
| <i>Range</i>               | Port number (see Table 2)  |
| <i>Out of Range</i>        | An error occurs. Error code: 222.  |
| <i>Target</i>              | Channel Ch from 1 to 4<br>Channel Ch from 1 to 16 (in N-port mode only)  |
| <i>Syntax</i>              | Port = 1<br>app.SCPI.SENSE(Ch).CORRection.COEFficient.METHOD.SOLT1 = Port  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SENSE(Ch).CORRection.COEFFicient.SAVE

|                            |  |
|----------------------------|--|
| <i>Description</i>         | Enables the written calibration coefficients depending on the selected calibration type.<br><br>On completion of the method the written calibration coefficients are cleared, the error correction automatically turns ON.<br><br>At the attempt to execute this method before all the needed calibration coefficients are written, an error occurs and the method is ignored. |
| <i>Type</i>                | Method   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COEFFicient.SAVE   |
| <i>Related Commands</i>    | Calibration type selection:<br>SCPI.SENSE(Ch).CORRection.COEFFicient.METHOD.<br>RESPonse. OPEN<br>SCPI.SENSE(Ch).CORRection.COEFFicient.METHOD.<br>RESPonse. SHORT<br>SCPI.SENSE(Ch).CORRection.COEFFicient.METHOD.SOLT1<br><br>Calibration coefficient writing:<br>SCPI.SENSE(Ch).CORRection.COEFFicient.DATA (Str,<br>Pt_r, Pt_s)  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.ACQuire.LOAD

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Measures the calibration data of the <i>load</i> standard for the specified port.  |
| <i>Range</i>               | Port number is 1,<br>1-16 (in N-port mode only).   |
| <i>Out of Range</i>        | An error occurs.   |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COLLect.ACQuire.LOAD<br>= Port   |
| <i>Notes</i>               | The property writing starts the measurement for the channel independently of the trigger initiation and trigger source settings. The function of the property writing waits for the completion of the measurement. |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Load</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.ACQuire.OPEN

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Measures the calibration data of the <i>open</i> standard for the specified port.  |
| <i>Range</i>               | Port number is 1,<br>1-16 (in N-port mode only).   |
| <i>Out of Range</i>        | An error occurs  |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ACQuire.OPEN=Port   |
| <i>Notes</i>               | The property writing starts the measurement for the channel independently of the trigger initiation and trigger source settings. The function of the property writing waits for the completion of the measurement. |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Open</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.ACQuire.SHORT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Measures the calibration data of the <i>short</i> standard for the specified port.   |
| <i>Range</i>               | Port number is 1,<br>1-16 (in N-port mode only).   |
| <i>Out of Range</i>        | An error occurs.   |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ACQuire.SHORT<br>= Port   |
| <i>Notes</i>               | The property writing starts the measurement for the channel independently of the trigger initiation and trigger source settings. The function of the property writing waits for the completion of the measurement. |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Short</b>  |

## SCPI.SENSE(Ch).CORRection.COLLect.ACQuire.THRU

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Variant  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number 1–16 (in N-port mode only)   |
| <i>Description</i>         | <p>Measures the calibration data of the thru standard between the source port and the receiver port.<br/>(in N-port mode only)</p> <p>The array contains 2 elements:</p> <p>Data(0) the number of the receiver port;</p> <p>Data(1) the number of the source port.</p> |
| <i>Range</i>               | Port numbers is 1-16.  |
| <i>Out of Range</i>        | An error occurs.   |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COLLect.ACQuire.THRU = Array(Rcv, Src)   |
| <i>Notes</i>               | The property writing starts the measurement for the channel independently of the trigger initiation and trigger source settings. The function of the property writing waits for the completion of the measurement.   |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Thru</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.LABel

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Calibration kit, selected for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The calibration kit label.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Preset Value</i>        | <p>Varies depending on the number of the calibration kit.</p> <p>1: "Not defined 50 Ohm"<br/> 2: "Not defined 75 Ohm"<br/> 3: "05CK10A-150 -F-"<br/> 4: "05CK10A-150 -M-"<br/> 5: "N1.1 Type-N -F-"<br/> 6: "N1.1 Type-N -M-"<br/> 7: "Agilent 85032B -F-"<br/> 8: "Agilent 85032B -M-"<br/> 9: "Agilent 85036B -F-"<br/> 10: "Agilent 85036B -M-"<br/> 11: "Agilent 85032F -F-"<br/> 12: "Agilent 85032F -M-"<br/> 13: "N611 -F-"<br/> 14: "N612 -F-"<br/> 15: "Empty"<br/> 16: "Empty"</p> |
| <i>Syntax</i>              | <pre>Dim Lab As String Lab = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.LABel app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.LABel = "User1"</pre>   |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; Calibration Kit Name</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.RESet

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Calibration kit, selected for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | Resets the calibration kit to the factory settings.   |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.RESet  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; Restore</b>                      |

## SCPI.SENSE(Ch).CORRection.COLLect.CKIT.SElect

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The selected calibration kit for the channel.  |
| <i>Range</i>               | from 1 to 14   |
| <i>Out of Range</i>        | An error occurs. Error code: 222.  |
| <i>Preset Value</i>        | 1  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.SElect app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.SElect = 3</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit</b>  |

Table 8. *Std*: Calibration Standard Number

|                     |   |
|---------------------|---|
| <i>Data Type</i>    | Long  |
| <i>Description</i>  | The number of the standard.   |
| <i>Range</i>        | Varies depending on the number of the standards in the calibration kit.   |
| <i>Out of Range</i> | If the specified standard number is greater than the number of standards in the kit, an error occurs (error code: 222). |
| <i>Notes</i>        | If the standard number is not specified, it is taken as equal to 1.   |

SCPI.SENSe(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).C0

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The C0 value of the open calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-15 F (Farad)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSe(Ch).CORRection.COLLect.CKIT.STAN (Std).C0 app.SCPI.SENSe(Ch).CORRection.COLLect.CKIT.STAN (Std).C0 = 100</pre>     |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; C0 [10<sup>-15</sup> F]</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).C1

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The C1 value of the open calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-27 F/Hz (Farad/Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).C1 app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).C1 = 100</pre>     |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Edit Cal Kit &gt; Capacitance &gt; C1 [10<sup>-27</sup> F/Hz]</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).C2

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)           |
| <i>Description</i>         | The C2 value of the open calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-36 F/Hz <sup>2</sup> (Farad/Hertz <sup>2</sup> )  |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).C2<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).C2 = 100 |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; C2 [10<sup>-36</sup> F/Hz<sup>2</sup>]</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).C3

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)           |
| <i>Description</i>         | The C3 value of the open calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-45 F/Hz <sup>3</sup> (Farad/Hertz <sup>3</sup> )  |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).C3<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).C3 = 100 |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; C3 [10<sup>-45</sup> F/Hz<sup>3</sup>]</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).DElay

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)      |
| <i>Description</i>         | The offset delay value of the calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.  |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).DElay app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).DElay = 93E-12</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; Offset Delay</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).L0

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The L0 value of the short calibration standard.  |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-12 H (Henry)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L0 app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L0 = 100</pre>     |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; L0 [10<sup>-12</sup> H]</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).L1

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The L1 value of the short calibration standard.  |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-24 H/Hz (Henry/Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L1 app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L1 = 100</pre>     |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; L1 [10<sup>-24</sup> H/Hz]</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).L2

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The L2 value of the short calibration standard.  |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-33 H/Hz <sup>2</sup> (Henry/Hertz <sup>2</sup> )  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L2 app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN (Std).L2 = 100</pre>     |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; L2 [10<sup>-33</sup> H/Hz<sup>2</sup>]</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).L3

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)           |
| <i>Description</i>         | The L3 value of the short calibration standard.  |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | 1E-42 H/Hz <sup>3</sup> (Henry/Hertz <sup>3</sup> )  |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).L3<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).L3 = 100 |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; L3 [10<sup>-42</sup> H/Hz<sup>3</sup>]</b>  |

SCPI.SENSe(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).LABel

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The label of the calibration standard.   |
| <i>Range</i>               | up to 254 characters   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Syntax</i>              | <pre>Dim Lab As String Lab = app.SCPI.SENSe(Ch).CORRection.COLLect.CKIT.STAN (Std).LABel</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).LOSS

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)                 |
| <i>Description</i>         | The offset loss value of the calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | Varies depending on the selected calibration kit and the standard.   |
| <i>Unit</i>                | $\Omega/\text{s}$ (Ohm/second)   |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).LOSS<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN( <i>Std</i> ).LOSS = 700E6 |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; Offset Loss</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.CKIT.STAN(*Std*).TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8)   |
| <i>Description</i>         | The type of the calibration standard.  |
| <i>Range</i>               | "OPEN" Open<br>"SHORT" Short<br>"LOAD" Load<br>"THRU" Thru   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN(Std).TYPE  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN(Std).Z0

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Standard <i>Std</i> of the calibration kit specified for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Std</i> standard number (see Table 8) |
| <i>Description</i>         | The offset Z0 value of the calibration standard.   |
| <i>Range</i>               | from -1E18 to 1E18   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 50 or 75, depending on the selected calibration kit.   |
| <i>Unit</i>                | Ω (Ohm)  |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN(Std).<br>Z0<br>app.SCPI.SENSE(Ch).CORRection.COLLect.CKIT.STAN(Std).<br>Z0 = 50  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Kit &gt; Edit Cal Kit &gt; Offset Z0</b>   |

**SCPI.SENSe(*Ch*).CORRection.COLLect.CLEAR**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Description</i>         | Clears the measurement values of the calibration standards.   |
| <i>Syntax</i>              | app.SCPI.SENSe( <i>Ch</i> ).CORRection.COLLect.CLEAR          |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Open   Short   Load &gt; Cancel</b>       |

SCPI.SENSE(*Ch*).CORRECTION.COLLECT.DATA.LOAD(*Pt*)

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Variant (array of double)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> : channel number (see Table 1)   |
| <i>Description</i>         | The array of the <i>load</i> calibration standard measurements for the port <i>Pt</i> ,<br><i>Pt</i> : port number 1<br>The array elements are complex numbers. Also see section 12.<br>The array size is 2N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br><br>Data(2n-2) real part of the measurement;<br><br>Data(2n-1) imaginary part of the measurement. |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SENSE(<i>Ch</i>).CORRECTION.COLLECT.DATA.LOAD (<i>Pt</i>) app.SCPI.SENSE(<i>Ch</i>).CORRECTION.COLLECT.DATA.LOAD (<i>Pt</i>) = <i>Data</i></pre>   |
| <i>Related Commands</i>    | SCPI.SENSE( <i>Ch</i> ).CORRECTION.COLLECT.ACQUIRE.LOAD   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.DATA.OPEN(*Pt*)

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (array of double)  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> : channel number (see Table 1)  |
| <i>Description</i>         | <p>The array of the <i>open</i> calibration standard measurements for the port <i>Pt</i>,<br/> <i>Pt</i>: port number 1</p> <p>The array elements are complex numbers. Also see section 12.</p> <p>The array size is 2N, where N is the number of measurement points.</p> <p>For the n-th point, where n from 1 to N:</p> <p style="margin-left: 40px;">Data(2n-2) real part of the measurement;</p> <p style="margin-left: 40px;">Data(2n-1) imaginary part of the measurement.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.DATA.OPEN(<i>Pt</i>) app.SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.DATA.OPEN(<i>Pt</i>) = Data</pre>   |
| <i>Related Commands</i>    | SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ACQuire.OPEN  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.DATA.SHORT(*Pt*)

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Variant (array of double)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> : channel number 1–16 (see Table 1)  |
| <i>Description</i>         | <p>The array of the <i>short</i> calibration standard measurements for the port <i>Pt</i>,<br/> <i>Pt</i>: port number 1</p> <p>The array elements are complex numbers. Also see section 12.</p> <p>The array size is 2N, where N is the number of measurement points.</p> <p>For the n-th point, where n from 1 to N:</p> <p style="margin-left: 40px;">Data(2n–2) real part of the measurement;</p> <p style="margin-left: 40px;">Data(2n–1) imaginary part of the measurement.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.DATA.SHORT(<i>Pt</i>) app.SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.DATA.SHORT(<i>Pt</i>) = Data</pre>  |
| <i>Related Commands</i>    | SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ACQuire.SHORT  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.ECAL.INFormation

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | AutoCal module ( <i>Ch</i> – arbitrary number 1 to 4)   |
| <i>Description</i>         | <p>Gets information about the AutoCal Module connected to the Network Analyzer in a string with comma separated fields.</p> <p>Autocal Module Information:</p> <ul style="list-style-type: none"> <li>• Model Name,</li> <li>• Serial Number,</li> <li>• Current Temperature of AutoCal Module,</li> </ul> <p>Selected Characterization Information:</p> <ul style="list-style-type: none"> <li>• Characterization Name,</li> <li>• Characterization Date and Time,</li> <li>• Min Frequency,</li> <li>• Max Frequency,</li> <li>• Number of Points,</li> <li>• Characterization Temperature,</li> <li>• PortA Connector,</li> <li>• PortB Connector,</li> <li>• PortA Adapter,</li> <li>• PortB Adapter,</li> <li>• Analyzer,</li> <li>• Location,</li> <li>• Operator.</li> </ul> |
| <i>Syntax</i>              | <pre>Dim ID As String ID = app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL. INFormation</pre>  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Characterization Info</b>  |

### SCPI.SENSE(*Ch*).CORRection.COLLect.ECAL.CHECK.Execute

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | AutoCal module ( <i>Ch</i> – arbitrary number 1 to 4)             |
| <i>Description</i>         | Executing confidence check  |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.CHECK.Execute |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Confidence Check</b>     |

### SCPI.SENSE.CORRection.COLLect.ECAL.ORIentation.Execute

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | AutoCal module  |
| <i>Description</i>         | Executing AutoCal orientation   |
| <i>Syntax</i>              | app.SCPI.SENSE.CORRection.COLLect.ECAL.ORIentation.Execute            |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Perform Auto-Orientation</b> |

## SCPI.SENSE(Ch).CORRection.COLLect.ECAL.ORIentation.STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | AutoCal ( <i>Ch</i> – arbitrary number 1 to 4)  |
| <i>Description</i>         | The ON/OFF state of the Auto-Orientation function used when executing AutoCal.  |
| <i>Allowable Values</i>    | <p><i>True</i>      Auto-Orientation function ON</p> <p><i>False</i>     Auto-Orientation function OFF</p>  |
| <i>Preset Value</i>        | False   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL. ORIentation.STATE app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL. ORIentation.STATE = False</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Orientation &gt; Auto</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.ECAL.SOLT1

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Executes 1-port calibration of the specified port of selected channel ( <i>Ch</i> ) using the AutoCal module. |
| <i>Syntax</i>              | <pre>Dim Port As Long app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL.SOLT1 = Port</pre>                           |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Calibrate</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.ECAL.SOLT2

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | Variant (Long array)  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number 1–16 (in N-port mode only)  |
| <i>Description</i>         | <p>Executes the one path 2–port calibration in both directions of the specified ports of selected channel (<i>Ch</i>) using the AutoCal module.<br/>(in N-port mode only)</p> <p>Data(0) the number of the receiver port;</p> <p>Data(1) the number of the source port.</p> |
| <i>Range</i>               | Port number from 1 to 16. The array elements can not contain the same port numbers.   |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.ECAL.SOLT2<br>= Array(2, 1)  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Calibrate</b>  |

## SCPI.SENSE(Ch).CORRection.COLLect.ECAL.UChar

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | AutoCal (Ch – arbitrary number 1 to 4)  |
| <i>Description</i>         | Sets or reads out the Characteristic used when executing AutoCal (factory or user characterization).  |
| <i>Range</i>               | "CHAR0" : Factory characterization<br>"CHAR1" : User characterization 1<br>"CHAR2" : User characterization 2<br>"CHAR3" : User characterization 3   |
| <i>Preset Value</i>        | CHAR0   |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL.UChar<br>app.SCPI.SENSE(Ch).CORRection.COLLect.ECAL.UChar<br>= "CHAR0" |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Autocalibration &gt; Characterization</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.METHOD.ERESponse

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number 1–16 (in N-port mode only)   |
| <i>Description</i>         | Selects the ports and sets the one path 2-port calibration type for the calculation of the calibration coefficients on completion of the calibration executed by the SCPI .SENSe ( <i>Ch</i> ) .CORRection .COLLect .SAVE method.<br>(in N-port mode only)<br>The array contains 2 elements:<br>Data(0) the number of the receiver port;<br>Data(1) the number of the source port. |
| <i>Range</i>               | Port number from 1 to 16. The array elements can not contain the same port numbers.  |
| <i>Out of Range</i>        | If an incorrect port number is specified, an error occurs. If the same port numbers are specified, an error occurs.  |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.ERESponse = Array(2, 1)  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Type</b>   |

SCPI.SENSe(*Ch*).CORRection.COLLect.METHOD.RESPonse.OPEN

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Selects the port and sets the <i>response calibration (Open)</i> type for the calculation of the calibration coefficients on completion of the calibration executed by the<br>SCPI.SENSe ( <i>Ch</i> ) .CORRection.COLLect.SAVE method. |
| <i>Range</i>               | Port number is 1,<br>1-16 (in N-port mode only).  |
| <i>Out of Range</i>        | An error occurs. Error code: 222.   |
| <i>Syntax</i>              | app.SCPI.SENSe ( <i>Ch</i> ) .CORRection.COLLect.METHOD.<br>RESPonse.OPEN = 1   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).CORRection.COLLect.METHOD.RESPonse.SHORt

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (write only)   |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | Selects the port and sets the <i>response calibration (Short)</i> type for the calculation of the calibration coefficients on completion of the calibration executed by the SCPI .SENSe (Ch) .CORRection. COLLect. SAVE method. |
| <i>Range</i>               | Port number is 1,<br>1-16 (in N-port mode only).  |
| <i>Out of Range</i>        | An error occurs..   |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COLLect.METHOD.<br>RESPonse.SHORT = 1   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.METHOD.SOLT1

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Selects the port and sets the <i>full 1-port calibration</i> type for the calculation of the calibration coefficients on completion of the calibration executed by the SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.SAVE method. |
| <i>Range</i>               | Port number is 1   |
| <i>Out of Range</i>        | An error occurs. Error code: 222.  |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.SOLT1<br>= 1   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SENSE(Ch).CORRection.COLLect.METHOD.SOLT2

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number 1–16 (see Table 1)   |
| <i>Description</i>         | Selects the ports and sets the one path 2-port calibration type for the calculation of the calibration coefficients on completion of the calibration executed by the SCPI.SENSE(Ch).CORRection.COLLect.SAVE method.<br>(in N-port mode only)<br>The array contains 2 elements:<br>Data(0) Data(0)<br>Data(1) Data(1) |
| <i>Range</i>               | Port number from 1 to 16. The array elements can not contain the same port numbers.  |
| <i>Out of Range</i>        | If an incorrect port number is specified, an error occurs. If the same port numbers are specified, an error occurs.  |
| <i>Syntax</i>              | app.SCPI.SENSE(Ch).CORRection.COLLect.METHOD.SOLT<br>2= Array(2, 1)  |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Calibration Type</b>   |

SCPI.SENSE(*Ch*).CORRection.COLLect.METHOD.RESPonse.THRU

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (write only)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number 1–16 (in N-port mode only)   |
| <i>Description</i>         | Selects the ports and sets the response calibration (Thru) type for the calculation of the calibration coefficients on completion of the calibration executed by the SCPI .SENSe ( <i>Ch</i> ) .CORRection .COLLect .SAVE method.<br><br>(in N-port mode only)<br><br>The array contains 2 elements:<br><br>Data(0) the number of the receiver port;<br><br>Data(1) the number of the source port. |
| <i>Range</i>               | Port number is 1 or 2. Array elements can not contain the same port numbers.   |
| <i>Out of Range</i>        | If an incorrect port number is specified, an error occurs. If the same port numbers are specified, an error occurs.  |
| <i>Syntax</i>              | app.SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.METHOD.RESPonse.THRU = Array(2, 1)  |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.METHOD.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The calibration type selected for calculating of the calibration coefficients on completion of the calibration executed by the SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.SAVE method.   |
| <i>Range</i>               | "ST" Scalar Thru (in N-port mode only)<br>"RO" Response (Open)<br>"RS" Response (Short)<br>"F1" Full 1-port calibration<br>"F1ST" Full 1-port calibration + Scalar Thru (in N-port mode only)<br>"F2ST" Full 2-port calibration + Scalar Thru (in N-port mode only)<br>"MATH" Calculated Full 2-port calibration + Scalar Thru (in N-port mode only)<br>"NONE" Not defined |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.SENSE(Ch).CORRection.COLLect.METHOD.TYPE</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).CORRection.COLLect.SAVE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Calculates the calibration coefficients from the calibration standards measurements depending on the selected calibration type.<br>On completion of the method, all the calibration standards measurements are cleared and the error correction automatically turns ON.<br>At the attempt to execute this method before all the needed standards are measured, an error occurs and the method is ignored.  |
| <i>Syntax</i>              | <i>app</i> .SCPI.SENSE( <i>Ch</i> ).CORRection.COLLect.SAVE  |
| <i>Related Commands</i>    | <p>Calibration type selection:</p> <p>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.METHOD.RESPonse<br/>.OPEN<br/>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.METHOD.RESPonse<br/>.SHORT<br/>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.METHOD.SOLT1<br/>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.METHOD.SOLT2 (in N-port mode only)</p> <p>Calibration standards measurement:</p> <p>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.ACQuire.LOAD<br/>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.ACQuire.OPEN<br/>SCPI.SENSE(<i>Ch</i>).CORRection.COLLect.ACQuire.SHORT</p> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Open   Short   Load &gt; Apply</b>   |

## SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).FREQuency(Ls)

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | The value of the frequency at the point number <i>Ls</i> for calculation of the loss for the port extension function,<br><i>Ls</i> point number 1–2 (see Table 9)                  |
| <i>Range</i>               | from 85 to 14000 MHz   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 1e9  |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | Dim Value As Double<br>Value =<br>app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).<br>FREQuency(Ls)<br>app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).<br>FREQuency(Ls) = 100E6 |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Frequency 1   Frequency 2</b>   |

Table 9. *Ls*: Point Number

|                     |  |
|---------------------|--|
| <i>Data type</i>    | Long   |
| <i>Description</i>  | Point number for loss assignment in the port extension function. |
| <i>Range</i>        | 1 or 2   |
| <i>Out of range</i> | An error occurs. Error code: 222                                 |
| <i>Notes</i>        | If the point number is not specified, it is taken as equal to 1. |

## SCPI.SENSe(Ch).CORRection.EXTension.PORT(Pt).INCLude(Ls).STATe

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)   |
| <i>Description</i>         | The ON/OFF state of the loss compensation at the point number <i>Ls</i> to calculate the loss for the port extension function,<br><i>Ls</i> point number 1–2 (see Table 9).          |
| <i>Allowable Values</i>    | <i>True</i> Loss compensation ON<br><i>False</i> Loss compensation OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status =<br>app.SCPI.SENSe(Ch).CORRection.EXTension.PORT(Pt).INCLude(Ls).STATe<br>app.SCPI.SENSe(Ch).CORRection.EXTension.PORT(Pt).INCLude(Ls).STATe = True |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Loss1   Loss2</b>   |

## SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).LDC

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)                                  |
| <i>Description</i>         | The loss value at DC for the loss calculation of the port extension function.   |
| <i>Range</i>               | from -200 to 200  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | dB (decibel)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). LDC app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). LDC = 10</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Loss at DC</b>   |

## SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).LOSS(Ls)

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)  |
| <i>Description</i>         | The loss value at the point number <i>Ls</i> to calculate the loss for the port extension function,<br><i>Ls</i> point number 1–2 (see Table 9)                   |
| <i>Range</i>               | from -200 to 200  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | dB (decibel)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). LOSS(Ls) app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). LOSS(Ls) = 10</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Loss 1   Loss 2</b>  |

## SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt).TIME

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Port <i>Pt</i> of channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)<br><i>Pt</i> port number (see Table 2)                                      |
| <i>Description</i>         | The electrical delay value for the port extension function.   |
| <i>Range</i>               | from -10 to 10  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). TIME app.SCPI.SENSE(Ch).CORRection.EXTension.PORT(Pt). TIME = 1e-9</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Port Extension</b>   |

## SCPI.SENSe(Ch).CORRection.EXTension.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of the port extension function.   |
| <i>Allowable Values</i>    | <i>True</i> Port extension function ON<br><i>False</i> Port extension function OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.SENSe(Ch).CORRection.EXTension.STATE app.SCPI.SENSe(Ch).CORRection.EXTension.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Port Extensions &gt; Port Extension</b>  |

## SCPI.SENSE(Ch).CORRection.IMPedance.INPUT.MAGNitude

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The system impedance Z0.  |
| <i>Range</i>               | from 0.001 to 1000  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 50  |
| <i>Unit</i>                | Ω (Ohm)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(1).CORRection.IMPedance.INPUT. MAGNitude app.SCPI.SENSE(1).CORRection.IMPedance.INPUT. MAGNitude = 75</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.SENSE(*Ch*).CORRection.STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The ON/OFF state of the error correction.   |
| <i>Allowable Values</i>    | <i>True</i> Error correction ON<br><i>False</i> Error correction OFF  |
| <i>Preset Value</i>        | <i>False</i>  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.SENSE(Ch).CORRection.STATE<br>app.SCPI.SENSE(Ch).CORRection.STATE = True |
| <i>Equivalent Softkeys</i> | <b>Calibration &gt; Correction</b>  |

**SCPI.SENSe(*Ch*).CORRection.TRANSform.DISTance.FREQuency**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The Value of Frequency specified for Cable Loss in DTF measurements.  |
| <i>Range</i>               | from 1.0 to 10000.0   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 1000.0  |
| <i>Unit</i>                | MHz   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSe(Ch).CORRection.TRANSform.DISTance. FREQuency app.SCPI.SENSe(Ch).CORRection.TRANSform.DISTance. FREQuency = 2000.0</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Cable Loss Correction &gt; Frequency</b>  |

SCPI.SENSE(*Ch*).CORRection.TRANSform.DISTance.LOSS

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The Value of Cable Loss for DTF measurements.   |
| <i>Range</i>               | from 0.0 to 1000.0  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0.0   |
| <i>Unit</i>                | dB/m  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.TRANSform.DISTance. LOSS app.SCPI.SENSE(Ch).CORRection.TRANSform.DISTance. LOSS = 0.25</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Cable Loss Correction &gt; Loss</b>   |

SCPI.SENSE(*Ch*).CORRection.TRANSform.DISTance.RVELocity

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The Value of Velocity Factor for DTF measurements.  |
| <i>Range</i>               | from 0.01 to 1.0  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 1.0   |
| <i>Unit</i>                | None  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).CORRection.TRANSform.DISTance. RVELocity app.SCPI.SENSE(Ch).CORRection.TRANSform.DISTance. RVELocity = 0.68</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Cable Loss Correction &gt; Velocity Factor</b>  |

**SCPI.SENSe(*Ch*).CORRection.TRANSform.DISTance.STATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | The channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The ON/OFF state of Cable Loss correction in DTF measurements.   |
| <i>Allowable Values</i>    | <i>True</i> Cable Loss correction ON<br><i>False</i> Cable Loss correction OFF   |
| <i>Preset Value</i>        | <i>False</i>   |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.SENSe(Ch).CORRection.TRANSform.DISTance. STATE app.SCPI.SENSe(Ch).CORRection.TRANSform.DISTance. STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Analysis &gt; Time Domain &gt; Cable Loss Correction &gt; Cable Loss Correction</b>   |

SCPI.SENSE(*Ch*).CORRection.TYPE(*Tr*)

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Variant (Variant array)   |
| <i>Target</i>              | <p>Trace <i>Tr</i> of channel <i>Ch</i>,</p> <p><i>Ch</i>      channel number (see Table 1)</p> <p><i>Tr</i>      trace number (see Table 3)</p>  |
| <i>Description</i>         | <p>The information about the applied calibration type and the port numbers for the specified trace.</p> <p>The array contains 3 elements:</p> <p>Data(0)      calibration type (see below);</p> <p>Data(1)      the number of the receiver port to be calibrated;</p> <p>Data(2)      the number of the source port to be calibrated.</p> |
| <i>Range</i>               | <p>Calibration type in the element <i>Data(0)</i>:</p> <p>"RESPO"      Response (Open)</p> <p>"RESPS"      Response (Short)</p> <p>"SOLT1"      Full 1–port calibration</p> <p>"NONE"      Not defined</p>  |
| <i>Syntax</i>              | <pre>Dim CalInfo As Variant CalInfo = app.SCPI.SENSE(Ch).CORRection.TYPE(Tr)</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).FREQuency.CENTer

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The stimulus center value of the sweep range for linear or logarithmic sweep types.                                  |
| <i>Range</i>               | from 85E6 to 5.4E9   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 2742.5E6   |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).FREQuency.CENTer app.SCPI.SENSE(Ch).FREQuency.CENTer = 1E9</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

SCPI.SENSE(*Ch*).FREQuency.DATA

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Variant (Double array)  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The array of the measurement points frequency for linear, logarithmic or segment sweep type.<br>The array size is N, where N is the number of measurement points.<br>For the n-th point, where n from 1 to N:<br>Data(n-1) the frequency value at the n-th measurement point. |
| <i>Syntax</i>              | Dim Data As Variant<br>Data = app. SCPI.SENSE(Ch).FREQuency.DATA  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SENSE(Ch).FREQuency.SPAN

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel Ch,<br>Ch channel number (see Table 1)   |
| <i>Description</i>         | The stimulus span value of the sweep range for linear or logarithmic sweep types.                                |
| <i>Range</i>               | from 0 to 5.4E9  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 5315E6   |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).FREQuency.SPAN app.SCPI.SENSE(Ch).FREQuency.SPAN = 1E9</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SENSE(Ch).FREQuency.START

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The stimulus start value of the sweep range for linear or logarithmic sweep types.                                   |
| <i>Range</i>               | from 85E6 to 5.4E9   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 85E6   |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).FREQuency.START app.SCPI.SENSE(Ch).FREQuency.START = 100E6</pre> |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Start Frequency</b>   |

## SCPI.SENSE(Ch).FREQuency.STOP

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The stimulus stop value of the sweep range for linear or logarithmic sweep types.                                |
| <i>Range</i>               | from 85E6 to 5.4E9   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 5.4E9  |
| <i>Unit</i>                | Hz (Hertz)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).FREQuency.STOP app.SCPI.SENSE(Ch).FREQuency.STOP = 3E9</pre> |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Stop Frequency</b>  |

## SCPI.SENSE(Ch).ROSCillator.SOURce

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Selects the reference oscillator source.  |
| <i>Range</i>               | "INT" Internal reference oscillator<br>"EXT" External source  |
| <i>Notes</i>               | Option specified for Planar RVNA.   |
| <i>Out of Range</i>        | An error occurs. Error code: 205.   |
| <i>Preset Value</i>        | "INT"   |
| <i>Syntax</i>              | Dim Param As String<br>Param = app.SCPI.SENSE(Ch).ROSCillator.SOURCE<br>app.SCPI.SENSE(Ch).ROSCillator.SOURCE = "EXT" |
| <i>Equivalent Softkeys</i> | <b>System &gt; Reference Source</b>   |

SCPI.SENSE(*Ch*).SEGMENT.DATA

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (Double array)   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | <p>The array of the segment sweep table.</p> <p>The array has the following format:</p> <pre>{ &lt;Buf&gt;, &lt;Flag1&gt;, &lt;Flag2&gt;, &lt;Flag3&gt;, &lt;Flag4&gt;, &lt;Flag5&gt;, &lt;N&gt;, &lt;Start(1)&gt;, &lt;Stop(1)&gt;, &lt;NOP(1)&gt; [,&lt;IFBW(1)&gt;] [,&lt;Pow(1)&gt;] [,&lt;Del(1)&gt;] [,&lt;Time(1)&gt;], &lt;Start(2)&gt;, &lt;Stop(2)&gt;, &lt;NOP(2)&gt; [,&lt;IFBW(2)&gt;] [,&lt;Pow(2)&gt;] [,&lt;Del(2)&gt;] [,&lt;Time(2)&gt;], ... &lt;Start(N)&gt;, &lt;Stop(N)&gt;, &lt;NOP(N)&gt; [,&lt;IFBW(N)&gt;] [,&lt;Pow(N)&gt;] [,&lt;Del(N)&gt;] [,&lt;Time(N)&gt;] }</pre> <p>&lt;Buf&gt; Always 5,<br/> &lt;Flag1&gt; Stimulus start setting (0 – start/stop, 1 – center/span),<br/> &lt;Flag2&gt; Setting of the &lt;IFBW&gt; field (0 – disabled, 1 – enabled),<br/> &lt;Flag3&gt; Setting of the &lt;Pow&gt; field (0 – disabled, 1 – enabled),<br/> &lt;Flag4&gt; Setting of the &lt;Del&gt; field (0 – disabled, 1 – enabled),<br/> &lt;Flag5&gt; Setting of the &lt;Time&gt; field (0 – disabled, 1 – enabled),<br/> &lt;N&gt; Number of segments,<br/> &lt;Start n&gt; Start value of the n-th segment,<br/> &lt;Stop n&gt; Stop value of the n-th segment,<br/> &lt;NOP n&gt; Number of points of the n-th segment,<br/> &lt;IFBW n&gt; IF bandwidth of the n-th segment (if enabled),<br/> &lt;Pow n&gt; Power of the n-th segment (if enabled),<br/> &lt;Del n&gt; Measurement delay of the n-th segment (if enabled),<br/> &lt;Time n&gt; Reserved for future use (if enabled).</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SENSE(<i>Ch</i>).SEGMENT.DATA app.SCPI.SENSE(<i>Ch</i>).SEGMENT.DATA = Data</pre>   |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Segment Table</b>   |

## SCPI.SENSE(Ch).SWEEP.POINT.TIME

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Double  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The value of the delay before measurement in each measurement point.  |
| <i>Range</i>               | from 0 to 0.3   |
| <i>Resolution</i>          | 5E-6  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.  |
| <i>Preset Value</i>        | 0   |
| <i>Unit</i>                | s (second)  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SENSE(Ch).SWEEP.POINT.TIME app.SCPI.SENSE(Ch).SWEEP.POINT.TIME = 5E-6</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

SCPI.SENSE(*Ch*).SWEep.POINts

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The number of measurement points.  |
| <i>Range</i>               | from 2 to 100001<br>from 2 to 16001 (in N-port mode only)  |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 201  |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.SENSE( <i>Ch</i> ).SWEep.POINts<br>app.SCPI.SENSE( <i>Ch</i> ).SWEep.POINts = 1001 |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Points</b>  |

SCPI.SENSe(*Ch*).SWEEP.REVERSE.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The ON/OFF state of the reverse scan.  |
| <i>Allowable Values</i>    | <p><i>True</i>      Reserse Scan ON</p> <p><i>False</i>     Reverse Scan OFF</p>   |
| <i>Preset Value</i>        | "False"  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.SENSe(1).SWEEP.REVERSE.STATE app.SCPI.SENSe(1).SWEEP.REVERSE.STATE = True</pre> |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Sweep Type &gt; Reverse Scan</b>  |

SCPI.SENSE(*Ch*).SWEEP.TYPE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | Sets the sweep type.   |
| <i>Range</i>               | "LINear" Linear frequency sweep<br>"LOGarithmic" Logarithmic frequency sweep<br>"SEGMENT" Segment frequency sweep  |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters. There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs. Error code: 206.  |
| <i>Preset Value</i>        | "LIN"  |
| <i>Syntax</i>              | Dim Param As String<br>Param = app.SCPI.SENSE( <i>Ch</i> ).SWEEP.TYPE<br>app.SCPI.SENSE( <i>Ch</i> ).SWEEP.TYPE = "LOG"  |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Sweep Type</b>  |

**SCPI.SERVICE.CHANNEL.ACTIVE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The number of the active channel.                            |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.SERVICE.CHANNEL.ACTIVE |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SERVICE.CHANNEL.COUNT**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | The maximum number of the channels.                         |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.SERVICE.CHANNEL.COUNT |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SERVICE.CHANnel(*Ch*).TRACe.ACTive

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                  |
| <i>Description</i>         | The active trace number of the channel.  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.SERVICE.CHANnel(Ch).TRACe.ACTive</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SERVICE.CHANnel.TRACe.COUNT

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | The maximum number of the traces in the channel.                          |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.SERVICE.CHANnel.TRACe.COUNT</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.SERVICE.PORT.COUNT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)                                     |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The number of the ports.                                 |
| <i>Syntax</i>              | Dim Value As Long<br>Value = app.SCPI.SERVICE.PORT.COUNT |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SERVICE.SWEep.FREQency.MAXimum**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The upper limit of the measurement frequency.                          |
| <i>Syntax</i>              | Dim Value As Double<br>Value = app.SCPI.SERVICE.SWEep.FREQency.MAXimum |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SERVICE.SWEep.FREQency.MINimum

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The lower limit of the measurement frequency.                                  |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SERVICE.SWEep.FREQency.MINimum</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SERVICE.SWEep.POINts

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The maximum number of the measurement points.                      |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.SERVICE.SWEep.POINts</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SOURce(*Ch*).POWer.LEVel.STATE**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)   |
| <i>Description</i>         | The power level for the frequency sweep (only for R54/R140).  |
| <i>Range</i>               | “HIGH” high output power;<br>“LOW” low output power.<br>“ROFF” RF Out is Off  |
| <i>Preset Value</i>        | “HIGH”  |
| <i>Syntax</i>              | Dim Value As String<br>Value = app.SCPI.SOURce(Ch).POWer.LEVel.STATE<br>app.SCPI.SOURce(Ch).POWer.LEVel.STATE = “LOW” |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Power</b>  |

**SCPI.SOURce(*Ch*).POWer.LEVel.IMMediate.AMPLitude**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Description</i>         | The power level for the frequency sweep (only for R60, R180).  |
| <i>Range</i>               | From the minimum value to the maximum value of the analyzer power range  |
| <i>Resolution</i>          | 0.05   |
| <i>Out of Range</i>        | Sets the value of the limit, which is closer to the specified value.   |
| <i>Preset Value</i>        | 0  |
| <i>Unit</i>                | dBm (decibels above 1 milliwatt)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SOURce(Ch).POWer.LEVel.IMMediate.AMPLitude app.SCPI.SOURce(Ch).POWer.LEVel.IMMediate.AMPLitude = -10</pre> |
| <i>Equivalent Softkeys</i> | <b>Stimulus &gt; Power &gt; Output Power</b>   |

## SCPI.STATUS.OPERATION.CONDITION

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Operation Status Condition Register.                                     |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.OPERATION.CONDITION</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.OPERATION.ENABLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Operation Status Enable Register.  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.OPERATION.ENABLE app.SCPI.STATUS.OPERATION.ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.OPERation.EVENT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System                                     |
| <i>Description</i>         | Operation Status Event Register                                      |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.OPERation.EVENT</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.OPERation.NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Operation Status Register  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.OPERation.NTRansition app.SCPI.STATUS.OPERation.NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.OPERation.PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Operation Status Register.   |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.OPERation.PTRansition app.SCPI.STATUS.OPERation.PTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.PRESet

|                            |                                  |
|----------------------------|----------------------------------|
| <i>Object Type</i>         | Method                           |
| <i>Target</i>              | IEE488.2 Status Reporting System |
| <i>Description</i>         | Initialization of all registers. |
| <i>Syntax</i>              | app.SCPI.STATUS.PRESet           |
| <i>Equivalent Softkeys</i> | <b>None</b>                      |

## SCPI.STATUS.QUESTIONable.CONDITION

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Status Condition Register                                      |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.CONDITION</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.ENABLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Status Enable Register  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.ENABLE app.SCPI.STATUS.QUESTIONable.ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.EVENT

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Status Event Register                                      |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.EVENT</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch).CONDITION

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Limit Channel Status Condition Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch) . CONDITION</pre>                        |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch).ENABLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Limit Channel Status Enable Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMIT.CHANNEL(Ch) . ENABLE app.SCPI.STATUS.QUESTIONable.LIMIT.CHANNEL(Ch) . ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch).EVENT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Limit Channel Status Event Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app. SCPI.STATUS.QUESTIONable.LIMIT.CHANNEL(Ch) .EVENT</pre>                        |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch).NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Questionable Limit Channel Status Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1))                        |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch) . NTRansition app.SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch) . NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.CHANnel(Ch).PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Questionable Limit Channel Status Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                         |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMIT.CHANnel(Ch) . PTRansition app.SCPI.STATUS.QUESTIONable.LIMIT.CHANnel(Ch) . PTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.CONDITION

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Limit Status Condition Register.                                     |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.CONDITION</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.LIMit.ENABLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Limit Status Enable Register.   |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.ENABLE app.SCPI.STATUS.QUESTIONable.LIMit.ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.EVENT

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Limit Status Event Register.                                     |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.EVENT</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.LIMit.NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Questionable Limit Status Register   |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.NTRansition app.SCPI.STATUS.QUESTIONable.LIMit.NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.LIMit.PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Questionable Limit Status Register.  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.LIMit.PTRansition app.SCPI.STATUS.QUESTIONable.LIMit.PTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Questionable Status Register.  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.NTRansition app.SCPI.STATUS.QUESTIONable.NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Questionable Status Register.  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.PTRansition app.SCPI.STATUS.QUESTIONable.PTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch).CONDition

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Ripple Limit Channel Status Condition Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . CONDition</pre>                              |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch).ENABLE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Ripple Limit Channel Status Enable Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                                     |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . ENABLE app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch).EVENT

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | Long  |
| <i>Target</i>              | IEE488.2 Status Reporting System  |
| <i>Description</i>         | Questionable Ripple Limit Channel Status Event Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1) |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . EVENT</pre>                              |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch).NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Questionable Ripple Limit Channel Status Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                    |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . NTRansition app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch).PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Questionable Ripple Limit Channel Status Register for channel <i>Ch</i> ,<br><i>Ch</i> channel number (see Table 1)                      |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . PTRransition app.SCPI.STATUS.QUESTIONable.RLIMit.CHANnel(Ch) . PTRransition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.CONDITION

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Ripple Limit Status Condition Register.                               |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.CONDITION</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.STATUS.QUESTIONable.RLIMit.ENABLE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Ripple Limit Status Enable Register   |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.ENABLE app.SCPI.STATUS.QUESTIONable.RLIMit.ENABLE = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.STATUS.QUESTIONable.RLIMit.EVENT**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Questionable Ripple Limit Status Event Register.                               |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.EVENT</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.NTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Negative Transition Filter of the Questionable Ripple Limit Status Register  |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.NTRansition app.SCPI.STATUS.QUESTIONable.RLIMit.NTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.STATUS.QUESTIONable.RLIMit.PTRansition

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Long   |
| <i>Target</i>              | IEE488.2 Status Reporting System   |
| <i>Description</i>         | Positive Transition Filter of the Questionable Ripple Limit Status Register.   |
| <i>Range</i>               | from 0 to 65535  |
| <i>Preset Value</i>        | 65535  |
| <i>Syntax</i>              | <pre>Dim Value As Long Value = app.SCPI.STATUS.QUESTIONable.RLIMit.PTRansition app.SCPI.STATUS.QUESTIONable.RLIMit.PTRansition = Value</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SYSTEM.COMMUniccate.ECAL.TEMPerature.SENSOR

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | AutoCal module   |
| <i>Description</i>         | Reads out the temperature of the AutoCal module connected to the instrument.               |
| <i>Unit</i>                | °C (Celsius)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SYSTEM.COMMUniccate.ECAL.TEMPeratureSENSOR</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

## SCPI.SYSTem.CORRection.STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Boolean   |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | The ON/OFF state of the system error correction.  |
| <i>Allowable Values</i>    | <p><i>True</i>      System error correction ON</p> <p><i>False</i>     System error correction OFF</p>              |
| <i>Preset Value</i>        | True  |
| <i>Syntax</i>              | <pre>Dim Status As Boolean Status = app.SCPI.SYSTem.CORRection.STATE app.SCPI.SYSTem.CORRection.STATE = False</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.SYSTem.DATE**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Variant (Long array)   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | <p>The current date.</p> <p>The array consists of three elements:</p> <p>Data(0) year from 1900 to 2100;</p> <p>Data(1) month from 1 to 12;</p> <p>Data(2) day from 1 to 31.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SYSTem.DATE app. app.SCPI.SYSTem.DATE = Array(2009, 9, 9)</pre>   |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SYSTem.HIDe**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Instrument                                     |
| <i>Description</i>         | Make the main form of a application invisible. |
| <i>Syntax</i>              | <code>app.SCPI.SYSTem.HIDe</code>              |
| <i>Related Commands</i>    | <code>SCPI.SYSTem.SHOW</code>                  |
| <i>Equivalent Softkeys</i> | <b>None</b>                                    |

**SCPI.SYSTem.LOCal**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Sets the instrument to the local operation mode, when all the keys on the front panel, mouse and the touch screen are active. |
| <i>Syntax</i>              | app.SCPI.SYSTem.LOCal   |
| <i>Related Commands</i>    | SCPI.SYSTem.RWLock  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.SYSTem.PRESet**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Method   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Resets the instrument to the factory settings. The difference from the SCPI.IEEE4882.RST: method is that the trigger is set to the <i>Continuous</i> trigger mode. |
| <i>Syntax</i>              | app.SCPI.SYSTem.PRESet   |
| <i>Equivalent Softkeys</i> | <b>System &gt; Preset</b>  |

## SCPI.SYSTem.REMote

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Sets the instrument to the remote operation mode, when all the keys on the front panel, mouse and the touch screen are not active, except for one key labeled <i>Return to Local</i> . Pushing this button will reset the instrument to the local operation mode. |
| <i>Syntax</i>              | app. SCPI.SYSTem.REMote   |
| <i>Related Commands</i>    | SCPI.SYSTem.LOCal   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.SYSTem.RWLock

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Sets the instrument to the remote operation mode, when all the keys on the front panel, mouse and the touch screen are not active. Only SCPI.SYSTem.LOCal command can release this remote operation mode. |
| <i>Syntax</i>              | app. SCPI.SYSTem.RWLock   |
| <i>Related Commands</i>    | SCPI.SYSTem.LOCal   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.SYSTem.SHOW**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Return the main form of a application to visible state. |
| <i>Syntax</i>              | app. SCPI.SYSTem.SHOW                                   |
| <i>Related Commands</i>    | SCPI.SYSTem.HIDE  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.SYSTem.STANdby**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Description</i>         | Standby state of the instrument.<br><br><i>True</i> Instrument in Standby mode<br><br><i>False</i> Instrument in Normal mode |
| <i>Syntax</i>              | Dim State as Boolean<br>State = app.SCPI.SYSTem.STANdby<br>app.SCPI.SYSTem.STANdby = False                                   |
| <i>Equivalent Softkeys</i> | <b>System -&gt; Standby Mode</b>   |

**SCPI.SYSTem.TEMPerature.SENSor(Idx)**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read only)   |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | Reads out the specified sensor (Idx) temperature inside the analyzer.        |
| <i>Unit</i>                | °C (Celsius)   |
| <i>Syntax</i>              | <pre>Dim Value As Double Value = app.SCPI.SYSTem.TEMPerature.SENSor(1)</pre> |
| <i>Equivalent Softkeys</i> | <b>None</b>  |

**SCPI.SYSTem.TERMinate**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method                                  |
| <i>Target</i>              | Instrument                              |
| <i>Description</i>         | Close the COM server application.       |
| <i>Syntax</i>              | app. SCPI.SYSTem.TERMinate              |
| <i>Equivalent Softkeys</i> | <b>System &gt; Program Exit &gt; Ok</b> |

## SCPI.SYSTem.TIME

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | Variant (Long array)  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | <p>The current time.</p> <p>The array consists of three elements:</p> <p>Data(0)        hours from 0 to 23;</p> <p>Data(1)        minutes from 0 to 59;</p> <p>Data(2)        seconds from 0 to 59.</p> |
| <i>Syntax</i>              | <pre>Dim Data As Variant Data = app.SCPI.SYSTem.TIME app. app.SCPI.SYSTem.TIME = Array(15, 20, 30)</pre>  |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.TRIGger.OUTPUT.FUNCTION

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Trigger output   |
| <i>Description</i>         | Selects the trigger output function. The trigger output outputs various waveforms depending on the setting of the Output Trigger Function (see the operating manual).  |
| <i>Range</i>               | <p>"BSET" : Before frequency setup pulse</p> <p>"BSAM" : Before sampling pulse</p> <p>"ASAM" : After sampling pulse</p> <p>"RTRG" : Ready for trigger signal</p> <p>"ESWP" : End of sweep pulse</p> <p>"MEAS" : Measurement sweep signal</p> |
| <i>Preset Value</i>        | "RTRG"   |
| <i>Syntax</i>              | Param = app.SCPI.TRIGger.OUTPUT.FUNCTION<br>app.SCPI.TRIGger.INPUT.OUTPUT.FUNCTION = "ESWP"  |
| <i>Related Commands</i>    | SCPI.TRIGger.OUTPUT.POLarity<br>SCPI.TRIGger.OUTPUT.STATE  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Output &gt; Position &gt; Before Setup   Before Sampling   After Sampling   Ready for Trig   Sweep End   Measurement</b>   |

**SCPI.TRIGger.OUTPUT.POLarity**

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | String   |
| <i>Target</i>              | Trigger output   |
| <i>Description</i>         | Selects the polarity of the trigger output set by the SCPI.TRIGger.OUTPUT.FUNCTION command |
| <i>Range</i>               | "POSitive" Positive polarity<br>"NEGative" Negative polarity                               |
| <i>Preset Value</i>        | "NEG"  |
| <i>Syntax</i>              | Param = app.SCPI.TRIGger.OUTPUT.POLarity<br>app.SCPI.TRIGger.INPUT.OUTPUT.POLarity = "NEG" |
| <i>Related Commands</i>    | SCPI.TRIGger.OUTPUT.FUNCTION<br>SCPI.TRIGger.OUTPUT.STATE                                  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Output &gt; Polarity &gt; Negative Edge   Positive Edge</b>        |

## SCPI.TRIGger.OUTPUT.STATE

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Trigger output   |
| <i>Description</i>         | Turns ON/OFF the state of the trigger output.                                  |
| <i>Range</i>               | True trigger output ON<br>False trigger output OFF                             |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Status = app.SCPI.TRIGger.OUTPUT.STATE<br>app.SCPI.TRIGger.OUTPUT.STATE = True |
| <i>Related Commands</i>    | SCPI.TRIGger.OUTPUT.FUNCTION<br>SCPI.TRIGger.OUTPUT.POLarity                   |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Output &gt; Enable Out&gt; ON   OFF</b>                |

## SCPI.TRIGger.SEQuence.EXternal.Delay

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Double   |
| <i>Target</i>              | External Trigger   |
| <i>Description</i>         | Sets the response delay with respect to the external trigger signal.   |
| <i>Range</i>               | From 0 to 100 sec  |
| <i>Resolution</i>          | 0.1 usec   |
| <i>Out of Range</i>        | Sets to the nearest bound.   |
| <i>Preset Value</i>        | 0  |
| <i>Syntax</i>              | <pre>Dim Param As Double Param = app.SCPI.TRIGger.SEQuence.EXTERNAL.Delay app.SCPI.TRIGger.SEQuence.EXTERNAL.Delay = 0</pre> |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce   |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Input &gt; Delay</b>   |

## SCPI.TRIGger.SEQuence.EXternal.POStion

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | External trigger  |
| <i>Description</i>         | Selects the position of the external trigger. The Analyzer waits for external trigger:<br>Before sampling, when the frequency of the stimulus port have been set.<br>The frequency change of the stimulus port begins after sampling.<br>Before the frequency setup and subsequent measurement. The frequency change of the stimulus port begins when the external trigger arrives.<br>Depending on the command SCPI.TRIGger.SEQuence.POInt the external trigger wait occurs before each point or before the first point of the full sweep cycle. |
| <i>Range</i>               | "BSAM" Before sampling<br>"BSET" Before frequency setup   |
| <i>Out of Range</i>        | An error occurs.  |
| <i>Preset Value</i>        | "BSAM"  |
| <i>Syntax</i>              | Dim Param As String<br>Param =<br>app.SCPI.TRIGger.SEQuence.EXTERNAL.POStion<br>app.SCPI.TRIGger.SEQuence.EXTERNAL.POStion =<br>"BSAM"  |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Input &gt; Position &gt; Before Sampling   Before Setup</b>   |

## SCPI.TRIGger.SEQuence.EXternal.SLOPe

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | External trigger  |
| <i>Description</i>         | Selects the edge of the external trigger.   |
| <i>Range</i>               | "POSitive" Positive edge<br>"NEGative" Negative edge  |
| <i>Out of Range</i>        | An error occurs.  |
| <i>Preset Value</i>        | "NEG"   |
| <i>Syntax</i>              | Dim Param As String<br>Param = app.SCPI.TRIGger.SEQuence.EXternal.SLOPe<br>app.SCPI.TRIGger.SEQuence.EXternal.SLOPe = "POS" |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Input&gt; Polarity &gt; Negative Edge   Positive Edge</b>   |

## SCPI.TRIGger.SEQuence.IMMediate

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | <p>Generates a trigger, independently of the trigger source setting (except for the <i>External</i>). If the trigger source is set to <i>External</i>, an error occurs (error code 221) and the command is ignored.</p> <p>If the instrument is not in the waiting for a trigger state (sweep is in progress or all the channels are set to <i>Hold</i>), an error occurs (error code 211) and the command is ignored.</p> <p>The method returns control before the end of the sweep.</p> |
| <i>Syntax</i>              | app.SCPI.TRIGger.SEQuence.IMMediate   |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce<br>SCPI.INITiate(Ch).CONTinuous<br>SCPI.INITiate(Ch).IMMEDIATE   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## SCPI.TRIGger.SEQuence.POINT

|                            |  |
|----------------------------|--|
| <i>Object Type</i>         | Property (read/write)  |
| <i>Data Type</i>           | Boolean  |
| <i>Target</i>              | Instrument   |
| <i>Description</i>         | The ON/OFF state of the point trigger feature.<br>When the point trigger feature is turned ON, the external trigger response is single point. When the point trigger feature is turned OFF, the external trigger response is single sweep. |
| <i>Allowable Values</i>    | <i>True</i> point trigger feature ON<br><i>False</i> point trigger feature OFF   |
| <i>Preset Value</i>        | False  |
| <i>Syntax</i>              | Dim Status As Boolean<br>Status = app.SCPI.TRIGger.SEQuence.POINT<br>app.SCPI.TRIGger.SEQuence.POINT = True  |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce   |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Input &gt; Event &gt; On Sweep   On Point</b>  |

## SCPI.TRIGger.SEQuence.SINGle

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Method  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | <p>Generates a trigger, independently of the trigger source setting (except for the <i>External</i>). If the trigger source is set to <i>External</i>, an error occurs (error code 221) and the command is ignored.</p> <p>If the instrument is not in the waiting for a trigger state (sweep is in progress or all the channels are set to <i>Hold</i>), an error occurs (error code 211) and the command is ignored.</p> <p>The method does not return control before the end of the sweep (waiting for the completion of the sweep of all the channels).</p> |
| <i>Syntax</i>              | app.SCPI.TRIGger.SEQuence.SINGle  |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.SOURce<br>SCPI.INITiate( <i>Ch</i> ).CONTinuous<br>SCPI.INITiate( <i>Ch</i> ).IMMEDIATE   |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

**SCPI.TRIGger.SEQuence.SOURce**

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read/write)   |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Selects the sweep trigger source.   |
| <i>Range</i>               | "INTernal" Internal<br>"EXTernal" External<br>"BUS" Bus   |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters.<br>There is no distinction between upper and lower case letters when the property is written. When the property is read out, the short format is indicated by upper case letters. |
| <i>Out of Range</i>        | An error occurs.  |
| <i>Preset Value</i>        | "INT"   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.TRIGger.SEQuence.SOURce app.SCPI.TRIGger.SEQuence.SOURce = "BUS"</pre>  |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.IMMEDIATE<br>SCPI.TRIGger.SEQuence.SINGLE<br>SCPI.IEEE4882.TRG  |
| <i>Equivalent Softkeys</i> | <b>Trigger &gt; Trigger Source &gt; Internal   External   Bus</b>   |

## SCPI.TRIGger.SEQuence.STATE

|                            |   |
|----------------------------|---|
| <i>Object Type</i>         | Property (read only)  |
| <i>Data Type</i>           | String  |
| <i>Target</i>              | Instrument  |
| <i>Description</i>         | Returns the status of the scanner.  |
| <i>Range</i>               | "HOLD" scanning is stopped<br>"WAIT" waiting for the start<br>"MEAS" is scanning                          |
| <i>Notes</i>               | The short format of the parameter is indicated by upper case letters.                                     |
| <i>Out of Range</i>        | An error occurs. Error code: 200.   |
| <i>Syntax</i>              | <pre>Dim Param As String Param = app.SCPI.TRIGger.SEQuence.STATE</pre>                                    |
| <i>Related Commands</i>    | SCPI.TRIGger.SEQuence.IMMEDIATE<br>SCPI.TRIGger.SEQuence.SINGLE<br>SCPI.IEEE4882.TRG<br>SCPI.IEEE4882.RST |
| <i>Equivalent Softkeys</i> | <b>None</b>   |

## APPENDIX 1. ERROR CODES

|     |   |
|-----|---|
| 114 | "Header suffix out of range"              |
| 200 | "Execution error"                         |
| 211 | "Trigger ignored"                         |
| 213 | "Init ignored"                            |
| 220 | "Parameter Error"                         |
| 222 | "Data out of range"                       |
| 224 | "Illegal parameter value"                 |
| 201 | "Invalid channel index"                   |
| 202 | "Invalid trace index"                     |
| 203 | "Invalid marker index"                    |
| 204 | "Marker is not active"                    |
| 205 | "Invalid save type specifier"             |
| 206 | "Invalid sweep type specifier"            |
| 207 | "Invalid trigger source specifier"        |
| 208 | "Invalid measurement parameter specifier" |
| 209 | "Invalid format specifier"                |
| 210 | "Invalid data math specifier"             |
| 214 | "Invalid limit data"                      |
| 215 | "Invalid segment data"                    |
| 216 | "Invalid standard type specifier"         |
| 217 | "Invalid conversion specifier"            |
| 218 | "Invalid gating shape specifier"          |
| 219 | "Invalid gating type specifier"           |
| 300 | "Device-specific error"                   |
| 302 | "Status reporting system error"           |

## APPENDIX 2. PROGRAMMING EXAMPLES

### Example 1. Instrument Information String Readout

The following program reads out and displays on the screen the instrument information string – the Name property of the COM object. The string contains the following fields:

*Manufacturer, Model, Serial Number, Software Version/Firmware Version*

For example:

Copper Mountain Technologies, PLANAR R140, 00000001, 15.4.0/1.1

```
Dim app As Object
Sub Example1()
    Set app = CreateObject("RVNA.Application")
    ID = app.Name
    MsgBox ("Information string read out: " + ID)
End Sub
```

## Example 2. Checking the Instrument Ready State

Normally, the user control program starts when the analyzer executable module is running, the instrument booting is completed, and the instrument is ready for use. In some cases, it is recommended to check if the instrument is ready for use. The instrument may be not ready for use if it is not connected to PC via USB cable. Moreover, if the analyzer executable module has not been started in advance, the *CreateObject* function will automatically start the application and then within about 10 seconds the instrument booting will be in progress. The instrument will not be ready for use until the booting is completed. The *Ready* property is used to check if the instrument is ready for use.

The following program checks the *Ready* property right after a COM object has been created. If the *RVNA.exe* application has been started in advance and the booting is completed, “Analyzer is ready” will be displayed. If the *Ready* property value is *False*, 10 second delay is activated for the case the *RVNA.exe* application has been started by the COM object creation. In 10 seconds the program rechecks the *Ready* property. If the value is *True*, “Analyzer is ready” will be displayed, if otherwise, “Analyzer is not ready” will be displayed, what means the instrument is not connected to LAN or it is not connected to PC via USB cable.

```
Dim app As Object
Sub Example2()
    Set app = CreateObject("RVNA.Application")
    If app.Ready = False Then
        Application.Wait (Now + TimeValue("0:00:10"))
        If app.Ready = False Then
            MsgBox ("Analyzer is not ready")
            Exit Sub
        End If
    End If
    MsgBox ("Analyzer is ready")
End Sub
```

### Example 3. Setting the Measurement Parameters

The following program shows the setting of some measurement parameters. First, the instrument is reset to the factory settings. Then the following parameters are set:

- Two channel windows are opened and allocated one above the other.
- The number of traces is set to 2 in the first channel window.
- For the first channel the stimulus parameters are set as follows: the frequency range from 100 MHz to 1.2 GHz, the number of measurement points 401.
- For the second channel the stimulus parameters are set as follows: the frequency range from 800 MHz to 900 MHz, the number of points 51, IF bandwidth 100 Hz, output power – low.
- In the first channel window SWR format is set for the trace 1, logarithmic magnitude format is set for the trace 2.
- In the second channel window: logarithmic magnitude format is set for the single trace. Then the auto scale function is called for this trace.
- 

```

Dim app As Object

Public Sub Example3()
Set app = CreateObject("RVNA.Application")

app.SCPI.SYSTem.PRESet
app.SCPI.DISPlay.Split = 2
app.SCPI.Calculate(1).Parameter.Count = 2
app.SCPI.SENSE(1).Frequency.Start = 100000000
app.SCPI.SENSE(1).Frequency.STOP = 1200000000
app.SCPI.SENSE(1).SWEEP.Points = 401
app.SCPI.SENSE(2).Frequency.Start = 800000000
app.SCPI.SENSE(2).Frequency.STOP = 900000000
app.SCPI.SENSE(2).SWEEP.Points = 51
app.SCPI.SENSE(2).BANDwidth.RESolution = 100
app.SCPI.Source(2).Power.LEVEL.STATE = "LOW"
app.SCPI.Calculate(1).Parameter(1).Select
app.SCPI.Calculate(1).Selected.Format = "SWR"
app.SCPI.Calculate(1).Parameter(2).Select
app.SCPI.Calculate(1).Selected.Format = "MLOG"
app.SCPI.Calculate(2).Parameter(1).Select
app.SCPI.Calculate(2).Selected.Format = "MLOG"
app.SCPI.DISPlay.Window(2).TRACe(1).Y.SCALE.AUTO

End Sub

```

#### Example 4. Measurement Data Acquisition

The following program shows data array acquisition with further writing into a file. The program also shows the method of a sweep triggering and waiting for the sweep completion.

Three variables  $F$ ,  $M$ ,  $P$  are declared in the second string of the code. They are used for arrays of frequency values (Hz), magnitude values (dB), and phase values (degree) respectively.

After the instrument has been reset to the factory settings, two operators are used for the sweep triggering and waiting for the sweep completion:

```
app.SCPI.TRIGger.SEQuence.Source = "BUS"
app.SCPI.TRIGger.SEQuence.Single
```

The first operator sets the LAN bus command or the COM/DCOM interface command as a trigger source. It aborts the sweep and switches the instrument to waiting for a trigger. The second operator is used for a new sweep triggering and waiting for the sweep completion.

**Note**

Unlike the SCPI.TRIGger.SEQuence.IMMEDIATE and SCPI.IEEE4882.TRG commands, which are completed immediately after a trigger generation, the SCPI.TRIGger.SEQuence.Single command is not completed until the end of the sweep. Using the SCPI.TRIGger.SEQuence.Single command is the simplest way to set the waiting for the sweep completion.

On completion of the sweep, three arrays are read out: frequency values, magnitude values and phase values. Before the magnitude and phase arrays are read out, the corresponding trace format is set.

The array size of frequency  $F$  is equal to the number of measurement points, and the array size of magnitude  $M$  and phase  $P$  is equal to the double number of measurement points (see section 12). In rectangular formats (for magnitude and phase) the measurement data are real numbers located in even cells of the array. Odd cells of the array contain 0.

On completion of the program, the frequency, magnitude and phase values for each measurement point are written string by string into the file named *TESTFILE*.

```
Dim app As Object
Dim F, M, P

Public Sub Example4()
Set app = CreateObject("RVNA.Application")

app.SCPI.SYSTem.PRESet

app.SCPI.TRIGger.SEQuence.Source = "BUS"
app.SCPI.TRIGger.SEQuence.Single

F = app.SCPI.SENSE.Frequency.Data

app.SCPI.Calculate.Selected.Format = "MLOG"
M = app.SCPI.Calculate.Selected.Data.FDATA

app.SCPI.Calculate.Selected.Format = "PHASE"
P = app.SCPI.Calculate.Selected.Data.FDATA

Open "TESTFILE" For Output As #1

For i = LBound(F) To UBound(F)
    Print #1, F(i), M(i * 2), P(i * 2)
Next i

Close #1
End Sub
```

### Example 5. Program Written in C++

The following C++ program represents an example of the measurement parameter setting, as well as acquisition and display of the measurement data array. The program also shows a method of the sweep triggering and waiting for the sweep completion.

```

//-----
// Simple example of using COM object of RVNA.exe application.
// This example is console application. GUI is not used in this example to
// simplify the program. Error processing is very restricted too.
#include "stdafx.h"
//-----
// Generate description of COM object of RVNA.exe application.
#import "RVNA.exe" no_namespace
//-----
int _tmain(int argc, _TCHAR* argv[])
{
    IRVNAPtr pNWA;                                // Pointer to COM object of RVNA.exe
    CComVariant Data;                             // Variable for measurement data
    // Init COM subsystem
    HRESULT hr = CoInitialize(NULL);
    if(hr != S_OK) return -1;
    // Create COM object
    hr = pNWA.CreateInstance(__uuidof(RVNA));
    if(hr != S_OK) return -1;
    // Preset network analyzer
    pNWA->SCPI->SYSTem->PRESet();
    // Set frequency start to 1 GHz
    pNWA->SCPI->SENSe[1]->FREQuency->STARt = 1e9;
    // Set frequency stop to 1.2 GHz
    pNWA->SCPI->SENSe[1]->FREQuency->STOP = 1.2e9;
    // Set number of measurement points to 51
    pNWA->SCPI->SENSe[1]->SWEep->POINTS = 51;
    // Set trigger source to GPIB/LAN bus or COM interface
    pNWA->SCPI->TRIGger->SEQuence->SOURCE = "bus";
    // Trigger measurement and wait
    pNWA->SCPI->TRIGger->SEQuence->SINGLE();
    // Get measurement data (array of complex numbers)
    Data = pNWA->SCPI->CALCulate[1]->SElected->DATA->FDATA;
    // Display measurement data.
    // Data is array of NOP * 2 (number of measurement points).
    // Where n is an integer between 0 and NOP - 1.
    // Data(n*2)      : Primary value at the n-th measurement point.
    // Data(n*2+1)    : Secondary value at the n-th measurement point. Always 0
    //                  when the data format is not the Smith chart or
    the polar.
    CComSafeArray<double> mSafeArray;
    if (mSafeArray.Attach(Data.parray) == S_OK)
    {
        for (unsigned int n = 0; n < mSafeArray.GetCount() / 2; ++n)
        {
            printf("%+.9E\t%+.9E\n",
                   mSafeArray.GetAt(n*2),
                   mSafeArray.GetAt(n*2+1));
        }
        mSafeArray.Detach();
    }
    printf("Press ENTER to exit.\n");
    getc(stdin);
    // Release COM object
    pNWA.Release();
    CoUninitialize();
    return 0;
}

```